

---

---

# xChime

**Technical Model Name: XHV1**

**Technical Model Number: SCHV1AE0**

---

---



---

---

## User's Guide

---

---

---

# Table of Contents

---

CHAPTER 1 INTRODUCTION..... 1

    Physical Details ..... 2

CHAPTER 2 BASIC SETUP..... 4

    Installation ..... 4

APPENDIX A SPECIFICATIONS..... 5

    Spec ..... 5

    Regulatory Approvals ..... 6

    Label Information ..... 8

Copyright © 2016. All Rights Reserved.

Document Version: 1.0 All trademarks and trade names are the properties of their respective owners.

---

## Chapter 1

# Introduction


# 1

xChime is a plug-in wireless speaker device that directly plugs into standard 120V AC wall outlet and provides audible alerts anywhere in your home when an event of interest happens via a compatible smart home device

### Features

- ***Supports WiFi 5 Wireless Standard.*** The xChime product is an 802.11ac device with a dual-band dual-selectable 2.4GHz and 5GHz radio
- ***Support Plug standard outlet.*** The xChime product support standard plug

Physical Details



---

**Reset Pin Hole**

To restore the device to the original factory settings:

- Power On
- Gently press and hold for over 5 sec then release to restore the device to factory settings.

**Pairing Button**

Push the pairing button on the device easily creates an encryption-secured wireless connection automatically.

**POWER indicator  
(Blue/White)**

**Solid White** - The xChime is booting up.

**Blinking White** - The xChime is ready to pair or pairing.

**(Note: May change  
in future)**

**Solid Blue** - The xChime is connected to WiFi, working normally.

**Solid Amber** - The xChime is not connected to a router or has trouble connecting.

SERCOMM CONFIDENTIAL

---

## Chapter 2

# Basic Setup



*This Chapter provides information on how to install the xChime.*

### Installation

You must complete the following installation procedure when using the device

#### Step

1. Plug in the xChime to the power outlet
2. Download the Xfinity app from Google Play or App Store
3. Sign into the app with your Xfinity Credentials
4. Select "Security" tab
5. Select Add a Device then choose Xfinity xChime to start setting up
6. Follow the instructions in the app to finish setup of the device and you can use the same device functions in the same app after setup the device

#### WARNING

1. This is indoor use only.
2. Do not place the chime unit near a heat source, such as near a radiator or baseboard heater.

# Appendix A

## Specifications

Spec

xChime	
Model	xChime
Dimensions (without Prongs) (h x w x d)	4 x 2 x 1.7 in (102 x 52 x 44 mm)
Color	White
Power Input	Directly plugs into standard power outlets in North America Power Input: 120V, 60Hz, 0.25A
Wireless	802.11AC 2 x 2 Dual band selectable, Low Energy Bluetooth 4.1 for pairing
Speaker	1 Built-in Speaker
Status Light Indicator	1 Status LED
Buttons	1 Reset Pin Hole Button 1 Pairing Button
Operating Temperature	32°F to 104°F (0° C to 40° C)
Storage Temperature	-4°F to 158°F (-20° C to 70° C)
Housing or use case	Indoor Only
Regulatory	UL, cUL, IC and FCC Listed

---

## Regulatory Approvals

### Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### IMPORTANT NOTE:

##### Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Operations in the 5.15-5.25GHz band are restricted to indoor usage only.



**Industry Canada statement:**

This device complies with ISED's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) le dispositif ne doit pas produire de brouillage préjudiciable, et (2) ce dispositif doit accepter tout brouillage reçu, y compris un brouillage susceptible de provoquer un fonctionnement indésirable.

**Radiation Exposure Statement:**

This equipment complies with ISED radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with greater than 20cm between the radiator & your body.

**Déclaration d'exposition aux radiations:**

Cet équipement est conforme aux limites d'exposition aux rayonnements ISED établies pour un environnement non contrôlé. Cet équipement doit être installé et utilisé à plus de 20 cm entre le radiateur et votre corps.

**Caution :**

(i) the device for operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems;

(ii) where applicable, antenna type(s), antenna models(s), and worst-case tilt angle(s) necessary to remain compliant with the e.i.r.p. elevation mask requirement set forth in section 6.2.2.3 shall be clearly indicated.

**Avertissement:**

(i) les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux;

(iv) lorsqu'il y a lieu, les types d'antennes (s'il y en a plusieurs), les numéros de modèle de l'antenne et les pires angles d'inclinaison nécessaires pour rester conforme à l'exigence de la p.i.r.e. applicable au masque d'élévation, énoncée à la

Label Information

Deice Label Sample (Label size: 21\*20.5mm)



Box label Sample (Label size: 45\*35mm)

