


Remote Control Outlets

Operating Instructions



FOR INDOOR/OUTDOOR USE



1

IMPORTANT SAFEGUARDS

Signal Word Definitions

NOTE: These are general definitions only; all may not pertain to the actual product purchased.

DANGER - Indicates an imminently hazardous situation, which, if not avoided, will result in death or serious injury. Usage of this signal word is limited to the most extreme situations.

WARNING - Indicates a potentially hazardous situation, which, if not avoided, could result in death or serious injury.

CAUTION - Indicates a potentially hazardous situation, which, if not avoided, may result in minor/moderate injury or product/property damage. It also alerts against unsafe practices.

When using electrical products, always follow basic safety precautions including the following:



READ ALL INSTRUCTIONS BEFORE USE.



WARNING-- To reduce the risk of fire, electric shock, or serious personal injury:

- Do not immerse the product in water or other liquids.
- This product is not intended for use by children and contains small parts that may pose a choking hazard to children under the age of three. Keep the product out of the reach of children and pets.
- Do not use an electrical device or appliance with this product whose electrical specifications exceed those specified in the "Electrical Specifications" section of this manual.



CAUTION-- To reduce the risk of personal injury or product/property damage:

- This product is intended for non-commercial, non-industrial use in the remote control of one electrical outlet. Do not use this product for any other purpose.

2

WARNING: This product is equipped with a three-prong grounding pin plug to reduce the risk of electric shock. This plug will fit into a grounded outlet only one way. This is a safety feature. Never use the plug with an extension cord unless you can fully insert the plug into the extension cord. Do not alter the plug. Do not attempt to defeat the safety purpose of the grounding plug.




RECEIVER MODEL: RC-017
TRANSMITTER MODEL: TR-031-6
FCC ID: PAGTR-031-6
IC : 4494A-TR0316

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

TO USE

1. To set up the three Receivers (outlets) with various devices, locate channel 1, 2, 3, on the Remote Control and the 1, 2, 3, on each Receiver and select ON/OFF function with same channel (Channel 1, Channel 2, Channel 3, ...) respectively.
2. To activate the Receiver, press the '1' Button of the Remote Control. The red LED of the Remote Control will illuminate momentarily and the LED of the Receiver will remain illuminated.
3. To turn the Receiver OFF, press the '0' Button of the Remote Control. The LED on the receiver will shut off.



3

Features

- Controls electrical outlet up to a distance of 100 feet
- Has one three-prong receptacle

Caution:

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment with is not to be used for an extended period of time.
- Remove used batteries promptly.

To Set Up

1. Mount the Receiver near a three-prong, grounded, standard 125-volt AC electrical outlet:
 - a. Choose a location on the wall to insert a nail or wood screw (not included) for mounting the Receiver. Please note the following when choosing the location:
 - When hung from the nail/screw, the Receiver must be close enough to the outlet for the cord to plug into the outlet.
 - The Receiver must be mounted vertically with its outlets facing downward and not reaching ground level.
 - b. Insert the nail/screw into the wall in the chosen location. The nail or screw head must extend at least 3/16" from the wall.
 - c. Hang the keyhole of the Receiver on the nail or screw.
2. Plug the Receiver into a standard 125-volt AC electrical outlet.
3. Confirm that the electrical specifications of an item you wish to use with this product do not exceed those specified in the "Electrical Specifications" section. Plug the item into an outlet of the Receiver.
4. Remove the plastic battery tab from the Battery Compartment in the back of the Remote Control to activate the DC 12V Type A23 pre-installed battery.
5. The device must be mounted in a vertical position with the receptacle facing downward and with the receptacle at least 2 feet above the ground level not for water immersion.

4

To Use

1. To activate the Receiver, press the ON Button of the Remote Control. The red LED of the Remote Control will illuminate momentarily and the LED of the Receiver will remain illuminated.

NOTE: The Remote Control must be within 100 feet of the Receiver.
2. To turn the Receiver off, press the OFF Button of the Remote Control. The LED on the Receiver will shut off.

Battery Handling and Usage

- WARNING:** Keep batteries away from children and pets.
- Follow the battery manufacturer's safety and usage instructions.
 - Insert the battery observing the proper polarity (+/-) as indicated inside the Battery Compartment.
 - Remove a spent or discharged battery from the product. remove the battery when not using the product for an extended period.
 - Never throw batteries into a fire. Do not expose batteries to fire or other heat sources.
 - Battery contains mercury. Do not put in trash. Recycle or manage as hazardous waste.
 - Dispose or recycle spent / discharged batteries in compliance with all applicable laws. For detailed information contact your local solid waste authority.

Battery Replacement:

- Remove the Battery compartment cover from the side of the remote control.
- Remove the spent battery and place a new 3V battery into the Battery Compartment correctly observing the polarity indications (+/-) inside the Battery Compartment.
- Replace the Battery Compartment.
- Clear the battery contacts and also those of the device prior to battery installation.

Electrical Specifications

Voltage	Frequency	Wattage	Amperage	Horse Power
125VAC	60Hz	*1000W-1250W	10A	1/3HP

*Maximum combined wattage for items using a tungsten bulb plugged into the Receiver is 1000W.

*Maximum combined wattage for appliances plugged into the Receiver is 1250W.



WARNING: Cancer and Reproductive Harm -
www.P65Warnings.ca.gov

5

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for Class B digital device, harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation of the device.

FCC Caution: The Grantee is not responsible for any changes or modifications not expressly approved by the party responsible for compliance, such modifications could void the user's authority to operate the equipment.

Industry Canada statement:

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Déclaration d'Industrie Canada :

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Unique Identifier :
KAB Model No. : RC-017/TR-031-6
Responsible Party - U.S. Contact Information
Company Name :
Customer Address :
Tel/Internet Contact :

Made in China

6