


Size: W-279.4 x H-108/mm

USE AND CARE GUIDE

OUTDOOR WIRELESS REMOTE CONTROL



Safety Information

Federal Communications Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help
- This device complies with Part 15 of the FCC Rules. Operation is subject to the

following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Industry Canada statement:

This Class B digital apparatus complies with Canadian ICES-003. This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Déclaration d'Industrie Canada :

Cet appareil numérique de classe B est conforme au système Canadien ICES-003. Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device must be mounted in a vertical position with the receptacle facing downward and with the receptacle at least 2 feet above the ground level not for water immersion.

Purpose of control :

- Operating Control
- Cord-connected

RATINGS

125Vac 60Hz ; 15 A General Use ; 15 A Resistive, 1000 W Tungsten

500 VA Electronic Ballast, 1/2 HP, 120Vac 60Hz 8.3A Ballast

Product Description





WARNING: For outdoor use.

1. **Power indicator light:** The power indicator light indicates that the receiver is on.

2. **Outlets:** The outlets located at the base of the receiver allow the user to plug an array of devices into it. Plug the lights or devices to be controlled by the remote into the outlets.

3. **Remote control :**

- ON:** When the on button is pressed, it will override the receiver's current program to on function.
- OFF:** When the off button is pressed, it will override the receiver's current program to off function.
- Remote indicator lights:** The LED lights indicate that the ON or OFF button is being pressed.



Operating Instructions

1 Using the remote control

- Plug the receiver into an outlet. Plug the devices to be controlled into the outlets on the receiver.
- To activate the receiver, press the "ON" button of the remote control. The red LED of the remote control will illuminate momentarily and the LED of the receiver will remain illuminated.
- To turn the receiver OFF, press the "OFF" button of the remote control. The LED on the receiver will shut off.

Maintenance

2 Replacing the battery



WARNING: Do not mutilate or place the battery in a fire. The battery may burst or release toxic materials. Do not short-circuit or reverse polarity as this may cause burns.

- Remove the battery compartment cover from the back of the remote control by sliding the cover in the direction that its threads curve.
- Remove the old battery and place a new DC 12V Type A23 battery into the battery compartment, correctly observing the polarity indications (+/-) inside the battery compartment.
- Replace the battery compartment cover.
- Dispose or recycle spent/discharged batteries in compliance with all applicable laws. For detailed information, contact your local solid waste authority.
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed correctly with regard to polarity (+ and -).
- Remove batteries from equipment when it is not to be used for an extended period of time.
- Remove used batteries promptly.

Troubleshooting

Problem	Solution
The lights do not turn on and off via remote control.	Confirm remote operation after replacing batteries.
The lights do not turn on, even when the power indicator light indicates that the receiver is on.	Ensure the lights are functional by plugging them directly into an outlet. Be sure that the lights are in the "ON" position if they have their own switch. Be sure that the outlet that the receiver is plugged into is active.

Distributed by
Treemote Inc.
www.treemote.com
Made in China
SAVE THESE INSTRUCTIONS!

RECEIVER MODEL: RC-043
TRANSMITTER MODEL: TR-032-B
FCC ID: PAGTR-032-B
IC: 4494A-TR032B