

ROBOTS PUNCH LEFT & RIGHT, PLUS MOVE FREELY FOR 360-DEGREE BOXING ACTION!

WARNING: Small parts. Not suitable for children under 3 years.



- Full-Motion Arms Perform Hooks and Power Jabs
- Robot Head Ejects When Chest Plate Is Punched
- Includes Dual Remote Controls For Wireless Boxing Matches
- Nested Wheels Propel Robots In All Directions

BLUE HAT TOY COMPANY



TWO-PLAYER RADIO CONTROLLED BOXING

BATTLE BOXING ROBOTS

BATTLE BOXING ROBOTS

TWO-PLAYER RADIO CONTROLLED BOXING



AGES 6+

BATTERY OPERATED PLAY ROBOTS

AGES 6 AND UP
WARNING! CHOKING HAZARD - Small parts. Not suitable for children under 3 years.

JL2014A



2 PLAYER ACTION!



BATTLE BOXING ROBOTS

TWO-PLAYER RADIO CONTROLLED BOXING



"POW!"

WINDOW DIE-CUT

Tray Insert Prints 40C/100Y (Green)



BATTLE BOXING ROBOTS

TWO-PLAYER RADIO CONTROLLED BOXING

Toy RC Boxing Robots

See bottom panel for important battery information. Colors and styles may vary.



- EXCITING ROBOTIC BOXING ACTION!**
- Robot's Head Ejects When Chest Plate Is Hit By Opponent
 - Two Robots/Remote Controls For Thrilling 2-Player Battles
 - Perform Hooks, Jabs And 360-Degree Spins
 - Play Head-To-Head For Hours Of Interactive Fun



Each robot requires 3 "AAA" 1.5V alkaline batteries (not included). Each remote control requires 1 "9V" alkaline battery (not included). See bottom panel for important battery information. Colors and styles may vary.



SAFETY PRECAUTIONS:

- Do not use the product near small children or animals. The detachable head can pose a choking hazard.
- Adult supervision is recommended at all times.
- Avoid electric shock and never swim with your vehicle. Never submerge any portion of the product in water.
- Never touch the product near sources of heat, under direct sunlight or outside overnight as this is harmful to internal components.

BATTERY WARNING:

- Do not mix old and new batteries.
- Do not use alkaline, silver-oxide, or rechargeable (nickel-cadmium, nickel-metal hydride) batteries.
- Insert batteries using the correct polarity. Do not short-circuit the exposed terminals.
- Remove batteries when not in use. Remove or dispose of exhausted batteries according to local, state, and federal laws. Do not dispose of batteries in the fire.
- Do not use damaged or recalled batteries, cheap/used or other adapters.
- Do not use damaged or recalled batteries, cheap/used or other adapters.
- Always use, replace, and recharge if applicable batteries under adult supervision.

KEEP THIS PACKAGE FOR REFERENCE AS IT CONTAINS IMPORTANT INFORMATION.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

©2014 MercoSource, LLC. Blue Hat Toy Company, Blue Hat Toy Company logos are trademarks of MercoSource, LLC, used under license. All rights reserved. Distributed by MercoSource, LLC, Irvine, CA 92618. China Patent No. 201320381109.3. PATENT PENDING.


For technical support, please visit www.mercoSource.com or call 1-800-274-2746. The artwork and design of this package are protected by copyright laws and may not be reproduced, distributed, displayed, published or used for any purpose without prior written permission. It is not permitted to alter, reuse or reproduce any trademark or copyright notice from this package.

OPERATING INSTRUCTIONS

Each robot requires 3 "AAA" 1.5V batteries (not included). Each remote control requires 1 "9V" battery (not included). When charging batteries, adult supervision is required. Use alkaline batteries for best performance.

1. Carefully remove items from the package.
2. Locate the battery compartment on the back of each robot, as well as each remote.
3. On robots, loosen the screws and remove battery doors. Slide doors open on rc units.
4. Insert "AAA" alkaline battery robot while observing the correct polarity in each compartment (see diagrams). Insert one 9V battery into each remote control.
5. Replace the battery doors and tighten screws.
6. Switch robot and remote control power switches to the "ON" position. The power switch is located on the side of the robot.

NOTE: Before use, adjust the robots to make sure both feet have good contact with the ground before use. Use on a hard, flat surface for best results.



HOW TO PLAY

There are sensors located beneath each robot's chest plate. The object of the game is to knock the opposing boxer's head off by making contact with the chest plate during the robot's head. To replace the head, slide a face forward onto the neck and gently press down until it clicks into place.

WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

32.5x22x27cm