 <small>A Phoenix Mecano Company</small>	Issue department: Bedding Division	Date:	2017-08-23
	Product Function instruction	Author:	Kyle
CB.13.22.02		No: CB1322	
	Version:	1.1	
Page 2 of 5			

Function instruction

Function Picture



1. Process of test

1.1. HEAD MOTOR

Connect to head actuator, control by remote single:

Click head up button on the remote, head actuator moves out, stop when released;


Click head down button, head actuator moves in, stop when released;

This function takes effect only by pressing the corresponding button on the remote.

1.2. FOOT MOTOR

Connect to foot actuator, control by remote single:

Click foot up button, foot actuator moves out, stop when released;

 <small>A Phoenix Mecano Company</small>	Issue department: Bedding Division	Date:	2017-08-23
	Product Function instruction	Author:	Kyle
CB.13.22.02		No: CB1322	
	Version:	1.1	
	Page 3 of 5		

Click foot down button, foot actuator moves in, stop when released;
This function takes effect only by pressing the corresponding button on the remote.

1.3. Massage

Connect to head & Foot massage, control by remote:
Click head massage + button, head massage strengthens by one level;
Click head massage - button, head massage weakens by one level;
This function takes effect only by pressing the corresponding button on the remote.

1.4. Test for underbed light

Click button of underbed light, turns on (or turns off) the underbed light, switch the status once when click once;
This function takes effect only by pressing the corresponding button on the remote.

1.5. SYNC port

Connect with the same other Control box or Other accessories;

1.6. Power LED & PAIRING LED

Power supply for control box, PAIRING LED of control box is blue, POWER LED is green.

1.7. Power


Connect to the 29V DC;

1.8. RESET button

Press and hold the RESET button (Corresponding Pair button), the Head, Foot actuators will move to lower position. Long press is reset.

1.9. Pair Function

Double click RESET button, pairing LED turns on, the control box enters into mode of code pairing;
Press and hold the pairing LED of Remote, the backlight of pairing LED flashes, the backlight of remote flashes, the remote enters into mode of code pairing;

 <small>A Phoenix Mecano Company</small>	Issue department: Bedding Division	Date:	2017-08-23
	Product Function instruction	Author:	Kyle
CB.13.22.02		No: CB1322	
	Version:	1.1	
	Page 4 of 5		

The backlight of paring LED of remote stops flashing, and the paring led of control box turns off, it indicates that the code paring is successful;

Press and release the FLAT button on remote, the head and foot actuators moves to lower position (when the actuator is free, can turn off the vibration motor and turn off the indicator light when press once), stop when press any button;

1.10. FLAT function

This function takes effect only by pressing the corresponding button on the remote.



1.11. ZERO G position function

Press and release ZERO G button on remote, the head and foot actuator moves to preset memory position, stop when press any button;

This function takes effect only by pressing the corresponding button on the remote.

FCC warning:

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

ISED RSS Warning:

This device complies with Innovation, Science and Economic Development Canada licence exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.


Le présent appareil est conforme aux CNR d'ISED applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et
- (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.



RF.30.19.02



B.15227

B.15226

JLDQ.9.001.130C

NO.	Product name	Product code	number
1	Head Motor	B.15227	1
2	Foot Motor	B.15226	1
3	Massage Motor	JLDQ.9.001.130C	2
4	Massage Motor Cable	R5.410.01.009	1
5	Control Box	CB.13.22.02	1
6	Power Supply	JLDP.10.023.000	1
7	Power Cord	R5.217.01.016	1
8	ANSI power cord	R5.504.01.250	1
9	Y cable	R5.216.01.015C	1
10	Patch cord of LED strip	R5.413.01.005	1
11	LED strip/ LED	R5.113.00.011	1
12	USB Socket/USB	JLDP.05.032.000	1
13	Double USB Chager	JLDP.14.027.000	2
14	19Keys remote	RF.30.19.02	1

System-drawing		M550 V1.3	
Format	A4	Date	Name
Drawed		2017 07 31	John
Checked			

