

## Photograph No.1 Peak output power, power spectral density, occupied bandwidth and conducted spurious emissions measurement setup





Photograph No.2 Spurious emissions measurement setup in the anechoic chamber below 30 MHz

Photograph No.3 Spurious emissions measurement setup in the anechoic chamber in 30 – 1000 MHz





Photograph No.4 Radiated emissions measurement setup at the OATS



## Photograph No.5 Frequency stability test setup

## Photograph No.6 Frequency stability test setup





Photograph No.7 Conducted emissions measurement setup on AC line