



Warranty

All Maisto R/C Vehicles have a 30 day limited warranty in function and performance. You may receive a new replacement vehicle if the defective vehicle is returned to Maisto freight prepaid and confirmed to be factory defective. We are not responsible for defects due to abusive use, or damaged for reasons other than factory defects. We also reserve the right to make the final judgment and decision. Check the FAQ section before you return the unit to Maisto.

FAQ (Frequently Asked Questions)

1) Why does my R/C Vehicle not start?

- Make sure the Transmitter and the Vehicle are turned on.
- Make sure the Battery Pack is fully charged and the Battery is full.
- Make sure the Batteries are installed per polarity indicators.
- Make sure all 4 wheels are not obstructed by any foreign objects.
- Make sure the Transmitter and the Vehicle are set at the same channel.

2) Why does my R/C Vehicle make unusual noises?

- Check to make sure the Battery Pack is fully charged and the Battery is full.
- Check to make sure all 4 wheels are not obstructed by any foreign objects.

3) Will my R/C tires wear out quickly like some other R/C cars?

- Tires on Maisto R/C vehicles should not wear out quickly under normal use. However if necessary, new tires can be purchased. See the Maisto contact information below.

4) How do I buy replacement parts for my Maisto R/C Vehicle?

- New parts can be purchased. See the Maisto contact information below.

5) What if I'm still having a problem?

- Check the FAQ and make sure all attempts have been made to make the unit work.
- Check your purchase receipt date and make sure it's within the 30 days warranty period at the time you intend to send it back.
- Contact Maisto (see below), and tell us the model that you have, the problem(s) you are having, your daytime phone number, and any other information that might be helpful to us to correct the problem.
- If Maisto cannot solve your problem by mail, email or telephone, we will issue a return authorization number so you can return the unit to us for repair or replacement. No returns will be accepted without a return authorization (RA) number issued by Maisto clearly marked on the outside of the package. Pack the unit back in its original box or another box with sufficient protective material, include a copy of your dated store receipt and a description of the problem then send it freight prepaid to the address which we will provide once you receive your RA number.

Website: www.maisto.com
Email: rcsupport@maisto.com
Phone: (866) 357-7988
8:30 a.m. - 5:00 p.m. Monday-Friday Pacific Time

MADE IN CHINA

Size: A4 291mm(W) x 210mm(H)
Color: 1C (Black)
Paper: 128gsm 雙粉紙



Eng #B1019/#B1022/#B1024/#B1025/#B1032/#B1041/#B1044 Rev 3

CAUTION - ELECTRIC TOY
NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK.
INPUT : 120V AC 60Hz ONLY.
OUTPUT : 12V DC 200 mA.

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Maisto Radio Control Vehicles

The packaging has to be kept since it contains important information.
Class 1 LED Product

Contents:


- RC Vehicle x 1
- Transmitter x 1
- Transmitter Antenna x 1
- 4-Hour Battery Charger x 1
- 9.6V Rechargeable Battery Pack (For Vehicle Use) x 1
- 9V(6F22) non-rechargeable Battery (For Transmitter Use) x 1
- Instruction Manual x 1

MAI CHONG TOY PRODUCTS PTE. LTD.				DISCUSS	
Author	ARTIST/CH Designer/Eng	Product	ART	Issue	28-12-2008
Rev	0101	110112	12	Revision/Rev	01




Battery Charging:

1. Connect the 9.6V Battery Pack and the Charger connectors.
2. Plug the Charger into a standard electrical outlet.
3. Charging time is around 4 hours.
4. When charging is complete, detach the connectors and remove the Charger from the electrical outlet.




Transmitter: Battery and Antenna Installation

1. Switch the power OFF.
2. Open the Battery Cover.
3. Install a 9V Battery with correct polarity (+/-) as shown inside the Battery compartment.
4. Close the Battery Cover.
5. Screw the Antenna into the Transmitter securely.




Vehicle: Battery Pack installation

1. Switch the power to the OFF position.
2. Turn the Battery Knob and lift up the Battery Cover.
3. Install the Battery Pack into the battery compartment and plug it into the connector correctly.
4. Close and lock the Battery cover.



How to play:

1. Fully extend the Antenna of the Transmitter.
2. Match the Transmitter with the Vehicle Channel (Channel A or B or C).
3. Switch ON the transmitter, the red LED will light up.
4. Switch ON the Vehicle.
5. The Headlight features (LH, Low beam and H-H-beam) can be controlled on the Transmitter.
6. Pull the trigger to go forward, push it to go backward and release it to stop.
7. Turn the Transmitter steering wheel to move the Vehicle left or right.
8. If the Vehicle does not run in a straight line, adjust the wheel alignment arm on the Vehicle chassis.
9. Switch OFF the Transmitter and Vehicle power after playing.



Performance Tips:

1. Do not drive on grass, sand, carpet or go through water.
2. Do not drive in windy or rainy weather.
3. Avoid colliding with hard surfaces.
4. Switch OFF the Vehicle and Transmitter when not in use.
5. Remove all Batteries from the Vehicle and Transmitter when not in use.
6. Fully extend the antenna for best performance and do not point the antenna toward the vehicle.



7. Keep fingers, hair and loose clothing away from the wheels.
 8. The operating range can be affected by a variety of factors:
 - a) Weak Transmitter Battery, or under-charged Battery Pack.
 - b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency.
 - c) CB radios, cordless phones, high voltage transformers, etc.
 - d) Outdoor usage is recommended in order to get optimal control range (72 feet or 22 meters).
- Cautions :**
1. The 9.6V Battery Pack must be charged before use by utilizing the 4-Hour Battery Charger which is included.
 2. Do not overcharge the Battery Pack. Do not charge for more than 6 hours.
 3. Do not charge the Battery Pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.
 4. Do not cover the Battery Pack with any sort of material while charging.
 5. Do not touch the Battery Pack when it is hot. Wait until the Battery Pack cools before installing it in the Vehicle and before recharging.
 6. Do not dispose of the Battery in fire.
 7. Do not dismantle the Battery or Charger, and do not cut the Battery or Charger cables.
 8. The Battery Pack will be warm after charging, and hot after use in a Vehicle.
 9. The supply terminals are not to be short-circuited.
 10. Rechargeable Batteries are to be removed from the toy before being charged.
 11. Rechargeable Batteries are only to be charged under adult supervision.
 12. Battery charge must be only made by adult.
 13. Charge Only Type (700mAh Max.) rechargeable Battery Packs. Other types of Batteries may burst causing injury to persons and damage. This power unit is intended to be correctly orientated in a vertical or floor mount position. Regular examination of Battery Charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the Charger or Battery Pack charge until such damage has been repaired.
- Note that the 9V Battery is non-rechargeable and is not to be recharged. Only Batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor. Exhausted Batteries are to be removed from the Transmitter.

FCC Label Compliance Statement:


This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.
- Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures :
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.

The Manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's Authority to operate the equipment.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:
Pb = Battery contains lead
Cd = Battery contains cadmium
Hg = Battery contains mercury