



Warning : Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries.

You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

- Pb = Battery contains lead
Cd = Battery contains cadmium
Hg = Battery contains mercury

Warranty

All Maisto R/C products have a 30 days limited warranty in function and performance. You may receive a new replacement product if the defective product is returned to Maisto...

FAQ (Frequently Asked Questions)

1) Why does my R/C Vehicle not start?

- Make sure that the car and transmitter are set to the same channel (A, B or C).
Make sure the transmitter and the vehicle are turned on.
Make sure the battery pack is fully charged and the battery is full.

2) Why does my R/C Vehicle make unusual noises?

- Check to make sure the battery pack is fully charged and the battery is full.

3) Will my R/C tires wear out quickly like some other R/C cars?

- Tires on Maisto R/C vehicles should not wear out quickly under normal use. However if necessary, new tires can be purchased. See the Maisto contact information below.

4) What if I'm still having a problem?

Check the FAQ and make sure all attempts have been made to make the unit work. Check your purchase receipt date and make sure it's within the 30 days warranty period at the time you intend to send it back.

5) Please refer to FAQ section on our website for more information.

Website: www.maisto.com
Email: customer@maisto.com
Phone: (800) 357-7888



www.maisto.com
MADE IN CHINA Eng (R6)



Age 8+

#81019

CAUTION - ELECTRIC TOY

NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK.

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

Maisto Radio Control Vehicles

Please keep this owner's instruction manual for future reference. It contains important information. We reserve the right to improve/revise the product specifications without notice.


Contents:

- RC Vehicle x 1
Transmitter x 1
3-Hour Battery Charger x 1
6V Rechargeable Battery Pack (For Vehicle Use) x 1
1.5V "AA" LR6/R6 non-rechargeable Battery (For Transmitter Use) x 2
Owner's Instruction Manual x 1



Battery Charging (Refer to Diagram 1):

- 1. Connect the 6V battery pack and the charger connectors.
2. Plug the charger into the AC socket.
3. Initial charge: allow battery pack to be charged for a minimum of 4 hours for the first two times. Subsequent charging time is around 3 hours.




Battery installation for the transmitter (Refer to Diagram 2):

- 1. Set the power switch on the transmitter to "off" position.
2. Open the battery cover.
3. Install 2 new 1.5V "AA" LR6/R6 batteries with correct polarity (+/-) as shown inside the battery compartment.




Battery installation for the vehicle (Refer to Diagram 3):

- 1. Switch the power to the OFF position.
2. Turn the battery cover latch and open the battery cover.
3. Install the battery pack into the battery compartment and plug it into the connector correctly.





How to play:

- 1. Select and match the channel: A, B or C for both the transmitter and the vehicle (Refer to Diagram 4 & 5).
2. Turn on the transmitter by switching the power switch to A, B or C position, the Power LED will turn on.
3. Switch ON the vehicle.
4. The headlight features (OFF, Hi-Beam) can be controlled on the transmitter.
5. Pull the trigger to go forward, push it to go backward and release it to stop (Refer to Diagram 6).
6. Turn the transmitter steering wheel to move the vehicle left or right (Refer to Diagram 6).
7. If the vehicle does not run in a straight line, adjust the wheel alignment arm on the vehicle chassis (Refer to Diagram 7).
8. Switch OFF the transmitter and vehicle after playing.



Performance Tips:

- 1. Do not drive the vehicle on grass, sand or go through water.
2. Do not drive the vehicle in windy or rainy weather.
3. Do not drive the vehicle into any hard object.
4. Always switch the power OFF on the remote-controller and vehicle when you are done playing. Remove all batteries when not in use to prevent leakage of electrolyte which could damage the transmitter and the vehicle.
5. Keep fingers, hair and loose clothing away from the vehicle.



- 6. The operating range can be affected by a variety of factors:
A) Weak transmitter battery, or under-charged battery pack.
B) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
7. Outdoor usage is recommended in order to get optimal control range.
8. We recommend that you play with the vehicle in a flat and clean area.
9. Do not drive the vehicle into people or animals.
10. When you start playing, turn on the transmitter first and then the vehicle. After playing, turn off the vehicle first and then the transmitter.
11. Remove the package, take out all accessories and assemble the product before giving it to children to play.
12. Outdoor usage is recommended in order to get optimal control range (84 feet or 20 meters).
Cautions :
1. The 6V battery pack must be charged before use. Use only the battery pack charger that came with this vehicle.
2. Do not overcharge the battery pack. Do not charge for more than 4 hours.
3. Do not charge the battery pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.
4. Do not cover the battery pack with any sort of material while charging.
5. Do not touch the battery pack when it is hot. Wait until the battery pack cools before installing it in the vehicle and before recharging.
6. Do not dispose of the battery in fire.
7. Do not dismantle the battery or charger, and do not cut the battery or charger cables.
8. The battery pack will be warm after charging, and hot after use in a vehicle.
9. The supply terminals are not to be short-circuited.
10. Rechargeable batteries are to be removed from the toy before being charged.
11. Rechargeable batteries are only to be charged by an adult!
12. Battery charge must only be made by an adult!
13. The charger is not a toy.
14. Only use the charger to charge the 6V 700mAh Max. battery pack that comes with the product. Other types of battery may burst causing injury to persons and damage. This power unit charger is intended to be used in a vertical or floor mount position. This quick charger is intended to be used for charging 6V Rechargeable battery pack with capacity 700mAh Max. Regular examination of Battery Charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the Charger or Battery Pack charge until such damage has been repaired.
15. Note that the 1.5V "AA" Battery is non-rechargeable and is not to be recharged. Only batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor. Alkaline AA batteries are recommended to be used for the transmitter. Do not mix alkaline, standard or rechargeable batteries. Do not mix old and new batteries or different type of batteries. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
16. Exhausted batteries must be removed from the product.

FCC Label Compliance Statement:

- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :
1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

Size: A4_291mm(W) x 210mm(H)
Color: 1C (Black)

Table with columns: MAY CHEONG TOY PRODUCTS FTY. LTD., DIECUT, and various identification numbers and dates.