



Hauler with X3 Scout



Eng #81120

Battery Use

1. Alkaline batteries are recommended to use.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Do not mix alkaline, standard or rechargeable batteries.
4. Do not mix old and new batteries or different type of batteries.
5. Non-rechargeable batteries are not to be charged.
6. If rechargeable batteries are used, they are only to be charged under adult supervision.
7. Rechargeable batteries are to be removed from the product before they are charged.
8. Be sure to insert batteries with the correct polarities and always follow the battery manufacturer's instructions.
9. Remove all batteries from the vehicle and transmitter when not in use.
10. Exhausted batteries are to be removed from the product.
11. The supply terminals are not to be short-circuited.
12. Dispose of batteries properly. Do not dispose the batteries in fire — it may cause them to explode or leak causing injury or damage.
13. Battery change must be only made by adults!

Cautions

1. Do not attempt to disassemble the products.
2. Do not operate the vehicle with same frequency with other players in same location that will interfere and make the vehicle out of control.
3. Make sure the batteries are installed with correct polarity (+/-) as shown inside the battery compartment.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.
- Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
 - Consult the dealer or an experienced radio/TV technician for help.
- The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's Authority to operate the equipment.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.

You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:



Pb = Battery contains lead
 Cd = Battery contains cadmium
 Hg = Battery contains mercury

Website: www.maisto.com
 Email: rcsupport@maisto.com
 Phone: (909) 357-7989
 8:30 a.m. - 5:00 p.m. Monday-Friday Pacific Time

MADE IN CHINA



WARNING:
CHOKING HAZARD - Small parts.
 Not for children under 3 years.

AGES 8+

Warning! Do not aim at eyes or face

Warning! Do not use projectiles other than those supplied or recommended by the manufacturer.

The packaging and instruction manual contain important information.

Please keep them for future reference.

Class 1 LED Product

1. Contents:

Hauler X1
 X3 Scout X1
 Transmitter X1
 Instruction Manual X1
 Discs X12

2. Battery requirement:

X3 Scout: 3 x 1.5V "AA" Alkaline batteries.
 Hauler: 6 x 1.5V "AA" Alkaline batteries.
 Transmitter: 1 x 9V Battery.

Size: A4_297mm(W) x 210mm(H)
 Color: 1C (Black)
 Paper: 128gsm 雙粉紙

MAY CHEONG TOY PRODUCTS FTY. LTD.			DIECUT	
Job Item: N-Art023/09	Printed by: CI	Date: 07-04-2009	Sheet No.:	
Part No.: #81120_illustration_Eng	Check by:	Date:	File Name:	




Hauler with X3 Scout

3. Battery installation:


Transmitter:

- 1) Turn the switch to OFF position.
- 2) Open the battery door.
- 3) Insert a new 9V battery as the polarity shown in the battery compartment. (as shown in the illustration).
- 4) Close the battery door.




X3 Scout :

- 1) Turn the switch to OFF position.
- 2) Open the battery door with a screwdriver.
- 3) Insert 3 new AA1.5V alkaline batteries as the polarity shown in the battery compartment.
- 4) Close and secure the battery with a screwdriver.



Hauler:


- 1) Turn the switch to OFF position.
- 2) Push to open the battery door.
- 3) Insert 6 new AA alkaline batteries as the polarity shown inside the battery compartment.
- 4) Close the battery door.



4. How to play:

X3 Scout:



- 1) Turn the B/A/OFF switch in the transmitter to A or B position, Red LED light will turn on.
- 2) Turn the Hauler/Car switch to Car position.
- 3) Turn the B/A/OFF switch in the X3 Scout to match the A or B position in the transmitter.
- 4) Pull the trigger in the transmitter to control X3 Scout driving forward. Push the trigger in the transmitter to control X3 Scout driving backward. Release the trigger to stop X3 Scout.
- 5) Turn the knob in the transmitter to control X3 Scout to turn left or right.
- 6) Align the front wheels under the chassis in case the car cannot run straight.



Hauler with X3 Scout

Hauler:

- 1) Turn the switch B/A/OFF in the transmitter to A or B position. The LED light turns on.
- 2) Turn the switch Hauler/Car to Hauler position.
- 3) Turn the switch B/A/OFF in the hauler to match the A or B position in the transmitter.
- 4) Lift up the cab roof to load 12 pieces of discs into the launcher.
- 5) Pull the trigger in the transmitter to control the hauler driving forward. Push the trigger in the transmitter to control the hauler driving backward. Release the trigger to stop the hauler.
- 6) Turn the knob in the transmitter to control the hauler to turn left or right.
- 7) Align the front wheels under the chassis in case the car cannot run straight.
- 8) Press the red button in the middle of the transmitter to launch the discs.



Drive X3 Scout onto Hauler

- 1) The ramp is lowered when the hauler is in normal position.
- 2) Turn the switch B/A/OFF in the transmitter to A or B position.
- 3) Turn the switch B/A/OFF in the hauler and X3 Scout to match the A or B position in the transmitter.
- 4) Turn the Hauler/Car switch to Car position.
- 5) Use the transmitter to drive the X3 Scout onto the hauler and the ramp will raise up automatically. Turn the switch Hauler/Car in the transmitter to Hauler position. Control the hauler to move with X3 Scout.

Performance Tips:

1. Do not drive on grass, dirt, sand, carpet or go through water.
2. Do not drive in windy or rainy weather.
3. Avoid direct impact with obstacles.
4. Switch off the vehicle and transmitter when not in use.
5. Keep fingers, hair and loose clothing away from the wheels.
6. The operating range can be affected by a variety of factors:
 - a) weak transmitter's or vehicle's batteries.
 - b) interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
7. Outdoor usage is recommended in order to get optimal control range.