



English

Eng #81010 / #81008 / #81009

CAUTION - ELECTRIC TOY
NOT RECOMMENDED FOR CHILDREN UNDER 8 YEARS OF AGE. AS WITH ALL ELECTRIC PRODUCTS, PRECAUTIONS SHOULD BE OBSERVED DURING HANDLING AND USE TO PREVENT ELECTRIC SHOCK.
INPUT : 120V AC 60Hz ONLY.
OUTPUT : 7V DC 150 mA.

**WARNING:**

CHOKING HAZARD - Small parts.
Not for children under 3 years.

Maisto - Radio Control Vehicles

The packaging has to be kept since it contains important information.
Class 1 LED Product

Contents:

- RC Vehicle x 1
- Transmitter x 1
- Antenna Tube x 1
- 4-Hour Battery Charger x 1
- 9V (6F 22) Non-Rechargeable Battery (For Transmitter Use) x 1
- 6V Rechargeable Battery Pack (For Vehicle Use) x 1
- Instruction Manual x 1

**Radio Control Vehicles**

English

Performance Tips:

1. Do not drive on grass, sand, carpet or go through water.
2. Do not drive in windy or rainy weather.
3. Avoid colliding with hard surfaces.
4. Switch OFF the Vehicle and Transmitter when not in use.
5. Remove all Batteries from the Vehicle and Transmitter when not in use.
6. Keep fingers, hair and loose clothing away from the wheels.
7. The operating range can be affected by a variety of factors:
 - a) Weak Transmitter Battery, or under-charged Battery Pack.
 - b) Interference from other items that emit radio frequency signals such as another R/C item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
8. Outdoor usage is recommended in order to get optimal control range (49 feet or 15 meters).

Cautions:

1. The 6V Battery Pack must be charged before use by utilizing the 4-Hour Battery Pack Charger which is included.
2. Do not overcharge the Battery Pack. Do not charge for more than 6 hours.
3. Do not charge the Battery Pack if it shows leakage, corrosion, or has loose or exposed wires or other damage.
4. Do not cover the Battery Pack with any sort of material while charging.
5. Do not touch the Battery Pack when it is hot. Wait until the Battery Pack cools before installing it in the Vehicle and before recharging.
6. Do not dispose of the Battery in fire.
7. Do not dismantle the Battery or Charger, and do not cut the Battery or Charger cables.
8. The Battery Pack will be warm after charging, and hot after use in a Vehicle.
9. The supply terminals are not to be short-circuited.
10. Rechargeable Batteries are to be removed from the toy before being charged.
11. Rechargeable Batteries are only to be charged under adult supervision.
12. Battery charge must be only made by adults!
13. Charge Only Type (700mAh Max.) rechargeable Battery Packs. Other types of Batteries may burst causing injury to persons and damage. This power unit is intended to be correctly orientated in a vertical or floor mount position. This Quick Charger is intended to be used for charging 6V Rechargeable Battery Pack with capacity 700mAh Max. It cannot be used for charging non-rechargeable Batteries.
Regular examination of Battery Charger for any damage to their cord, plug, enclosure and other parts, and that, in the event of such damage, it must not be used with the Charger or Battery Pack charge until such damage has been repaired.
Note that the 9V Battery is non-rechargeable and is not to be recharged. Only Batteries of the same or equivalent type as recommended are to be used. It will need replacement when transmission is poor. Exhausted Batteries are to be removed from the Transmitter.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries.
You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:


Pb = Battery contains lead
Cd = Battery contains cadmium
Hg = Battery contains mercury

**Radio Control Vehicles**


English

Battery Charging:


1. Connect the 6V Battery Pack and the Charger connectors.
2. Plug the Charger into a standard electrical outlet.
3. Charging time is around 4 hours.
4. When charging is complete, detach the connectors and remove the Charger from the electrical outlet.

**Transmitter: Battery Installation**


1. Switch the power OFF.
2. Open the Battery Cover.
3. Install a 9V Battery with correct polarity (+/-) as shown inside the Battery compartment.
4. Close the Battery Cover.

**Vehicle: Battery Pack and Antenna tube installation**

1. Switch the power to the OFF position.
2. Open the battery cover using a screwdriver(not included)
3. Install the Battery Pack into the battery compartment and plug it into the connector correctly.
4. Fasten the Battery cover.
5. Insert the antenna wire into the antenna tube, then tie a knot.

**How to play:**

1. Match the Transmitter with the Vehicle Channel (Channel A or B or C).



2. Switch ON the Transmitter, the red LED will light up.
3. Switch ON the Vehicle.
4. Pull the trigger to go forward, push it to go backward and release it to stop.
5. Turn the Transmitter steering wheel to move the Vehicle left or right.
6. If the Vehicle does not run in a straight line, adjust the wheel alignment arm on the Vehicle chassis.
7. Switch OFF the Transmitter and Vehicle power after playing.

**Radio Control Vehicles**

English

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions :

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.
Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
 - Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
 - Consult the dealer or an experienced radio/TV technician for help.

The Manufacturer is not responsible for any Radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the User's Authority to operate the equipment.

FAQ (Frequently Asked Questions)**1) Why does my R/C Vehicle not start?**

- Make sure the Transmitter and the Vehicle are turned on.
- Make sure the Battery Pack is fully charged and the battery is full.
- Make sure the Batteries are installed per polarity indicators.
- Make sure all 4 wheels are not obstructed by any foreign objects.
- Make sure the Transmitter and the Vehicle are set at the same channel.

2) Why does my R/C Vehicle make unusual noises?

- Check to make sure the Battery Pack is fully charged and the Battery is full.
- Check to make sure all 4 wheels are not obstructed by any foreign objects.

MADE IN CHINA

| MAY CHEONG TOY PRODUCTS FTY. LTD. | | | | DIECUT | |
|---|-----------------|------------------|------------|--------|--|
| Job Item: Art004/09 Illustration | Printed by: JUN | Date: 26-02-2009 | Test No: | | |
| Item No: 81010 1-14_MaistoTech Off-Road | Check by: | Date: | File Name: | | |

Size: A3_297mm(W) x 420mm(H)
Color: 1C (Black)
Paper: 128gsm 雙粉紙