

Age 8+

Maisio Radio Control Vehicles

Please keep this owner's instruction manual for future reference. It contains important information. We reserve the right to improve/revise the product specifications without notice. **Warning!** The Antenna of Transmitter is not to be inserted into socket outlets.

Contents:

- 1. RC Vehicle x 1
- 2. Antenna Tube x 1
- 3. Owner's Instruction Manual x 1

Battery Requirement:

Vehicle: 2 x 1.5V AA, LR6/R6 batteries;
Transmitter: 2 x 1.5V AA, LR6/R6 batteries.

Battery Installation for the Transmitter and Antenna Installation: (Refer to Diagram 1 & 2)

1. Insert the batteries with correct polarity (+/-) as shown inside the battery compartment.
2. Install 2 new 1.5V AA, LR6/R6 batteries with correct polarity.
3. Insert antenna wire into the antenna tube.
4. Tie a knot at the top end of the wire.

Battery Installation for the Vehicle: (Refer to Diagram 3 & 4)

1. Switch the power OFF.
2. Push the battery cover on the vehicle.
3. Install 2 new 1.5V AA, LR6/R6 batteries with correct polarity (+/-) as shown inside the battery compartment.
4. Install the battery cover.

How to Play: (Refer to Diagram 5 & 6)

1. Switch ON the vehicle.
2. Push forward the lever on the left side of the transmitter to drive the vehicle forward.
3. Pull back the lever on the left side of the transmitter to drive the vehicle backward.
4. Push the lever on the right side of the transmitter to the left to turn left.
5. Push the lever on the right side of the transmitter to the right to turn right.
6. If the vehicle does not run in a straight line, adjust the wheel alignment under the chassis.
7. Remember to switch OFF the vehicle power after playing.

Performance Tips:

1. Do not drive the vehicle on grass, sand or go through water.
2. Do not drive the vehicle in windy or rainy weather.
3. Do not drive the vehicle into any hard object.
4. Always switch the power to OFF on the vehicle when you are done playing.
5. Keep fingers, hair and loose clothing away from the vehicle.
6. Keep the vehicle away from a variety of factors:
 - a) Weak transmitter or vehicle batteries.
 - b) Interference from other items that emit radio frequency signals such as another RC item on the same frequency, CB radios, cordless phones, high voltage transformers, etc.
7. Outdoor usage is recommended in order to get optimal control range (32 feet or 10 meters).

Battery use:







1. Alkaline batteries are recommended.
2. Only batteries of the same or equivalent type as recommended are to be used.
3. Do not mix old and new batteries.
4. Do not mix old and new batteries of different types of batteries.
5. Non-rechargeable batteries are not to be used, they are only to be changed by adult.
6. If rechargeable batteries are to be used, they are only to be charged by adult.
7. Rechargeable batteries are to be removed from the product before they are charged.
8. Be sure to insert batteries with correct polarities and always follow the battery manufacturer's instructions.
9. Remove all batteries from the product when not in use for long periods of time.
10. Exhausted batteries are to be removed from the product.
11. The supply terminals are not to be short-circuited.
12. Dispose of batteries properly. Do not dispose of batteries in fire – It may cause explosion and/or fire damage.
13. Battery change must only be made by adult.

Disposal of batteries

Batteries should not be disposed of in the household waste. As the consumer, you are responsible for the safe disposal of harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold.



You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:
Pb = Battery contains lead
Cd = Battery contains cadmium
Hg = Battery contains mercury



WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

#81016

Cautions:

1. Do not attempt to disassemble the products.
2. Do not operate the vehicle with same frequency with other players in same location. This will interfere and cause the vehicle to lose control.
3. Make sure the batteries are installed with correct polarity (+/-) as shown inside the battery compartment.
4. Remove the package, take out all accessories and assemble the product before giving it to children to play.

FCC Label Compliance Statement:

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
 2. This device must accept any interference received, including interference that may cause undesired operation.
- Note - This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
 - Increase the separation between the equipment and receiver.
 - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
 - Consult the dealer or an experienced radio/TV technician for help.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RSS-310 Compliance Statement:

This radiocommunication device complies with all the requirements of Industry Canada Standard RSS-310. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Carrier Frequency: 49.860MHz
Field strength and measurement distance: 72.2 dBuV/m at 3 meter
Carrier Frequency: 27.145MHz
Field strength and measurement distance: 74 dBuV/m at 3 meter

Troubleshooting:

Problem	Cause	Correction
No Function	Low battery level Battery polarities are reversed	Replace with new batteries Insert the batteries with correct polarities as shown on the battery compartment
Drive Slow / Poor Turning Signal	The wheels are obstructed by foreign objects The wheels are obstructed by foreign objects	Remove foreign objects on the vehicle / wheels Remove foreign objects on the vehicle / wheels
Poor distance control	Low battery level Strong interference of surroundings	Replace with new batteries Move to a better location for playing

Maisio International, Inc.
Fontana, CA 92336, U.S.A.



MAY CHEONG TOY PRODUCTS FTY. LTD.				DIECUT	
Job Item:	(B1)	Finished by:		Test No.:	
Item No.:	#81016 - 1:24 RC with stick controller	Check by:		Material:	
Item No.:	#81016 - 1:24 RC with stick controller	Check by:		Material:	