


# Meet your BPC100.

## inseeGo


### About your BPC100

#### Rear View



No.	Item	No.	Item
1	External Antenna Connector 1	4	Alarm Port
2	Power Connector Port	5	Phone/Fax Port
3	Ethernet Port	6	External Antenna Connector 2

#### Top View



No.	Item
1	BPC Battery Cover
2	3 AA Backup Batteries
3	Reset button

Note: Never place a USB-based device into the power connector port of the BPC100. Doing so may damage the device and negate its warranty.

## Setting up your BPC100


Your BPC100 comes with the SIM card installed.

### Step 1: Transfer your phone number

Please read the following if you are transferring your phone number from a different provider.

**Note:** Customers transferring in their business number will not be able to make or receive calls on the BPC100 until the transfer process is completed. The transfer process can take 2 - 10 business days. Check the status of your transfer by visiting [verizonwireless.com/LNP](http://verizonwireless.com/LNP) or by calling (888)-844-7095.

### Step 2: Install backup batteries for use during power outage



1. Open the battery cover.
2. Insert three (3) AA batteries.
3. Close the battery cover.

### Step 3: Install the power adapter

1. Insert the power adapter into the power connector port.
2. Plug the power adapter into a wall outlet.



### Step 4: Connect your telephone to the BPC100

The BPC100 provides one port for either a telephone or fax machine.

1. Unplug telephone that you want to use with the BPC100 from the wall telephone jack.

**Warning:**

If your existing phone has rotary or pulse dialing, it will not work with this product.

2. Plug the end of your telephone cord into the telephone port on the back of your BPC100 (the other end of the cord must remain plugged into the back of your telephone base unit).
3. For best results, place on a firm, flat surface. If BPC100 needs to be mounted on a wall, please use double-sided mounting tape.

**Note:** The telephone and telephone cord are not included.

### Step 5: Turn on your BPC100

Press the Power button on the front of the device to turn on the BPC100. The power indicator will be blue when device is turned on.

**Important**

Please make sure your BPC100 is located in an area of your business that receives a strong wireless signal.

**Optional:** Install the antenna

To increase signal strength, you can install the two (2) antennas included.

1. Align antennas with the antenna ports and screw securely into place.
2. Restart the BPC100 after the antennas are inserted or removed.

### Step 6: Make calls

1. Before making a call, make sure the indicator light is solid blue. If the indicator light is blinking red, move the BPC100 to a location that receives a signal or try installing the optional antenna for greater signal strength.
2. Place a call to start using the service.

**Important**

Customers may need to use the three-digit area code when dialing local and long distance numbers.

### Find more information

- For additional information on BPC100 settings and software updates, please go to: <http://my.bpc100> (default password = admin)
- Please refer to the User Guide at [verizonwireless.com/support](http://verizonwireless.com/support) for more details.
- Customer Service is available at any Verizon Wireless store or by calling 800.922.0204.

## Warning

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Cet appareil est conforme aux CNR exempts de licence d'Industrie Canada. Son fonctionnement est soumis aux deux conditions suivantes : ( 1 ) Ce dispositif ne peut causer des interférences ; et ( 2 ) Ce dispositif doit accepter toute interférence , y compris les interférences qui peuvent causer un mauvais fonctionnement de l'appareil.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The antenna(s) used for this transmitter must be installed to provide a separation distance of at least 30 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.