

ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

Programming Instructions:

- 1) Turn the ignition switch to ON
- 2) Press the LOCK or UNLOCK button on one of the remotes. (A programmed remote can be used for this step.)
- 3) Turn the ignition switch to Lock (0)
- 4) Repeat steps 1,2 and 3 two or more times using the same keyless remote used in step 2.
- 5) Turn the ignition switch to ON.
- 6) Press the LOCK or UNLOCK button the same remote. Make sure the power door locks to confirm you are in the programming mode.
- 7) Press the LOCK and UNLOCK button on each remote you want to program. Make sure door locks cycle after you push each remote button to confirm that the system has accepted the remote.
- 8) Turn the ignition switch to LOCK to exit programming mode.
- 9) Test all remotes to ensure they work.

FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

IC WARNING

63999359IC

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met.

This device complies with Industry Canada's license-exempt RSSs.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

Cet appareil est conforme aux RSSs exempts de licence d'Industrie Canada.

Le fonctionnement est Suivant deux conditions:

- 1) Cet appareil ne doit pas causer d'interférences; Et
- (2) Cet appareil doit accepter toute interférence, y compris les interférences qui peuvent Fonctionnement du dispositif