

ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

Programming Instructions:

Be sure to have all currently programmed remotes available for this process. Any remotes not present will be erased.

Turn the ignition off

Plug the programming dongle into the OBD-2 port.

Using a valid remote, press lock and then unlock.

Wait 5 seconds. The programmer will beep a short beep and the green LED will blink.

Wait 20 seconds. The programmer will begin to flash the red LED every second to indicate security access is in progress.

After 10 minutes the programmer will beep and flash the green light to indicate security access has been gained.

Press the button to erase all stored key data. This will erase all currently programmed keys to the vehicle. All previously programmed keys must be relearned during this process.

The programmer will beep a long beep and flash the green LED to indicate that all keys have been erased.

Place a remote into the programming socket, then press the button on the programming dongle.

The programmer will beep a short beep and the LED will remain off to indicate that the remote has been detected in the socket.

The red LED will blink until the remote is programmed.

The programmer will beep a long beep and the green LED will turn on to indicate that the key has been successfully programmed.

Remove the programmed remote from the socket. Test the remote by pressing lock/unlock.

Place the next remote into the programming socket, then press the button on the programming dongle.

The programmer will beep a short beep and the LED will remain off to indicate that the remote has been detected in the socket.

The red LED will blink until the remote is programmed.

The programmer will beep a long beep and the green LED will turn on to indicate that the key has been successfully programmed.

Remove the programmed remote from the socket. Test the remote by pressing lock/unlock.

Repeat steps 15 through 19 for any additional remotes. A maximum of 4 remotes may be learned to the vehicle.

When all remotes have been programmed, unplug the programmer from the OBD-2 port.

ALL KEY FOBS MUST BE PRESENT AND REPROGRAMMED WHEN PROGRAMMING NEW FOBS

FCC WARNING

Statement 15.19(a)(3): This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by Dorman Products Inc. could void the user's authority to operate the equipment.

FCC Part 15.21: THE GRANTEE IS NOT RESPONSIBLE FOR ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

IC WARNING

FVIN 6399377IC FVIN 6399378IC

The term IC before the Certification/Registration number only signifies that the Industry Canada technical specifications were met. This device complies with Industry Canada's license-exempt RSSs. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.