


K2P 2.4G无线触控键盘 用户手册

注意：正确操作本产品，请仔细阅读用户手册。



注意：请按正负极正确安装电池，请勿将电池充电，弃于火中，或将不同型号或新旧电池混用，以免电池漏液或爆炸。请将电池存放在阴凉干燥处并远离儿童，电量长时间不用时，请将电池取出。

● 连接使用说明：

1. 请打开键盘底部的电池盖，取出接收器。
2. 如图所示，装入2节7号电池，再装上电池盖。
3. 将接收器插入有USB口的设备上。（请确保您的电脑设备USB接口可用）
4. 打开键盘底部的电源开关，即可使用您的键盘。

组合键功能说明(Fn+)

F1	静音	F2	音量减小	F3	音量增大
F4	播放/暂停	F5	搜索	F6	共享
F7	设备	F8	设置	F9	原位键
F10	结尾键	F11	向上翻页键	F12	向下翻页键
PrtScr Pause	中止	Ins NumLk	NumLock NumLock	Del ScrLk	NumLock NumLock

灯标指示

I	数字键	A	大写锁定	C	低电压指示灯
---	-----	---	------	---	--------

触控板功能说明



技术规格

- 键盘尺寸：329.6X110.0X17.8mm
- 触控板尺寸：80.4X93.3mm
- 工作距离：8M
- 键盘重量：270g
- 键盘布局：80键
- 休眠时间：6分钟
- 唤醒方式：任意键唤醒
- 工作电压：3.0V
- 低电压报警：<2.2V
- 休眠电流：0.03mA
- 使用触控板工作电流：<29mA
- 使用按键工作电流：<11mA
- 供电方式：7号AAA干电池X2

状态显示LED

- 开启电源：蓝灯亮起
- 对码成功：蓝色对码灯熄灭；
- 低电压指示：当低电压低于2.2V工作电压时，低电压指示灯红灯闪烁；
- NumLock/CapsLock：打开亮起，关闭熄灭。

系统要求

针对Windows 10系统。兼容Android 4.0系统。

故障分析

请与售后服务人员联系。

知识产权信息

未经卖方的许可，禁止复制本用户手册的内容。

安全提醒

请不要打开或修理该设备，请不要在潮湿的环境使用该设备。请用干布擦拭该设备。

质保条款
本设备提供自购买之日起1年的有限产品硬件保修服务。

键盘保养

1. 请勿将设备暴露于液体和潮湿的环境中或使其淋雨，请勿在浴缸、水槽、桑拿房、游泳池或蒸汽房附近使用。
2. 请勿将设备暴露于过高或过低的温度条件下。
3. 请勿长时间放置在阳光直射的地方。
4. 请勿靠近明火，如烹饪用炉、蜡烛或者壁炉。
5. 避免使用锋利器物刮擦产品，及时给产品进行充电或更换干电池以保证正常使用。

常见问题解答

1. 接收器无法识别？
接收器插入电脑未识别，请检查USB接口是否接触良好。
2. 键盘指示灯在使用途中红灯闪烁？
键盘指示灯在使用途中红灯闪烁，表示电池即将没电，请尽快更换电池。
3. 设备显示无线键盘断开连接？
无线键盘在一段时间内不使用，设备为了省电将自动进入休眠，按任意键唤醒，无线连接将自动恢复。
4. 掉码？
请重新插拔接收器，电脑识别后，打开电源，按住Fn+Backspace，即可快速对码。

保修卡

用户填写资料

公司或个人全称 _____

通讯地址 _____

电话 _____ 邮编 _____

所购产品名称及型号 _____

购买日期 _____

本有限质保不涵盖由于以下原因导致的问题或损坏：
(1) 意外事件、误用、操作不当或任何未经授权的维修、改装或者拆卸；
(2) 操作或维护不当，使用过程中违反产品说明或连接不适当的电源；
(3) 或者使用并非本公司提供的消耗品（如备用电池），但适用法律禁止此类限制的情况除外。



● Operating System Instructions :

1. Turn the keyboard upside down, open the lid and remove the 2.4G Nano receiver.
2. Insert two AAA batteries as shown picture on the left. Close the batteries cover.
3. Place 2.4G Nano receiver into USB port of your computer.
4. Turn the keyboard upside down, open the power switch, the keyboard is ready for use.

Warranty Card

User information

Company or personage full name _____

Contact address _____

TEL _____ Zip _____

The purchased product name and model NO. _____

Purchased date _____

This reason due to the product broken and damage is not include on the warranty:
(1) Accident, misuse, improper operation, or any unauthorized repair, modified or removed
(2) Improper operation or maintenance, when operation violation of the instructions or connection unsuitable power supply.



Status Display LED

- Open the power switch: blue lights up.
- After connect successfully the blue light crush out.
- Low voltage indication: when the voltage below 2.2V working voltage, the red light twinkles.
- Numlock / Capslock: when open the Numlock / Capslock the lamp will light, when close the lamp will crush out.

Compatible system

For windows10 system, compatible with Android 4.0 system

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this quick start guide without the permission of seller.

Safety instructions

Do not open or repair this device. Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

1. Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
2. Please don't expose the keyboard at too high or too low temperature condition.
3. Please don't put keyboard under sun for a long time.
4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fire place.
5. Avoid sharp objects scratching products, timely to recharge or replace the dry cell products to ensure the normal use.

FAQ

1. The 2.4G Nano receiver unrecognized?
If the 2.4G Nano receiver unrecognized, please check the USB interface is functioning.
2. Why the red light always twinkle when in use?
The keyboard red light always twinkle when in use, indicates low power of battery, please change new battery quickly.
3. The device display the 2.4G Keyboard is disconnecting?
The 2.4G wireless keyboard after some time later not used, the tablet PC will go into dormant mode to save battery power. Press any key to awake the device.
4. Code missing
Please plug the 2.4 G Nano receiver again, after the computer has been recognized, press the Fn+Backspace key and open the keyboard of power switch, the keyboard will be connected successfully.

2.4GHz Wireless Keyboard With Multi-touchpad & USB Receiver User's Manual

Note: Please read the user manual carefully before you start using this product.

Status Display LED

- Open the power switch: blue lights up.
- After connect successfully the blue light crush out.
- Low voltage indication: when the voltage below 2.2V working voltage, the red light twinkles.
- Numlock / Capslock: when open the Numlock / Capslock the lamp will light, when close the lamp will crush out.

Compatible system

For windows10 system, compatible with Android 4.0 system

Troubleshooting

Please contact the after-sales service.

Copyright

It is forbidden to reproduce any part of this quick start guide without the permission of seller.

Safety instructions

Do not open or repair this device. Do not use the device in a damp environment. Clean the device with a dry cloth.

Warranty

The device is provided with one-year limited hardware warranty from the purchase day.

Keyboard Maintenance

1. Please keep the keyboard away from liquid or humid environment, saunas, swimming pool, steam room and don't let the keyboard get wet in the rain.
2. Please don't expose the keyboard at too high or too low temperature condition.
3. Please don't put keyboard under sun for a long time.
4. Please don't put keyboard close to the flame, such as cooking stoves, candles or fire place.
5. Avoid sharp objects scratching products, timely to recharge or replace the dry cell products to ensure the normal use.

FAQ

1. The 2.4G Nano receiver unrecognized?
If the 2.4G Nano receiver unrecognized, please check the USB interface is functioning.
2. Why the red light always twinkle when in use?
The keyboard red light always twinkle when in use, indicates low power of battery, please change new battery quickly.
3. The device display the 2.4G Keyboard is disconnecting?
The 2.4G wireless keyboard after some time later not used, the tablet PC will go into dormant mode to save battery power. Press any key to awake the device.
4. Code missing
Please plug the 2.4 G Nano receiver again, after the computer has been recognized, press the Fn+Backspace key and open the keyboard of power switch, the keyboard will be connected successfully.


Function Key Combinations(Fn+)

F1	Mute	F2	Volume-	F3	Volume+
F4	Play/Pause	F5	Search	F6	Share
F7	Device	F8	Set up	F9	Home
F10	End	F11	Page up	F12	Page Down
PrntScr Pause	Stop	Ins NumLk	Key lock	Del ScrLk	Scroll lock

Touchpad Functions

I	Number keys	A	Caps Lock	C	Power Light
---	-------------	---	-----------	---	-------------

Touchpad Functions



Technical Specifications

- Keyboard size : 329.6X110.0X17.8mm
- Touchpad size : 80.4X93.3mm
- Working distance : 8M
- Weight : 270g
- Keyboard layout : 80Keys
- Sleep time : Six minutes
- Awaken way : Arbitrarily key to awaken
- Working voltage : 3.0V
- Low voltage alarm : <2.2V
- Sleep current : 0.03mA
- Touchpad working current : <29mA
- Working current : <11mA
- Power supply mode : AAA X2 dry battery

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC WARNING

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.