2. Photograph for the worst case configuration



3. Sample Calculation

The emission level measured in decibels above one microvolt (dB $\,$) was converted into microvolt per meter ($\,$ /m) as shown in following sample calculation.

For example:

	Measured Value at	58.94 M Hz	< 2.0 dB / m
+	Antenna Factor		8.7 dB
+	Cable Loss		1.3 dB
	Preamplifier		0.0 dB
	Distance Correction Factor *		0.0 dB
=	Radiated Emission		< 12.0 dB /m
			(=<4.0 /m)

^{*} Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.