
2. Photograph for the worst case configuration



3. Sample Calculation

The emission level measured in decibels above one microvolt (dB $\,$) was converted into microvolt per meter ($\,$ /m) as shown in following sample calculation.

For example:

	Measured Value at	75.62 M Hz	2.3 dB /m
+	Antenna Factor		6.8 dB
+	Cable Loss		1.6 dB
	Preamplifier		0.0 dB
	Distance Correction Factor *		0.0 dB
=	Radiated Emission		10.7 dB /m
			(=3.43 / m)

^{*} Extrapolated from the measured distance to the specified distance by an inverse linear distance extrapolation.