

9F-3, No. 16, Jain Ba Rd., Chung Ho City, Taipei Hsien, Taiwan 235, R.O.C.

TEL: +886-2-8226-3811 FAX: +886-2-8226-3822

APPROVAL SHFFT

SH	HEET		No: _ Date: _	2002/11	/27	
Customer:						
Customer Part No:						
Parts Name:	AQ Type Rem	ote p	ointer-	(912M	HZ)	
Customer Model No	.:					
Part No.:	RCAQ0001-901					
Model No.:	TSAQ-901					
Note:						
Signatur	e For Return		APP' D	CHK' D	DSG' D	

TopSe	eed Te	echno	ology	Corp.									
					SPI	ECIFIC	CATIC	N FO	R	PAGE: 2/14			
				RF	Flex	Point	er-FS	K (912	2MHz) D	ATE: 2002/11/27			
						COI	NTEN	TS					
	1. Table of date revision 2. Description 3. Physical Description and Specification 4.RF Flex Pointer Specification 5.Electronical Block Diagram FSK (912MHz) Transmitter FSK (912MHz) Receiver 6. Electrical Characteristics 7.Mechanical Specification 8.Endurance 9. Environmental Tests 10. Assembly Drawing 11. Packing Drawing												
				1. Ta	able of	f date-	revisio	n					
				-						-			
						APPD.	CHKD.	DSGD.	PART NO.	DE Elem Delate			
						1			RCAQ0001-90	RF Flex Pointer			
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)			

SPECIFICATION FOR RF Flex Pointer-FSK (912MHZ)

PAGE: **3/14** DATE: 2002/01/22

FCC GUIDELINES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna

Increase the separation between the equipment and receiver

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

						APPD.	CHKD.	DSGD.	SPEC. NO.	
									RCAQ0001-901	
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHZ)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 4/14

DATE: 2002/11/27

2. Description:

The RF Flex Pointer is a FSK (Frequency Shift Key) Transmitter for the frequency band 902-928 MHz. The Flex Pointer offers a full-integrated PLL synthesizer and a high efficiency power amplifier to drive a loop antenna, A special circuit design and an unique power amplifier design are used to save current consumption and to save battery life.

This RF Flex Pointer is a best companion of Microsoft Power Point designed, lets you Slide Forward, Slide Back, Blank functions, F5 and Esc as desired, when browsing the Internet or scrolling through any Windows documents gives reliable control and accuracy. Flex Pointer RF's radio frequency wireless technology solves all of your presentation input needs.

For the RF Receiver use with USB 1.1 compliant can be easily actuated without affecting the position of the Flex Pointer.



The Radio Frequency designed in this Version of RF Flex Pointer is FSK 912MHz and can be use in a range of up to 10 Meter from the Receiver at any directions. The Flex Pointer can operate for 6 months with CR2032 DC 3V Lithium batteries.


						APPD.	CHKD.	DSGD.	PART NO.	
									RCAQ0001-901	RF Flex Pointer
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.				11CAQ0001-301	FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 5/14

DATE: 2002/11/27

3. Physical Description and Specification:



3.1 Dimensions

The approximate dimensions of the remote's transmitter is as follows:

Length 90mm
Width 40mm
Height 22mm

3.2 Weight

The approximate weight of the remote's transmitter is as follows: Weight of the RF Flex Pointer not to exceed 40 grams (with batteries).

						APPD.	CHKD.	DSGD.	PART NO.	
									DCA 00004 004	RF Flex Pointer
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.				RCAQ0001-901	FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 6/14

DATE: 2002/11/27

4.RF Flex Pointer Specification

The RF Flex Pointer consists of three major parts; a baseband controller, a radio that suitable for America available 902–928 MHz frees ISM band applications, and a low power uC-controlled, includes RF antenna supporting circuitry, together with basic RF software level.

- 4-1 Range in meters: 10 Meter from the Receiver
- 4- 2 Frequency Range: 912MHz+/-100KHz (64 channels ID for Flex-Pointer)
- 4-3 Data transmitting by transistor module
- 4-4 Operational voltage: 2.4~3.3 V
- 4-5 Low power consumption: On normal operation less than 8 mA

On sleep mode. Less than 10 uA.

- 4-6 Support Power down Mode and high efficiency power amplifier.
- 4-7 Receiver Fully Compliant Low Speed (1.5Mbps) USB 1.1 Interface
- 4-8 Suspend/resume operation and device remote wakeup

APPD. CHKD. DSGD. PART NO.

RF Flex Pointer
RCAQ0001-901
FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 7/14

DATE: 2002/11/27

4.RF Flex Pointer Specification

4-9 Application



Symbo		Key definition
В	Black	Display a black screen or return to the slide show from a black screen
	Slide Forward	Perform the next animation or advance to the next slide
Р	Slide Back	Perform the previous animation or return to the previous
F5	F5/ESC	F5: Running your slide show in full screen mode ESC:End a Slide show
М		Mode Key

Notice:

- 1.ID Change: Press Both " M " and " B " buttons simultaneously more than 3 seconds will change the currend ID. (Green LED flashed)
- 2. Remote Power On/Off: In the remote ON mode, press and hold the "M" key and press "F5" buttons more than 3 seconds the remote will be Power Off. Green LED from on to off.

 In the remote Off mode, press and hold the "M" key and press "F5" buttons more than 3 seconds the remote will be Power On. Green LED from off to on.

						APPD.	CHKD.	DSGD.	PART NO.	
										RF Flex Pointer
									RCAQ0001-901	
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 8/14

DATE: 2002/11/27

4.RF Flex Pointer Specification

4-10

Frequency Range	912 MHz
Modulation	FSK
Channel No.	1
Channel I.D	6 bits 64
Operation Voltage	3V
Potton/	CR2032 DC 3V Lithium
Battery	batteries.
Batter Life	6 months
TX Power	< 0dBm (1mW)
Transmission rate	6 K bps
TX FM frequency deviation	60 KHz- 160 KHz
Frequency tolerance	+/- 20ppm
Button	5
Transmission Distance	10 Meter

L											
							APPD.	CHKD.	DSGD.	PART NO.	
ļ											RF Flex Pointer
										RCAQ0001-901	
	SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)


SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE:9/14

DATE: 2002/11/27

5. Electrical Block Diagram

FSK (912MHz) Transmitter



						APPD.	CHKD.	DSGD.	PART NO.	
										RF Flex Pointer
									RCAQ0001-9011	
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)


SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 10/14

DATE: 2002/11/27

5. Electrical Block Diagram

FSK (912MHz) Receiver



USB 1.1 compliant The module is a USB high-speed class device (12 Mbps) and has the full functionality of a USB slave

						APPD.	CHKD.	DSGD.	PART NO.	
										RF Flex Pointer
									RCAQ0001-901	
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

DATE: 2002/11/27

PAGE: 11/14

6. Electrical Characteristics:

6.1 GENERAL SPECIFICATION

6.1.1 Operation temperature range: -10 ~ + 55

6.1.2 Storage temperature range : - 25 ~ + 65

6.1.3 Operation Relative humidity range: 10 %~ 85 % RH

6.1.4 Storage humidity range: 10 %~ 95 % RH

6.2 Operational Range

Parameter	Min	Max	Unit
Supply Voltage	2.4	3.3	V
Frequency	912MHz -	+/- 100KHz	MHZ

6.3 Electrostatic Discharge (ESD) Sensitivity

Direct discharge:

Test Voltage: Not less than 8 KV for Air discharge

Not less than 4 KV for Contact discharge

Indirect discharge:

Test Voltage: Not less than 4 KV for HCP

Not less than 4 KV for VCP

						APPD.	CHKD.	DSGD.	PART NO.	
									RCAQ0001-901	RF Flex Pointer
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 12/14

DATE: 2002/11/27

6.4 AC/DC Characteristics

Supply Voltage: VS= 3.0 V

Р	arameter	Min	Тур	Max	Unit
Current	Sleep mode		5	10	uA
Consumption	Transmit Mode		5	8	mA
Data rate			6K		bps
Sensitivity		-100	-95	-90	dbm
Transmitter sett	tling time		2.2		ms
Output power (7	Transmit mode)	-10		0	dbm

7. Mechanical Specification

ITEM	SPECIFICATION
7.1 Push Button Operating force	Max. 150gf in any direction.
7.2 Push Button Action distance	(1) Apply vertical to the center of the push button pin Dia 4mm
	A static Force of 3 Kg being applied vertically to the center of the push button for 1 minute.
7.4 Scrolling operation force	Max. 50gf in tangent direction.

						APPD.	CHKD.	DSGD.	PART NO.	
									RCAQ0001-901	RF Flex Pointer
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.				10,10001 301	FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHz)

PAGE: 13/14

DATE: 2002/11/27

8.Endurance

ITEM	SPECIFICATION						
8.1	(1) Switching frequency 1~2cycles/sec						
button life test (2) Switch Actuation force: 50-100 gram force							
	(3) Minimum Actuation per Switch 500,000 actuation						
8.3	(1)Height 700 ±20mm						
Drop test	(2) Test surface concrete						
	(3) Direction free						
	(4) Test times 3 times						
8.4	(1) Air Discharge: over 8KV						
ESD test	(2) Contact Discharge: over 4KV						

						APPD.	CHKD.	DSGD.	PART NO.	
									RCAQ0001-901	RF Flex Pointer
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.				110AQ0001-301	FSK (912MHz)

SPECIFICATION FOR RF Flex Pointer-FSK (912MHZ)

PAGE: 14/14

DATE: 2002/08/01

9. Environmental Tests

ITEM	SPECIFICATION								
9.1 Heat load test	Measure initial value at standard testing conditions. Leave samples in 65 全。C for 72 hours, and in standard testing conditions for 2 hours, then take measurements within 1 hour.								
9.2	Leave samples in 50 ±5。C for 24 ±2 hours, and in standard								
Humidity load test	testing conditions for 2 hours, then take measurements. Leave samples in 50 ±5°, C, 90~95%RH, for 72 hours, and in standard testing conditions for 2 hours, then take measurements within 1 hour.								
9.3	Measure initial value at standard testing conditions.								
Cold test	Leave samples in -25 ₺。 C for 72 hours, and in Standard								
	testing conditions for 2 hours, then take Measurements within								
	1 hour.								
9.4	Vibration test fixture is used to vibrate the tuner with a total								
Vibration test	amplitude 1mm and frequency ranging from 10 to 55Hz, once								
	per minute onsecutively, for 40 minutes in each of three directions. X. Y and Z								
9.5	Measure initial value at standard testing conditions.								
HEAT CYCLE	1. Conditions								
TEST	25°C 10 10 (WIN)								

NOTE: When using RF products, keep away from hi-frog electric products.

						APPD.	CHKD.	DSGD.	PART NO.	
										RF Flex Pointer
									RCAQ0001-901	
SYMB.	PAGE	DATE	APPD.	SHKD.	OSGD.					FSK (912MHz)