

Nighthawk® 5G Mobile Hotspot



Let's Get Started

AT&T Eco Rating 2.0 only applies to the NETGEAR Nighthawk 5G Mobile Hotspot, model MR5000. For limited factors evaluated visit [att.com/EcoSpace](http://att.com/EcoSpace). Wireless Emergency Alerts is a registered Trademark and Service Mark of CTIA.

NETGEAR and Nighthawk are trademarks of NETGEAR, Inc. 5G is a trademark of 3GPP. 5G not available everywhere. Contains Lithium ion battery - recycle or dispose of properly.

© 2018 AT&T Intellectual Property. All rights reserved. AT&T, the AT&T logo and all other AT&T marks contained herein are trademarks of AT&T Intellectual Property. All other marks are the property of their respective owners.


Printed in USA

201-24964-01

## What's in the Box

- Nighthawk 5G Mobile Hotspot with pre-installed SIM card
- Battery cover
- Battery
- USB Type-C cable
- AC adapter
- Quick start guide
- Warranty card

## Get to Know Your Mobile Hotspot



## Install the Battery

- 1 Insert the battery.



- 2 Install the back cover.

The battery is partially charged. To fully charge it, connect the USB cable to the mobile hotspot and then plug into either:


- A wall socket, using the wall charger (faster charge option)
- The USB port on your laptop

**Note:** The mobile hotspot comes with a preinstalled SIM card. The SIM must be activated to a data plan with AT&T.


## Set Up Your Mobile Hotspot

- 1 Press and hold the **Power** button for 2 seconds.

To better safeguard your network, the first time you turn on your mobile hotspot, you are asked to set up your login credentials.




- 2 Follow the onscreen instructions to customize your mobile hotspot settings.



## Home Screen

The Home screen displays the mobile hotspot's WiFi network name and password. The network indicator lets you know which AT&T wireless network you are connected to.



## Connect to the Internet

**Note:** The mobile hotspot Home screen displays the WiFi network name and password. The screen goes dark to save power. Press and release the **Power** button to wake the screen.

### On your laptop or other WiFi device

- 1 Open your WiFi network connection manager.
- 2 Find your mobile hotspot's WiFi network name (ATT-WIFI-XXXX) and connect.
- 3 Enter your mobile hotspot's WiFi password.
- 4 Launch your Internet browser.


## Change the WiFi band

- 1 On the home screen, tap the **WiFi** icon.
- 2 Tap **Band**.
- 3 Select the 2.4 GHz or 5 GHz WiFi band.

## LCD Settings

### View or change the settings

On the home screen, tap the **Settings** icon.



## For More Information

### Manage your account

On the web: [att.com/myATT](http://att.com/myATT)

Compatible device and online account required. Data and messaging rates may apply for download and app usage.

### Need more help?

On the web: [att.com/DeviceHowTo](http://att.com/DeviceHowTo)

### Give us a call


611 from any AT&T wireless phone, or 800.331.0500. When prompted, enter your device's 10-digit number.

## LCD WiFi Manager


You can manage the WiFi network from the LCD screen.

### Change the WiFi network name and password

- 1 On the home screen, tap the **WiFi** icon.



- 2 Tap **Main WiFi**.



- 3 Enter your changes.


## WiFi Manager

You can use a browser to view and change the mobile hotspot settings.

### Log In

- 1 On your mobile hotspot, go to the LCD Settings screen, tap the **More** icon. Then tap **Device Information** and look for the WiFi Manager URL.
- 2 On the WiFi device that is connected to your mobile hotspot, type the WiFi Manager URL in the browser bar.
- 3 Log in as administrator.

The default login is **attadmin**.



## **Federal Communication Commission Interference Statement**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC Caution:**

- Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.
- This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

**Radiation Exposure Statement:**

This device meets the government's requirements for exposure to radio waves.

This device is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government.

The exposure standard for wireless device employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. \*Tests for SAR are conducted using standard operating positions accepted by the FCC with the device transmitting at its highest certified power level in all tested frequency bands.

For body worn operation, this device has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and be positioned a minimum of 10mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the device at the ear, position the handset a minimum of 10cm from your body when the device is switched on.

Note: The country code selection is for non-US model only and is not available to all US model. Per FCC regulation, all WiFi product marketed in US must fixed to US operation channels only.