




Photograph No.1 Peak output power measurement setup at the OATS




Photograph No.2 Peak output power measurement setup, EUT close view



# Photograph No.3 Peak output power measurement setup


## Photograph No.4 Spurious emissions measurement setup in the anechoic chamber below 30 MHz



Photograph No.5 Spurious emissions measurement setup in the anechoic chamber in 30 -1000 MHz




### Photograph No.6 Spurious emissions measurement setup in the anechoic chamber below 1000 MHz, EUT close view



Photograph No.7 Spurious emissions measurement setup in the anechoic chamber in 1-18 GHz



Photograph No.8 Spurious emissions measurement setup in the anechoic chamber in 18-40 GHz




Page 9 of 14

## Photograph No.9 Spurious emissions measurement setup at the OATS above 40 GHz, 3 m test distance



## Photograph No.10 Spurious emissions measurement setup at the OATS above 40 GHz, 0.05 m test distance



## Photograph No.11 OBW measurement setup





## Photograph No.12 Frequency stability measurement setup



Photograph No.13 Conducted emission measurement setup on AC power lines