


R/C AIR BUGGY

CAUTION - ELECTRICALLY OPERATED PRODUCT - Not recommended for children under 6 years of age.
As with all electrical products, precautions should be observed during handling and use to reduce the risk of electrical shock.



AC-DC ADAPTOR

INPUT: 120VAC 60Hz 2.4W

OUTPUT: 12VDC 200 mA

Class 2 Transformer



FOR AGES 6 & UP

CAUTION - ELECTRICALLY OPERATED PRODUCT -
" CHARGE ONLY NICKEL CADMIUM TYPE RECHARGEABLE BATTERIES. OTHER TYPES OF BATTERIES MAY BURST CAUSING INJURY TO PERSONS AND DAMAGE. "

Batteries and Charger Required

- Condition of battery pack for best results by charging according to these instructions on every charge.
- On the first charge, expect a shorter run time. Run times will increase over the next 6 charges, reaching specified run times.

Battery Heat

- It is normal for the Battery getting hot after use. But be careful. Wait until battery is cool before charging (around 20 minutes or more if required).
- Charging batteries when they are not will severely reduce the number of times they can be recharged.
- After charging. Battery pack will be warm.

Drain Down - Cool Down - Charge Up

- After the first charge, for best performance always run the battery pack all the way down before recharging. Run until vehicle wheels/fans/motors slow to a stop.
- If you are operating a boat, hovercraft or other water vehicle in operate other kinds of vehicles in or near water.)
- Allow charging, battery pack to cool before recharging.

Recharging Instructions

- Connect the battery pack plug to the charger as shown
- Plug wall pack charger into a standard wall outlet
- Red light on charger will light to show charger is operating. Normal charging time is approximately 4 hours. And Unplug charger from wall after 4 hours of charging.
- After changing, battery pack will feel warm.

Rechargeable Battery Tips

- Do not overcharge the battery pack
- NiCd battery packs are not like alkaline batteries. They lose all their power suddenly, not gradually, and vehicle will stop very soon after slowing down becomes noticeable.
- Store your battery pack discharged
- Your battery pack will hold a charge for a shorter time in hot weather. Otherwise, you can charge a battery a day.
- When your battery pack's running time gets shorter and shorter, probably it's getting close to the end of its life and needs to be replaced.

CAUTION :

The transformer be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to persons and that, in an event such conditions, the transformer should not be used until properly repaired.

ATTENTION PARENTS:

IT IS RECOMMENDED THAT THIS TOY AND ALL ACCESSORIES BE PERIODICALLY EXAMINED FOR POTENTIAL HAZARDS AND THAT ANY POTENTIALLY HAZARDOUS PARTS BE REPAIRED OR REPLACED.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is needed.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user authority to operate the equipment.