REMOTE OVERVIEW

Please take a moment to familiarize yourself with your Connected remote's general features.



Technology	FM 2-WAY SST	
Max. Range	5000 feet	
Buttons	5	
Transmit Confirmation (TX)	LED	
Receive Confirmation (RX)	LED + Chime	
Batteries Required	CR2450	
Avg. Battery Life	1 Year	
Warranty	1 year	

REPLACING REMOTE BATTERIES



Follow the steps below to replace the batteries in your Connected remote:

- 1. On the backside of your remote, remove the 2x mini-phillips screws and seperate the front and back part from the transmitter.
- 2. Remove the old battery and replace by a new CR2450 battery.
- 3. Close back the front and back of the transmitter and reinstall the 2x screws.

WHEN SERVICING YOUR VEHICLE

To ensure safety during vehicle servicing, the remote starter must be placed in "Valet Mode". The "Valet Mode" will disable remote start functionality. To activate or deactivate the "Valet Mode" from your Connected remote, follow the instructions belows.

FUNCTION	ACTION	
Valet Mode ON	Turn ignition ON, then press	1
Valet Mode OFF		2

REMOTE START TROUBLESHOOTING

If your Connected remote fails to start the vehicle, the parking lights will flash a number of times according to the possible remote start error. Please consult your specific Remote Starter owners guide for error details. Please consult your retailer for more details.



ONE-YEAR LIMITED WARRANTY

Lightwave Technology Inc. warrants to the original purchaser of the Connected product that the following components product shall be free of defects in material and workmanship under normal use and circumstances for the period of one (1) year from the date of original installation, excluding battery replacement.

In the event of any product malfunction during the Warranty period, the original purchaser must return to the Authorized Dealer where it was originally purchased with the original proof of purchase. If a malfunction is detected, the Authorized Dealer will elect to repair or replace the product at its discretion. Labor costs may be applicable and are at the discretion of the Authorized Dealer.

THE ONE-YEAR LIMITED WARRANTY IS AUTOMATICALLY VOID IF:

An original proof of purchase is not provided when servicing the product during the warranty period;

The Connected product is transferred to another vehicle:

The vehicle in which the product was originally installed is transferred to a new owner.

Lightwave Technology Inc. is not responsible for any elamages whatsoever, including but not limited to any consequential elamages, incidental elamages, elamages for loss of time, loss of earnings, commercial loss, loss of economic opportunity and the like that may or may not have resulted from the installation or operation of a Connected product.

IC STATEMENT

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

CAN ICES-3 (B)/NMB-3(B) C Tested to comply
CAN ICES-3 (B)/NMB-3(B)





www.connectedremotestart.com



FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help.