

6"

8.5"

BELL

3011 BELL SPORTS, INC. / 3011-164-1111
3011 INNOVATION ROAD / ANNANDALE, IL 61818 USA

3011 983281

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MUST NOT INTERFERE WITH OTHER RADIO-FREQUENCY DEVICES. (2) THIS DEVICE MUST ACCEPT SUCH INTERFERENCE AS MAY BE RECEIVED FROM OTHER RADIO-FREQUENCY DEVICES WHICH ARE OPERATING IN ACCORDANCE WITH THE FCC RULES.

AVERTISSEMENT: NE PAS UTILISER DE BATTERIES PILES RECHARGEABLES NIQUEL-CADMIUM.
STANDARD (CABONEN-ZINC) AVEC DES PILES RECHARGEABLES NIQUEL-CADMIUM.

WARNING: DO NOT MIX OLD AND NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (CABONEN) OR RECHARGEABLE (NIQUEL-CADMIUM) BATTERIES.

INSTALLATION / FEU ARRIERE

1. Remove the cap and insert the battery into the battery compartment. The cap will snap back into place.
2. Push the battery into the compartment until it is seated.
3. Turn the tail light on by pressing the power button. The LED will flash.

HOW TO USE

1. Press the power button to turn the tail light on. The LED will flash.
2. Press the power button again to turn the tail light off.
3. Press the power button a third time to turn the tail light on in the alternate mode. The LED will flash.

INSTALLATION / CHANGEMENT DE PILE

1. Remove the cap by pulling it away from the battery compartment. The cap will snap back into place.
2. Remove the old battery from the compartment.
3. Insert the new battery into the compartment. The cap will snap back into place.

UTILISATION

1. Appuyez sur le bouton de la pile pour allumer le feu arrière. Le LED clignote.
2. Appuyez à nouveau sur le bouton de la pile pour éteindre le feu arrière.
3. Appuyez une troisième fois sur le bouton de la pile pour allumer le feu arrière en mode alternatif. Le LED clignote.

TO CHANGE / POUR CHANGER LA PILE

NOTE: CHANGE FULLY RECHARGEABLE BATTERIES.
RECHARGEABLE BATTERIES: CHANGEN A BATTERIES NIQUEL-CADMIUM.

1. Remove the cap by pulling it away from the battery compartment. The cap will snap back into place.
2. Remove the old battery from the compartment.
3. Insert the new battery into the compartment. The cap will snap back into place.

BATTERY CHANGE / CHANGEMENT DE PILE

1. Remove the cap by pulling it away from the battery compartment. The cap will snap back into place.
2. Remove the old battery from the compartment.
3. Insert the new battery into the compartment. The cap will snap back into place.

TAIL LIGHT / FEU ARRIERE

MODE	FUNCTION	REMARKS
1	Flash	3 times
2	Flash	7 times
3	Flash	3 times

Charge time: 4 hrs

FCC ID: QW711992N2Z
FCC TESTED TO PL1 STANDARDS

BELL

ARELLA™ 400
USB Rechargeable Tail Light
Feu Arrière Clignotant

FLASHING TURN SIGNAL

WIRELESS REMOTE CONTROL

USB RECHARGEABLE

Easy, No-Tools Installation
Multiple Functions
Left Turn / Right Turn
2 Tail Light Modes

Facile à installer, sans outils
Fonctions multiples
Virage à gauche / Virage à droite
2 modes de feu arrière

The information on this page is provided for informational purposes only. It is not intended to be used as a substitute for professional advice. The information is provided as a service to our customers and is not intended to be used as a substitute for professional advice. The information is provided as a service to our customers and is not intended to be used as a substitute for professional advice.

FCC Statement

2.08"

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more

of the following measures: • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. Shielded interface cable must be used with the equipment in order to comply with the limits for a digital device pursuant to Subpart B of Part 15 of FCC Rules. Specifications and designs are subject to change without any notice or obligation on the part of the manufacturer. Changes / modifications not approved by the responsible party could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. "To comply with FCC RF exposure compliance requirements, this grant is applicable to only Mobile Configurations. The antennas used for this transmitter must be installed to provide a separation distance of at least 5 mm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."