

Quick Start Guide

The B73 is a Bluetooth speaker designed to provide the high-definition sound your digital life demands. Simply pair your handheld device with the B73 to enjoy dynamic stereo sound.



What is in the box

- Bluetooth Speaker
- USB cable for charging
- User manual

■ Bluetooth Instruction (Note: The Bluetooth code is B73 , pair code: 0000)

1. Press and hold the power button for 3 seconds, hear prompt sound, the blue and red LED flash alternately, it is in Bluetooth pairing mode.
(If there is no operation within 10 minutes, it will power off automatically.)
2. On your portable device, turn Bluetooth on, search for Bluetooth devices, and select "B73".
3. If you are promoted to enter a password to complete pairing, enter 0000.
4. The B73 will connect to your device and the blue LED flash slowly.
5. It is ready for use.

■ Charging the Battery

Before first use, please charge the Bluetooth speaker.

Plug the provided USB charging cable into the speaker and a powered USB port.

While charging, the LED light is red. Once fully charged, it will turn off.

Charging time: 1.5hours

Remark: 1. The Bluetooth speaker can be used during charging.

2.The LED flash red quickly when it is low battery.

■ Specifications:

Speaker: D40mm (130HZ-20KHZ)

Power output: 3W 4Ω

SNR: ≥85±3dB

Bluetooth version: 4.2

Bluetooth effective range: up to 10meters

Polymer battery: 400mAh

Charging voltage: DC5V

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.