


# Bluetooth Headhones Instruction Manual

FCC ID:QIFE06-C



1. Indicator Light
2. Micro-USB input port
3. Line-In AUX port
4. Mic
5. ON/OFF switch
6. Multi-function button (Vol +/-, Previous/Next, Play/Pause)

## What's inside?

- 1 x Bluetooth Headhones
- 1 x Micro-USB to USB charging cable
- 1 x Audio Cable
- 1 x Instruction Manual

## Tech Specifications

Capacity: 300mAh  
Bluetooth effective range: up to 10 meters  
Charging Time: about 1.5-2 hours  
Playtime time: 5-6 hours

## Charging the Headphones:

When the device is charging, a Red LED light will turn on to indicate it is charging. The light will turn off when it is fully charged.

When charging with an AC wall adapter connect the provided USB to Micro-USB cable into the headphones (micro USB end) and into the wall adapter (the USB end).

Connect the USB cable into a computer USB output port, and the micro USB end into the headphones, to charge the device from a computer.

## Connected with Bluetooth:

Turn the headphones on and open your mobile devices Bluetooth list of available bluetooth connections. Select "Skyway" from the list and follow the instructions from your mobile device.

## Connected with the Line-In Function:

Connect the Line-In/AUX cable to your mobile device's AUX port. Connect the other end of the AUX cable to the Line-in port on the Headphones. Your mobile device should immediately transfer to the Skyway Bluetooth Headphones.

## LED Indication:

Blue Flashing lights indicates the headphones are on and ready to pair with a mobile device. Once paired the light will shut off. When charging the device will flash Red and Blue until fully charged.

## Multi-Function Button Control:

- 6 [ Long Press Up: Volume Increase  
Short Press Up: Next Track
- 6 [ Short Press Down: Volume Decrease  
Long Press Down: Previous Track

## Important safety precautions

Please note the following precautions before initial use. Failure to comply may be dangerous and cause damage to your mobile devices.

- Charge the headphones fully before initial use.
- Using an incorrect AC power adapter, adapter tip or USB cable can cause damage to both your mobile devices and the headphones.
- Always recharge the headphones in a well-ventilated area. Do not leave the headphones in hot or cold places.
- Do not immerse the headphones in water or expose it to moisture or weather conditions.
- Do not drop, knock, or shake the Headphones. Rough handling can damage the internal precision component and its boards.
- Keep the headphones away from children, this device is not a toy.
- While charging, the headphones casing may become warm, which is normal as the charging and discharging processes generate heat.
- Keep the headphones away from fire or other sources of heat.
- Exposing the headphones to high temperatures may cause it to explode.
- Do not short-circuit the headphones, as this may cause damage to the unit.
- Unauthorized changed or modifications may void your right to use this product.
- While using the headphones, always comply with any special regulations that may apply to the area you are in and always turn off your mobile device when its use is prohibited. For example: do not use the headphones during flight, take-off or landing, as it may cause interference or damage.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Made in China