


TCF No.: TCF-UM-V01

## Quick Start Guide

## Appearance



## Pairing and connection

### Bluetooth pairing

1. Press and hold the Power button for 4 seconds to enter Pairing mode. The indicator should blink white.
2. Enable Bluetooth on your phone and pair with the Bluetooth device "Amazon-XXX". (Note: XXX represents the last three digits of the earphones' Bluetooth MAC address.)



**Automatic reconnection**

After your earphones power on, and they are not in Pairing mode, they will automatically connect to the most recently paired phone.



Your phone must have Bluetooth enabled and also be within Bluetooth range of your earphones.

**Magnetic feature**

When attached, the earphones are disconnected from your phone.

When apart, the earphones automatically reconnect to your phone.

# How to use the earphones

## Call mode

Incoming call	Press the Function button to answer the call, or press and hold the same button for 2 seconds to reject the call.
On a call	Press the Function button to end the call.
Incoming call while on another call	Press the Function button to hold the current call and accept the new call, or press and hold the same button for 2 seconds to reject the new call and continue the current call.
Two calls on two lines (one in progress)	Press the Function button to switch between the two calls, or press and hold the same button for 2 seconds to end the current call.
On a call	Double-press the Function button to switch between the phone's receiver and the earphones.
Making a call	Press the Function button to cancel the call.
On standby	Double-press the Function button to redial the number from the last call.

## Music mode

Press the Function button to play/pause music.

Double-press the Function button to skip to the next song.

Triple-press the Function button to go back to the previous song.

Press the Volume up button to increase the volume.

Press the Volume down button to decrease the volume.

 Compatibility issues may occur with some non-Huawei or non-Honor phones.

## Smart mode

When your earphones are in Music mode and Standby mode, press and hold the Function button for 2 seconds to wake up HiVoice.

## Restoring factory settings

Press and hold the Function button for 10 seconds to restore to factory settings. This will clear the earphones' Bluetooth pairing information and restart them.

## Charging your earphones

1. Charge through a charger:  
Use a USB-C cable to connect to a charger.
2. Charge through a phone:  
Plug into a Huawei phone's USB-C port to charge (not supported by some models).

## Indicator status

Power on	White light on for 1 second
Power off	Red light on for 1 second
Ready for connection	White light flashes 2 times every 3 seconds
Pairing	White light flashes 3 times every second
Connection made	White light on for 1 second
Already connected	White light flashes 1 time every 10 seconds
Incoming/outgoing call	White light flashes 2 times every second
On a call	White light flashes 1 time every 10 seconds
Playing music	White light flashes 1 time every 10 seconds
Charging	Steady red light
Fully charged	Steady white light
Charging cable removed	Indicator goes off
Low battery	Red light flashes 2 times every 10 seconds

## Safety information

Before using the device, read and comply with the following precautions carefully to ensure optimal device performance and avoid danger or violation of laws and regulations.

- Do not use the device at locations where the use of wireless devices is prohibited due to potential interference with other electronic equipment, which may cause safety hazards.
- In clinics and hospitals where the use of wireless devices is prohibited, please comply with the regulations and power off the device.
- Some wireless devices may interfere with implantable medical equipment and other medical equipment, such as pacemakers, cochlear implants, and hearing aids. Consult the manufacturer of your medical equipment for more information.
- When using the device, keep it at least 15 cm away from medical equipment.
- When using the earphones to listen to music or make calls, please use the minimum volume necessary in order to avoid damaging your hearing. Prolonged exposure to high volume sounds may result in permanent hearing damage.
- Please reduce your audio volume while driving in order to reduce distractions and avoid accidents.
- Observe all local traffic laws and regulations while using the device. Do not use the device while driving.
- Keep in mind that while driving, safety is your primary responsibility, and avoid engaging in distracting activities.
- The device's wireless signal may interfere with your car's electronic systems. Please contact your car manufacturer for more information.
- Wireless devices may interfere with an aircraft's flight systems. Adhere to in-aircraft regulations and power off the device when required.
- If you use your earphones while performing activities that require your concentration, such as riding a bike or walking in a potentially dangerous area such as near a construction site or railroad, please pay attention to your safety and the safety of those around you. It is recommended that you either lower the volume on your earphones or remove your earphones in order to increase your awareness of your surroundings.
- Avoid dusty, damp, or dirty environments. Avoid magnetic fields. Using the device in these environments may result in circuit malfunctions.
- Keep the device away from appliances with strong magnetic or electrical fields, such as microwave ovens and refrigerators.
- Do not use the device during thunderstorms to avoid any lightning-related damage or injury.
- Use the device at temperatures between  $-10^{\circ}\text{C}$  and  $+55^{\circ}\text{C}$ , and store the device and its accessories at temperatures between  $-40^{\circ}\text{C}$  and  $+70^{\circ}\text{C}$ . Extreme heat or

cold may damage the device.

- Do not place the device in places that are easily exposed to direct sunlight such as on a car's dashboard or on a window sill.
- Do not place the device near exposed heat or ignition sources (such as heaters, microwaves, ovens, stove fire, candles, and so on).
- Do not place sharp metal objects, such as large pins, near the receiver or speaker of the device. Otherwise, metal objects may be attached, which may cause damage to you.
- The device and its accessories may contain small components. Keep the device and its accessories out of the reach of children. Otherwise, children may damage the device and its accessories by mistake, or swallow the small components, which may result in hazards such as choking.
- The device is not a toy, and children should only use it under adult supervision.
- You can only use device manufacturer-approved accessories for this model number. The use of other accessories may void the device warranty, lead to injury, or violate the related regulations of the country where the device is located. Contact an authorized Huawei Customer Service Center to obtain approved accessories.
- Connecting the device to non-approved or incompatible power supplies, chargers, or batteries is not advised as this may cause fires or explosions.
- Do not disassemble or modify the device, insert foreign objects, or submerge in water or other liquids to prevent leakage, overheating, fires, or explosions.
- Do not drop, squeeze, or puncture the battery. Avoid applying external pressure to the battery as this may cause its electronic circuitry to short or overheat.
- The device is equipped with a non-removable internal battery. Do not attempt to replace the battery yourself to avoid damaging the battery or device or causing fires and explosions. The battery should only be replaced by professional personnel at an authorized Huawei Customer Service Center.
- Ensure that the device and its accessories are dry. Do not attempt to dry the device using an external heating device such as a microwave oven or hair dryer.
- Avoid placing the device or its accessories in environments that are too hot or cold as this may cause device malfunctions or even explosions.
- Stop using the device, close all apps, and disconnect all connected devices before cleaning and performing maintenance on the device.
- Do not use strong chemicals, cleaning agents, or strong detergents to clean the device and its accessories. Instead, only clean the device and its accessories using a clean, soft, and dry cloth.
- Do not place magnetic stripe cards (such as bank cards or phone cards) near the device for extended periods of time as this may damage the magnetic stripe card.
- Please do not disassemble or modify the device and its accessories without prior authorization. Any resulting damage in this case will not be covered by

manufacturer's warranty. If the device suffers an error or ceases to function properly, please contact an authorized Huawei Customer Service Center for assistance.

- Avoid disposing the device and its accessories as ordinary household waste.
- Respect local laws on the disposal of electronic products and their accessories and support recycling efforts.

## Disposal and recycling information



The crossed-out wheeled-bin symbol on your product, battery, literature or packaging reminds you that all electronic products and batteries must be taken to separate waste collection points at the end of their working lives; they must not be disposed of in the normal waste stream with household garbage.

It is the responsibility of the user to dispose of the equipment using a designated collection point or service for separate recycling of waste electrical and electronic equipment (WEEE) and batteries according to local laws.

Proper collection and recycling of your equipment helps ensure electrical and electronic equipment (EEE) waste is recycled in a manner that conserves valuable materials and protects human health and the environment, improper handling, accidental breakage, damage, and/or improper recycling at the end of its life may be harmful for health and environment. For more information about where and how to drop off your EEE waste, please contact your local authorities, retailer or household waste disposal service or visit the website <http://consumer.huawei.com/en/>.

## Reduction of hazardous substances

This device and any electrical accessories are compliant with local applicable rules on the restriction of the use of certain hazardous substances in electrical and electronic equipment, such as EU REACH, RoHS and Batteries (where included) regulations, etc. For declarations of conformity about REACH and RoHS, please visit our web site <http://consumer.huawei.com/certification>.

## EU regulatory conformance

### RF Exposure

Your device is a low-power radio transmitter and receiver. As recommended by international guidelines, the device is designed not to exceed the limits established by the European Commission for exposure to radio waves.

### Statement

Hereby, Huawei Technologies Co., Ltd. declares that this device CM70-C and CM70-L is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU.

The most recent and valid version of the DoC (Declaration of Conformity) can be viewed at <http://consumer.huawei.com/certification>.

This device may be operated in all member states of the EU.



Observe national and local regulations where the device is used.  
This device may be restricted for use, depending on the local network.

## Frequency Bands and Power

(a) Frequency bands in which the radio equipment operates: Some bands may not be available in all countries or all areas. Please contact the local carrier for more details.

(b) Maximum radio-frequency power transmitted in the frequency bands in which the radio equipment operates: The maximum power for all bands is less than the highest limit value specified in the related Harmonized Standard.

The frequency bands and transmitting power (radiated and/or conducted) nominal limits applicable to this radio equipment are as follows: Bluetooth: 2402 MHz-2480 MHz: <10 dBm.

## Accessories and Software Information

Some accessories are optional in certain countries or regions. Optional accessories can be purchased from a licensed vendor as required. The following accessories are recommended:

**Batteries: HUA01/AHB380942TPO/AHB380942TPO-01**

The product software version is **V1.0.0.100**. Software updates will be released by the manufacturer to fix bugs or enhance functions after the product has been released. All software versions released by the manufacturer have been verified and are still compliant with the related rules.

All RF parameters (for example, frequency range and output power) are not accessible to the user, and cannot be changed by the user.

For the most recent information about accessories and software, please see the DoC (Declaration of Conformity) at <http://consumer.huawei.com/certification>.

## FCC Regulatory Compliance

### FCC statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**Caution:** Any changes or modifications to this device not expressly approved by Huawei Technologies Co., Ltd. for compliance could void the user's authority to operate the equipment.

## Industry Canada compliance

### Certification information (SAR)

The highest SAR value reported to the IC for this device type when using it in portable exposure conditions is **XXXX W/kg**.

### IC Statement

This device complies with CAN ICES-3 (B)/NMB-3(B).

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(S). Operation is subject to the following two conditions:

This device may not cause interference.

This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

L'appareil ne doit pas produire de brouillage;

L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

## Legal statement

**Copyright © Huawei Technologies Co., Ltd. 2019. All rights reserved.**

This document is for reference only. Nothing in this guide constitutes a warranty of any kind, express or implied.

All pictures and illustrations in this guide, including but not limited to the product color, size, and display content, are for your reference only. The actual product may vary.

Nothing in this guide constitutes a warranty of any kind, express or implied.

Please visit <http://consumer.huawei.com/us/support/index.htm> for recent updated hotline and email address in your country or region.

The *Bluetooth*<sup>®</sup> word mark and logos are registered trademarks owned by *Bluetooth SIG, Inc.* and any use of such marks by Huawei Technologies Co., Ltd. is under license.

## **User Software License Agreement**

Please read the software license agreement carefully before using the product. By using the product, you indicate that you agree to be bound by the license agreement. If you do not agree with the terms of the license agreement, please do not use the product and software. The product can be returned to the point of sale for a refund. For agreement content, please visit: <https://consumer.huawei.com/en/legal/eula/>.

## **Privacy protection**

To understand how we protect your personal information, please visit <http://consumer.huawei.com/privacy-policy> and read our privacy policy. For United States warranty card information, visit <http://consumer.huawei.com/us/support/warranty-policy/index.htm>.

Model: CM70-C, CM70-L



300404130815E00