

Pegasus Technologies, Inc.
PT11MHTransceiver

Users Manual (Preliminary)

RF Transceiver Installation Instructions

The PT11MH Transceiver Frequency Hopping Spread Spectrum transceiver. This transceiver should only be installed by qualified service personnel. The transceiver detects level, low battery or other data signals from the external binary inputs and broadcasts that data to the system's host receiver.

MOUNTING LOCATION

The PT11MH Transceiver is a module as defined by the FCC and therefore must be mounted to another host device in order to function.

This device is intended only for OEM integrators under the following conditions:

- 1) The integrator must position this device in any end product such that the antenna to user/bystander distance is greater than 20 cm when the transmitter is functioning (excluding hands, wrists, feet and ankles).
- 2) The transmitter module may not be co-located with any other transmitter or antenna.

As long as the 2 conditions above are met, further transmitter testing will not be required. However, the OEM integrator is still responsible for testing their end-product for any additional compliance requirements required with this module installed (for example, digital device emissions, PC peripheral requirements, etc.).

IMPORTANT NOTE: In the event that these conditions can not be met (for example applications where the antenna to user distance is < 20 cm or to be co-located with another transmitter), then the original FCC authorization is no longer considered valid and the FCC ID can not be used on the final product. In these circumstances, the OEM integrator will be responsible for re-evaluating the end product (including the transmitter) and obtaining a separate FCC authorization.

NOTICE TO CUSTOMER

Any Pegasus Technologies customer incorporating the PT11MH transceiver module into its own product must have an external notice affixed to its product. This notice must be placed in a conspicuous location and can use wording such as: "Contains FCC ID: QLBPT11MH" or "Contains Transceiver Module FCC ID: QLBPT11MH". Any similar wording that expresses the same meaning may be used.

NOTE: The end user should NOT be provided any instructions on how to remove or install the device.

RF Exposure Manual Information That Must be Included to End User

The users manual for end users must include the following information in a prominent location
"IMPORTANT NOTE: To comply with FCC RF exposure compliance requirements, the antenna used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter."

INSTALLATION INSTRUCTIONS

1. Supply the transceiver with DC power by inserting a 3.6 Volt battery into the battery holder on the customers host application circuit board.
2. The unit will come pre-programmed with a Network ID and Hop Seed. However, the customer does have the option of field programming the unit.
3. If possible, avoid installing the PT11MH in areas near large metallic objects such as air conditioners, heaters, screens and heaters.

CAUTION:

This device is required to comply with FCC RF exposure requirements for mobile and fixed transmitting devices. The FCC requires that the antenna used for this transmitter must be installed to provide a separation of at least 20 cm (8 inches) from all persons (not including hands, wrists, feet, and ankles) and must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC NOTICE

The Model PT11MH transceiver generates and uses radio frequency energy. If not installed and used in accordance with the manufacturer's instructions, it may cause interference to radio and television reception. The transceiver has been tested and found to comply with the specifications in Part 15 of FCC Rules for Spread Spectrum Intentional Radiators and FCC Part 15 Subpart C, Specifications.

If this equipment causes interference to radio or television reception - which can be determined by turning the equipment on and off - the installer is encouraged to correct the interference by one or more of the following measures: 1) Reorient the antenna of the radio/television. 2) Connect the AC transformer to a different outlet so the control panel and radio/television are on different branch circuits. 3) Relocate the control panel with respect to the radio/television.

If necessary, the installer should consult an experienced radio/television technician for additional suggestions, or send for the "Interference Handbook" prepared by the Federal Communications Commission. This booklet is available from the U.S. Government Printing Office, Washington, D.C., 20402, stock number 004-000-00450-7.

CAUTION: No field changes or modifications to the PT11MH should be made unless they are specifically covered in this manual.

All adjustments must be made at the factory under the specific guidelines set forth in our manufacturing processes. Any modification to the equipment could void the user's authority to operate the equipment and render the equipment in violation of FCC Part 15, Subpart C, 15.247.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

LIMITED WARRANTY

THERE ARE NOT WARRANTIES, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR OTHERWISE, WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. In no case shall Seller be liable to anyone for any consequential or incidental damages for breach of this or any other warranty, express or implied, or upon any other basis of liability whatsoever, even if the loss or damage is caused by Seller's own negligence or fault.