

User Manual

1. Turn on the computer.
2. Insert two Ni-MH AA batteries into the battery compartment at the bottom of the keyboard. Take care to insert the batteries in the correct polarity. Take out the RF receiver and close the battery cover.
3. Plug the RF receiver into the USB port of your computer.
4. ID pairing:
 - a. Keep the distance between keyboard and Receiver within 1 meter.
 - b. Press the connect button at the front side of keyboard. Receiver LED light flashes 3-5 seconds, then turns off, keyboard is synchronized, you may enjoy the use.

Note:

1. RF signal LED on the receiver will flash when the keyboard is being used.
2. Battery Low indicator flashes red light, you need to charge the batteries. Connect the keyboard to a available USB port on PC with the mini-USB extension cable to charge batteries. During charging, Battery Low indicator displays red light, it would become green light after the batteries are fully charged.
3. In order to extend the batteries life, please charge for no lower than 8 hours when you charge first time.

FCC WARNING

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

This device must be installed to provide a separation distance of at least 20 cm from all persons and must not be collocated or operating in conjunction with any other antenna or transmitter.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful

interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

NOTE 3: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.