

## **GARAGE DOOR SENSOR Model 45130**

### **1. INTRODUCTION**

The garage door sensor model 45130 is designed to monitor the status of your garage door and advise you if the door is open. By placing the sensor on the door panel, you will be alerted when the door is open. When the garage door is open, the receiver will beep and flash.

In this package, you should find a sensor, 3V lithium battery and mounting accessories.

Please follow the instructions below to setup the garage door sensor.

### **2. INSTALLATION**

#### **POWER UP**

- i) Remove the battery cover on the sensor and insert the 3V battery to the sensor as shown in the diagram.
- ii) After inserting the battery to the sensor, press and hold the learn button in the receiver unit, release the button when the receiver emits a beep. Select the zone location in the receiver, press the zone button [1 or 2 or 3 or 4] once on the receiver unit. The corresponding zone red LED on the receiver will flash.
- iii) When the sensor portion is fully extended, the receiver unit will emit a long beep indicating it has learned the code from the sensor.

#### **MOUNTING LOCATION**

Step 1 – Select a spot on your garage door to mount the sensor

Before you install the sensor onto the garage door, make sure the garage door is closed. The sensor assembly should be mounted on one of the vertical supports of your garage door near the bottom.

When the door is closed, the detection rod should be retracted. When the door is open, the detection rod will be extended.

Step 2 – Mount the sensor onto your garage door

You can mount the sensor onto your garage door with double-sided foam tape if the surface of your garage door is smooth and clean enough to provide a good adhesive surface, such surface can usually be found on a metal garage door. Please ensure the surface is smooth and clean. Important: The bottom of the sensor should be 1/2 inch above the ground.

For wooden garage doors, it is recommended to mount the sensor with screws onto the garage door with 3 x 18 screws provided.

#### **OPERATION**

When the garage door is open, the sensor will send a signal to the receiver. It will beep and the corresponding zone red LED light will flash.

If the sensor is set to zone 2, zone 2 LED on the receiver will flash, and the receiver unit will emit a continuous “2 beeps”.

By the number of beeps emitted by the receiver, user can identify which zone is triggered.

#### **FCC**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### **WARRANTY**

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

#### **CUSTOMER SERVICE**

If you would like to order other products or have difficulty getting them to work, please:

CUSTOMER SERVICE  
JASCO PRODUCTS COMPANY  
10E, Memorial, Oklahoma City, OK 73114 USA  
Tel:405-302-2370