## **WATER SENSOR Model 45133**

### 1. INTRODUCTION

The door/window sensor model 45133 is designed to detect the water overflow, water leakage or rising water such as the water level of your bathtub. When water is detected, the receiver will alert you. It will beep and flash.

In this package, you should find a sensor, 3V lithium battery.

Please follow the instructions below to setup the wate sensor.

## 2. INSTALLATION

## **POWER UP**

- i) Remove the top cover of the sensor and insert the 3V battery to the sensor as shown in the diagram.
- ii) After inserting the battery to the water sensor, press and hold the learn button in the receiver unit, release the button when the receiver emits a beep. Select the zone location in the receiver, press the zone button [1 or 2 or 3 or 4] once on the receiver unit. The corresponding zone red LED on the receiver will flash.
- iii) You can test the water sensor by submerging the sensor portion in water. Note: Only the sensor portion of the water sensor is waterproof, the transmitter portion should never be submerged in water.
- iv) When the sensor portion becomes submerged in water, the receiver unit will emit a long beep indicating it has learned the code from the sensor.

### MOUNTING LOCATION

A clean smooth surface is required to mount the water sensor securely. Mount the transmitter portion and sensor portion to the appropriate location with suction cups respectively.

## **OPERATION**

When the sensor portion detects water overflow, water leakage, or rising water, the receiver will beep and the corresponding zone red LED light will flash.

If the sensor is set to zone 4, zone 4 LED on the receiver will flash, and the receiver unit will emit a continuous "4 beeps".

By the number of beeps emitted by the receiver, user can identify which zone is triggered.

#### FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be

determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase and a Return Authorization are required.

## **CUSTOMER SERVICE**

If you would like to order other products or have difficult getting them to work, please:

CUSTOMER SERVICE
JASCO PRODUCTS COMPANY
10E, Memorial, Oklahoma City, OK 73114 USA
Tel:405-302-2370