




Ref -10 dBm Att 20 dB RBW 3 MHz Delta 1 [T1] 0.20 dB
 *VBW 3 MHz SWT 150 ms 99.700000 ms

1 PK
VIEW



★
A
SGL

Duty Cycle:

$$= \frac{1 \times (1.5) + 6 \times (0.5) + 22 \times (0.25)}{99.7}$$

$$= 0.1$$

Average Factor:


$$= 20 \log (0.1)$$

$$= -20 \text{ dB}$$


Center 318.01 MHz 15 ms/



Ref -10 dBm Att 20 dB RBW 3 MHz Delta 1 [T1]
*VBW 3 MHz SWT 25 ms -0.09 dB
1.500000 ms




Date: 1.NOV.2007 11:13:37



Date: 1.NOV.2007 11:14:13



Ref -10 dBm Att 20 dB RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz SWT 10 s -27.75 dBm
680.000000 ms




Date: 1.NOV.2007 17:01:14



Ref -10 dBm Att 20 dB RBW 3 MHz Delta 1 [T1]
*VBW 3 MHz SWT 25 ms 0.14 dB
250.000000 μs

1 PK
VIEW



★
A
SGL

Center 318.01 MHz 2.5 ms/