


RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -22.53 dBm
SWT 22 ms 1.432000 ms

Ref -10 dBm Att 20 dB

1 PK
VIEW



★
A
SGL

Duty Cycle
= $[1(1.43) + 7(0.504) + 20(0.24)] / 99$
= 0.099

Average Factor
= $20 \log (0.099)$
= -20.1dB

Center 317.942 MHz

2.2 ms/


RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -22.72 dBm
SWT 125 ms 99.000000 ms

Ref -10 dBm

Att 20 dB

1 PK
MAXH

★
A
SGL



Center 317.942 MHz


12.5 ms/

RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -22.83 dBm
SWT 10 s 600.000000 ms

Ref -10 dBm

Att 20 dB

1 PK
VIEW



Center 317.942 MHz


1 s/

RBW 3 MHz Marker 1 [T1]
*VBW 3 MHz -24.52 dBm
SWT 1 s 614.000000 ms

Ref -10 dBm

Att 20 dB

1 PK
MAXH



Center 317.942 MHz

100 ms/