

Keypad Transmitter Model : 45146

1. INTRODUCTION

The transmitter allows you to operate the receiver. It is a wall mount type transmitter to allow to access easily.

2. LEARN TRANSMITTER TO THE CONTROL PANEL

In order for the transmitter to communicate with the control panel properly, the transmitter must be programmed to the control panel. Follow the brief instructions below or refer to the detail instructions from the User's Instructions to program the transmitter to the control panel.

To program the transmitter to control panel:

1. Slide the mode switch to 'ON' position in the control panel.
2. Press and hold the 'Learn' button in the control panel. The 'ON' LED will begin to flash and it will continuous beeps.
3. Enter the password [1 2 3 4] on the transmitter.
4. If a connection has been made, you will hear a long tone from the control panel and the 'ON' LED will stop flashing.

3. OPERATION

Enter the password [1 2 3 4], this will activate the "learn" control panel. Or press the PANIC button on the transmitter to activate the "learn" control panel.

4. BATTERY

The remote control operates on a 3-volt lithium battery that is installed at the factory. These batteries do not need to be replaced if used under normal condition. There are no servicing parts inside the unit, please do not attempt to open the case. Warranty void if case is opened.

Recommendation: Test your transmitter periodically to ensure that all the batteries are working.

5. WARRANTY

If, within one year from date of purchase, this product should become defective (except battery), due to faulty workmanship or materials, it will be repaired or replaced, without charge. Proof of purchase is required.

6. FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference

to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

7. CUSTOMER SERVICE

If you would like to order Skylink's products or have difficulty getting them to work, please :

1. visit our FAQ section at www.skylinkhome.com, or
2. email us at support@skylinkhome.com, or
3. call our toll free at 1-800-304-1187 from Monday to Friday, 9am to 5pm EST. Fax (800) 286-1320.

SKYLINK TECHNOLOGIES INC.,
17 Sheard Avenue, Brampton, Ontario, Canada L6Y 1J3

Email: support@skylinkhome.com

Website: <http://www.skylinkhome.com>

© 2010 Skylink Group