

AZUMI


Ultra User Guide




WELCOME

- Congratulations on your purchase of the Azumi mobile phone. Your phone provides many functions which are practical for daily use, such as a hands-free loudspeaker, camera, MP3 player, Ultra clear video, WIFI and GPS.
- You can read the manual to understand how to use Azumi mobile phone and experience the well-established functions and simple operation method. Please use the original accessory in order to achieve the best use of effects. Azumi shall not be responsible for any damage in machinery due to use of non-original components.

PHONE OVERVIEW



CHARGE THE BATTERY




Connect this end to phone's USB port.


Tip: Be sure to charge your phone's battery completely after inserting it in the phone for the first time.

INSERT MICRO SIM CARD

1. Stick the eject tool into the pin hole, the Micro-SIM Tray will be out of the card slot.




2. Insert the Micro-SIM card correctly in Micro-SIM Tray.



3. Push the Micro-SIM Tray into the card slot.


TURN ON / OFF THE PHONE

- Press and hold power key (on the left side) to turn on phone.
- Press and hold power key (on the left side) until a menu will show. Choose the “power off” to turn off the phone




LOCK AND UNLOCK THE SCREEN

- Press the power key to lock. Or the screen will auto lock if you don't use the phone for a while.
- Drag the lock icon to any direction to unlock it.



HOME SCREEN




- **Status Bar**

The status bar shows your phone's status. The icons means:

Icon	Statement	Icon	Statement
	SIM Network signal		Headset is connected
	battery capacity		Bluetooth
	Unread messages		Wi-Fi
	Missed calls		Airplane mode
	Alarm		USB is connected


- **Notifications**

Slide to screen down to find the notifications. It will show weather, new message, phone connect status and more.




- **Calling**

- Make a call

Touch calling icon  in the home screen, then into the phone screen.


Tap the numbers you want to dial or open the contact list  to choose, touch  for calling.



- During the call

When the call is coming, you can slide to answer or hang up it.


Additional, you also can flip the card for more option, like ignoring an incoming call, SMS reply.




- **Message**

Touch the message icon  to view received messages or creates a new message.

Touch a text field to see the onscreen keyboard, and then tap the letters to type.


Use delete key  if you type a wrong letter.

Use  to turn into another line


After your finish, tap  to send out your message.

- **Apps**









Claro Apps




All Apps



MUSIC



	Play or Pause
	Previous song
	Next song
	Single Cycle, No Repeat, Random Playing, or Repeating current list
	Current playlist
	Sleep timer. The music will be auto closed after you appointed time.
	Add or Remove a song to collects
	DTS effect, Such as Standard, Nature, Surround, Voice, and Default.















FM RADIO




1. Insert earphone, and then tap the Power icon to stop or play FM.
2. Tap the forward by 0.1 MHz or scroll the knob icon to change channel frequency. Press volume key to adjust the volume.
3. Tap Auto search, Speaker, Record FM and Favorites icon to adjust.

TAKE A PICTURE

1. Launch the camera by pressing the camera icon  on the screen.
2. In the processing, tap the screen to focus on a specific area.
3. Press the camera button  to take a picture.


	CharmCam
	Set flash to open, close, or automatically.
	Transfer between the rear camera and front camera.
	Enter the menu about the camera settings.
	Enter Gallery
	Transfer between camera and video recorder.
	Choose Normal, Gesture shot, Touch shoot and Smile shot. Gesture shot and Smile shot allows you to take self-portraits without touching screen.
	Transfer between the rear camera and front camera.
	Enter Gallery
	Face beauty, adjustment of Skin, Face, and Eyes
	Make-up, slide to choose style of Angel, Breeze, Charm, Frosty, Glow, Natural, Ocean, Rose, Silk, Smoky, Tropics, and Velet.
	Multiple filters can choose. Sepia, Antique, Lomo yellow, Grayscale, Emboss, Negative, Lomo green, Lomo neutral, and Vignetting.
	Slide to screen and choose the stamps when you take a photo.
	Focus on PPT, whiteboards or books. Photos will be automatically adjusted.

SHOOT A VIDEO

1. Press the camera icon  on the screen, and then touch video icon  to transfer it.
2. Press the video button  to begin filming, and press again to stop it.

USE AS MODEM VIA USB

You can connect your phone to a computer with a USB cable, to transfer music, pictures, and other files between your phone's SD card and the computer.



CONNECT TO Wi-Fi NETWORKS

Wi-Fi is a wireless networking technology that can provide Internet access at distances of up to 100 meters, depending on the Wi-Fi router and your surroundings.

Touch Settings ->All settings -> WLAN. Check Wi-Fi to turn it on. The phone scans for available Wi-Fi networks and displays the names of those it finds. Secured networks are indicated with a Lock icon.

SETTINGS

Get to know the settings in your phone so that you can personalize them to your own requirements. Go to Settings to configure how your phone looks, sounds, communication, privacy, and operations in a variety of ways.

Airplane mode	Turn on the airplane mode. It will close your mobile network, WLAN, and Bluetooth wireless connections.
Mobile Network	Set preferences on how you use SIM card inserted in your phone.
WLAN	WLAN is a wireless networking technology that can provide internet access at distance of up to 100 meters, depending on the WLAN router and your surroundings. Touch to choose a Wi-Fi to connect it.
Bluetooth	Bluetooth is a short-range wireless communications technology that devices can use to exchange information over a short distance.
More wireless	Manage your wireless connections and connections settings. Let you configure and manage connections to networks and devices by Using Wi-Fi, hotspot, VPN, USB internet and default SMS app.
Sound and vibrate	Voice control. You can customize the ringtone and volume of incoming call, notification ringtone in this interface.
Display	Adjust your screen brightness, font size, change wallpaper, settle the screen sleep time, cast screen, auto rotate screen, lock screen notifications and close button light.
Security	Manage your personal information, set up a password for screen lock, SIM card lock, and credential storage.
Location	Location mode includes High accuracy, Battery saving, Device only.

Add account	Set up an account in Corporate, Google, IMAP, and POP3.
Battery	Battery status and active battery saving mode.
Storage	Check phone capacity and format phone
Apps	Apps management.
Smart gestures	Smart dial, Smart answer, Pause alarm, Double click wake, Quick operation, Smart remind
Date & time	Set date and time, choose the format of them
Schedule power on/off	Turn on / off the phone at you appointed time.
Schedule airplane on/off	Turn on / off the airplane mode at you appointed time.
Language & input	Select the phone language and keyboard input methods.
System backup	Back up the data from contact, SMS, Call log, Calendar, and Email.
Backup & reset	Back up app data, WLAN passwords and other settings to Google services before reset the phone.
Accessibility	Enable your installed accessibility applications and adjust related settings.
Printing	Turn on / off cloud print
Developer options	Select runtime and USB debugging
About phone	Phone status, legal information, model number, Android version, kernel version, build number, and Wireless update.

		Ultra
Corriente eléctrica encendido		385mA
Corriente eléctrica pantalla		310mA
Voltaje Pantalla		DCDC-12V
Corriente eléctrica Llamada		140mA
Voltaje Llamada		3.6-4.35V
Voltaje celular apagado		3.6V
Voltaje de teléfono		3.6-4.35V
Cargador de corriente ca/cc	Entrada	100-240V 50/60HZ 200mA
	Salida	5.0V 1000mA

1.FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

SAR Information Statement

Your wireless phone is a radio transmitter and receiver. It is designed and manufactured not to exceed the emission limits for exposure to radiofrequency (RF) energy set by the Federal Communications Commission of the U.S. Government. These limits are part of comprehensive guidelines and establish permitted levels of RF energy for the general population. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6 W/kg. * Tests for SAR are conducted with the phone transmitting at its highest certified power level in all tested frequency bands. Although the SAR is determined at the highest certified power level, the actual SAR level of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a wireless base station antenna, the lower the power output. Before a phone model is available for sale to the public, it must be tested and certified to the FCC that it does not exceed the limit established by the government adopted requirement for safe exposure. The tests are performed in positions and locations (e.g., at the ear and worn on the body) as required by the FCC for each model. The highest SAR value for this model phone when tested for use at the ear is 0.345W/Kg and when worn on the body, as described in this user guide, is 0.733W/Kg(Body-worn measurements differ among phone models, depending upon available accessories and FCC requirements). The maximum scaled SAR in hotspot mode is 0.733W/Kg. While there may be differences between the SAR levels of various phones and at various positions, they all meet the government requirement for safe exposure. The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/oet/fccid> after searching on

FCC ID: QRP-AZUMIULTRA Additional information on Specific Absorption Rates (SAR) can be found on the Cellular Telecommunications Industry Association (CTIA) web-site at <http://www.wow-com.com>. * In the United States and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in measurements.

Body-worn Operation

This device was tested for typical body-worn operations. To comply with RF exposure requirements, a minimum separation distance of 10mm must be maintained between the user's body and the handset, including the antenna. Third-party belt-clips, holsters, and similar accessories used by this device should not contain any metallic components. Body-worn accessories that do not meet these requirements may not comply with RF exposure requirements and should be avoided. Use only the supplied or an approved antenna.