

## Operational Description of the equipment

<b>PRODUCT</b>	ANT + Heart Rate Transmitter
<b>MODEL NO.</b>	ZT22A
<b>POWER SUPPLY</b>	DC power source from battery : 3Vdc/65uA
<b>CABLE</b>	NA
<b>FREQUENCY BAND</b>	2.400GHz ~ 2.483.5GHz
<b>CARRIER FREQUENCY</b>	2.457GHz
<b>CHANNEL SPACING</b>	NA
<b>NUMBER OF CHANNEL</b>	1
<b>RATED RF OUTPUT POWER</b>	82.8dBuV/m
<b>MODULATION TYPE</b>	GFSK
<b>BIT RATE OF TRANSMISSION</b>	250Kbit/sec
<b>MODE OF OPERATION</b>	Simplix
<b>ANTENNA TYPE</b>	Chip Antenna
<b>ANTENNA GAIN</b>	2 dBi
<b>OPERATING TEMPERATURE RANGE</b>	-10 ~ 60°C

## PUTTING ON THE TRANSMITTER

- Attach one end of the adjustable elastic strap to the transmitter
- Moisten the rubber electrodes of the belt with either water or saliva as shown
- Position the transmitter on the chest just below the breastbone, with the Cardiosport logo the right way up.
- Pass the elastic strap around your chest and attach to the other end of the transmitter.
- Adjust the strap to give a close but comfortable fit.

