

FLIP SPEEDER LIGHTS



PLEASE READ THIS INSTRUCTION MANUAL CAREFULLY BEFORE USE.

The materials, specifications, parts and packaging mentioned in this manual are for reference purposes only. We are not responsible for any changes made to this printed material, nor are we able to inform customers of any updates or changes. Please refer to our website: R3VOLT.COM for the latest information.

IMPORTANT SAFETY INFORMATION

Thank you for buying this REVOLT item. To ensure that you operate the vehicle correctly. Please read these instructions carefully before first use and store them in a safe place for future reference.

Safety information

- *Keep the smaller-sized accessories out of the reach of children.
- *Do not store batteries in a hot environment (e.g. near open flames or a heating device).
- *Children must be supervised by an adult when operating the vehicle. The vehicle should always remain within the line of sight of the driver (or instructor).
- *Do not recharge non-rechargeable batteries. When installing or changing the batteries, ensure that they are connected in the correct polarity. Do not mix old and new batteries or different types.
- *Do not short circuit the battery terminals.
- *If you do not plan to use the vehicle for at least 10 days, discharge the battery to 40%-50% (i.e. if the battery is fully charged, drive the vehicle for half of the total driving time). This helps to prolong the lifespan of the battery.
- *You must only use the charging cable provided. Disconnect the charging cable from the vehicle before cleaning. Regularly inspect the charging cable's wires, plug socket, outer casing and other accessories to ensure they are not damaged. If there are any signs of damage, discontinue use immediately until repaired.
- *After use, ensure that the vehicle and remote control are switched off and remove the batteries in the remote control.

 *The packaging and this manual contain important information and should be kept in a safe place for future reference.

Repair and maintenance

- *Clean the product regularly with a clean, soft cloth.
- *Avoid exposing the product to direct sunlight or heat.
- *Do not submerge the product in water, as this may damage the electrical components.

PRODUCT SPECIFICATIONS

Remote Control Vehicle

Weight	321.8g
Dimensions	16.5 x 16 x 7cm / 6.5" x 6.3" x 2.75"
Remote control range	appr. 30 meters / 100 Feet
Charging time	appr. 90 min
Operating time	appr. 15 min
Battery	3.7V500mAh rechargeble battery (included)

Remote Control


Operating frequency	2.4 GHz
Battery Requirements	2xAA 1.5V batteries (not included)

CONTENTS:

•1x Light stunt car

- 1x Remote Control
- •1x USB Charging Cable

BASIC OPERATING INSTRUCTIONS:






PAIRING:

- 1.Switch the vehicle power to "ON".
- 2. Switch the remote Control to "ON".
- 3. The vehicle and remote Control will pair automatically when both are "ON".

MOVING THE VEHICLE:



INSERTING THE BATTERIES

Remote control


- 1. Check the ON/OFF switch is in the "OFF" position.
- Use a screwdriver to loosen the screw.
- Remove the battery cover.
- 4. According the polarity indicated inside in the remote control. Put the 2*AA battery into the hattery compartment
- 5. Put the battery cover back and tighten the screw.



Remote control car


- 1.Check the ON/OFF switch is in the "OFF" position.
- Use a screwdriver to loosen the screw.
- Remove the battery cover.
- 4. Install the battery as indicated in the picture on the right:
- Connect the rechargeable battery in the battery pack as indicated in the picture.
- Put the battery cover back and tighten the screw.

Note: If breakdown occurs in the product, please take out the battery for one minute, and then reinstall it. If the breakdown still exists, please replace the battery. The battery can only be installed by the adults.



CHARGING THE BATTERIES

Vehicle



Battery charging

- ·Connect the USB charger to USB output on computer or AC/DC adaptor, then insert the car charger plug to the vehicle charging port (see diagram)
- ·A full charge takes 90 minutes. When charging the LED indicator turns red, when charging is complete, the LED indicator stays off.
- Regularly inspect the toy, battery charger, charging cable, connectors and other components for signs of damage. In the event of any damage, discontinue use and send the parts for repair.



- In case of abnormal responses such as suspicious smell, noise or smoke in the charger, please remove the power supply at once.
- Please recharge with the dedicated USB charging cable delivered with the product.

 Never use broken charging cables or charging cables from other products.
- Please do not recharge the swelling, leaking or broken battery.
- ·Please do not overcharge the battery. When the battery is fully recharged, please stop charging!
- ·Please do not recharge the battery near flammable things(carpet, wood floor, furniture, etc.) or of conductive objects. While recharging please keep the battery within line of sight.

Caution

- ·Do not touch moving Wheels' to avoid entanglment and injury to yourself or damage to the car.
- ·Please do not play by the road or in dangerous places that could accidents.
- ·Do not use this vehicle near water.
- ·Before using the car, make sure the car battery cover screws are tightened. Failure to tighten may cause water damage to the vehicle.
- If recharging is necessary, please take the battery out of the remote control vehicle (if applicable).









Warning!

- *This product must be assembled and used under the direct supervision of an adult.
- *This product contains small components that present a choking hazard if swallowed; this product is not suitable for children under 5 years of age.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not / installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- •Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

"This device complies with FCC radiation exposure limits set forth for general population(uncontrolled exposure). This device must not be collocated or operating in conjunction with any other antenna or transmitter."

Decoration of Conformity Inserts:

"Hereby, GuangDong Syma model drone Industrial co, Itd, declares that this drone is in compliance with the essential requirements and other relevant provisions of Directive 2014/53/EU."

A copy of the full DoC is attached.

SYMA MODEL AIRCRAFT INDUSTRIAL CO.LTD

Address: Intersection of Xingye Road No. 2 (West side) and Xingye Road (North side), Laimei Industrial Park, Chenghai District, Shantou, Guangdong Province, China Sales hotline: 0754-86980668, After-sales hotline: 0754-86930595

Fax: 0754-86395098 Zip code: 515800

The manufacturer the right to the final interpretation of this instruction manual.