

FiiO®


快速入门指南 Quick Start Guide



Model no.:FX 1221

English **Portable High Resolution Music Player**
X1 2nd Gen (hereinafter referred to as X1)

Buttons and Ports Introduced



Portable High Resolution Music Player

A. Basic Operations

- **Power on/off:** Hold "Power/Lock" for 2s, the screen will turn on and show the boot animation. With the unit powered on, hold "Power/Lock" for 2s to turn it off.
- **Connect to computer:** Insert a micro SD card into X1 card slot, then use the included micro USB cable to connect the X1 to the computer (no driver is required). After that you may transfer music files to the TF / Micro SD card by copy & paste.
- **Play Music:** While in the main menu, touch the "Touch wheel" or press the "Previous" & "Next" to locate the "Browse Files" menu, then press the "OK" to enter. After that select a music file and press the "OK" to play it.

B. Notes On Usage

- The X1II will skip any songs it has trouble decoding to prevent hang-ups. If the charging voltage from the power adapter is too high, the X1II would switch off automatically and stop charging. Please switch to an appropriate charger; rating of DC 5V/2A is recommended.
- If a system error or hang-up occurs, try holding the Power / Lock button for 10 seconds to force a shutdown.
- After transferring music to the micro SD card on the X1II, the media library needs to be updated for the tracks to show on the category menus and play under all modes.

If the unit is to be left unused for a long time, please recharge the unit periodically to preserve its battery life. Batteries should not be exposed to direct sunlight, fire or other such high-temperature conditions.

Learn More

For more product information, please visit the website www.fiiio.net
And for the complete user manual, please visit <http://fiiio.net/en/supports> to download the related PDF document.

Portable High Resolution Music Player

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.