

Bluetooth speaker

BTS-518B



INSTRUCTION MANUAL

**PLEASE READ ALL INSTRUCTIONS
CAREFULLY AND RETAIN FOR FUTURE USE**



In the Box

- Bluetooth Speaker
- Charging Cable
- Instruction Manual

Features

- Enjoy music wirelessly
- Multi-mode LED light
- Built-in rechargeable battery.
- Clear sound with bass effect.
- IPX4 resistance, can be used indoors and outdoors

Safety Instructions

Read this manual carefully before putting the appliance into operation and keep this manual for future reference.



- Do not insert any metal object into the device.
- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not attempt to repair the device yourself.

- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

ABOUT WATER RESISTANCE

This speaker is resistant to water splashes with IPX4 standard. It might be used in a shower and can get wet, but cannot be submerged in water. Make sure the DC 5V water resistant protector is sealed before coming into contact with any water.

Description of Parts



1	Power ON/OFF button
2	DC 5v input port
3	Bluetooth connect/disconnect
4	Light on/off
5	Power off (Standby)
6	Power on (Valid only when the speaker is in Standby mode)
7	Color selection
8	White light
9	Increase the light (valid for R/G/B light only)
10	Decrease the light (valid for R/G/B light only)
11	Light mode 1

12	Light mode 2
13	Light mode 3
14	One color light dances to the music
15	Multicolor light dances to the music
16	Mute the speaker
17	Play/Pause
18	Volume decrease
19	Volume increase
20	Previous
21	Next

Tips: To save power consumption, please use the ON/OFF button on the bottom to turn off the speaker completely. When you use the remote controller to turn off the speaker, the speaker is actually in Standby mode.

Charging Instructions

This Bluetooth speaker comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully. Only use the supplied charging cable to charge the Bluetooth speaker.

1. Connect the charging cable to the DC 5V port on the unit.
2. Connect the other end of the charging cable to a USB port on a PC or an AC/DC adapter.

Pairing the Bluetooth speaker with Bluetooth devices (phone or music device)

1. Turn on the Bluetooth speaker.
2. Turn on your Bluetooth enabled device and activate the Bluetooth function.
3. Search for the Bluetooth device, “BTS-518C” will show up.
4. Pair your Bluetooth enabled device with BTS-518C. If a password is needed, type in “0000”. After the BTS-518C is paired with your device, connect it to your device.

Specifications

Bluetooth version	4.2(Not support BLE)
Bluetooth operating distance	10 meters (equal to 33 feet)

Frequency range	2.4-2.48GHz
Frequency response	100Hz-20kHz
Speaker power	1x5w
Distortion	≤1%
Playback time	Approx 3-4 hours
Charging input power	DC 5V
Charging time	Approx 3 hours
IP grade	IPx4 (Splash proof)

Note: Battery life & charging time may vary, based on usage & types of devices used.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 (1) this device may not cause harmful interference, and
 (2) this device must accept any interference received, including interference that may cause undesired operation.
 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are

designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.