

# Bluetooth speaker

**BTS-C13**

## INSTRUCTIONS MANUAL

**PLEASE READ ALL INSTRUCTIONS  
CAREFULLY AND RETAIN FOR FUTURE USE**



**Getting started**

- Remove the Bluetooth speaker & accessories from the box.
- Remove all packaging from the Bluetooth speaker.
- Place the packaging inside the box to either store or dispose of safely.

## **In the Box**

- Bluetooth Speaker
- USB Charging Cord
- AUX in cable
- Instructions Manual

## **Features**

- Portable Bluetooth Speaker with carabiner
- Built-in hands free microphone.
- AUX input function
- Support TF card.
- Redial last number
- Every time the Bluetooth speaker is turned on, it connects to last connected device automatically

## **Safety Instructions**

Read this manual carefully before putting the

appliance into operation and keep this manual for future reference.

- I Do not insert any metal object into the device.
- I To avoid a static charge, do not use the device in an extremely dry climate.
- I Do not attempt to repair the device yourself.
- I Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

## Description of Parts



1	Power On/Off
2	Vol-/Prev
3	Play/Pause/Phone button
4	Vol+/Next
5	DC5V micro USB charging port
6	AUX input jack
7	TF card slot
8	Mode (switch between Bluetooth pairing, TF card, and AUX input mode)

## Charging Instructions

This Bluetooth speaker comes with a built in rechargeable battery. Before using it for the first time we recommend you charge the battery fully.

1. Connect the USB cable to the USB port on the unit.
2. Connect the other end of the USB cable to a USB port on a PC or an AC/DC adapter, the LED on the speaker turns red, the Bluetooth speaker is being charged. When the battery is fully charged, the red LED turns off.


## **Pairing the Bluetooth speaker with Bluetooth devices (phone or music device)**


1. Turn on the Bluetooth speaker.
2. Turn on your Bluetooth enabled device and activate the Bluetooth function.
3. Search for the Bluetooth device, “BTS-C13” will show up.
4. Pair your Bluetooth enabled device with BTS-C13. If a password is needed, type in “0000”. After the BTS-C13 is paired with your device, connect it to your device.

### **Tips:**

Once the speaker is paired and connected to your Bluetooth device, it automatically connects the next time as long as the Bluetooth on your device is on.

## **Control a phone call via speaker**

**Answer a call:** Short press the  button.

**End a call:** Short press the  button.

**Redial the last number:** Press the phone button twice quickly.

## Specifications

Bluetooth profiles	HSP, HFP, A2DP and AVRCP
Bluetooth operating distance	10 meters (equal to 33 feet)
Frequency	2402-2480MHz
Speaker output power	3w
Frequency response	100Hz-20kHz
Distortion	≤1%
Microphone sensitivity	-40db
Playback time	Approx 4 hours
Charging input power	DC 5V
Charging time	Approx 3 hours
Unit size	105*70*40 mm
Unit weight	Approx. 176g

**Note:** Battery life & charging time may vary, based on usage & types of devices used.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.