


# Bluetooth Speaker

**YM-386**  
**User Manual**



## Safety Instructions

Read this manual carefully before putting the appliance into operation and keep this manual for future reference.

- Do not insert any metal object into the device.
- To avoid a static charge, do not use the device in an extremely dry climate.
- Do not attempt to repair the device yourself.
- Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like



## In the Box

- Bluetooth Speaker
- USB charging cord
- AUX in cable
- User manual

## Features

- Multi Bluetooth speaker with night light
- Waterproof portable speaker with Bluetooth receiver
- Built in rechargeable lithium battery.
- Built in microphone for hands free phone calls.
- Support TF card playback.
- AUX in function for nonbluetooth devices.

## Location of Controls



1. On/Offswitch, Play/Pause/Phone, Mode button: Switch between Bluetooth, TF card playback, and AUX mode.
2. PREV/Vol-
3. Next/Vol+
4. On/Off switch of LED light
5. 3.5mm AUX in jack.
6. Micro SD card slot.
7. DC 5V charging port.

## Pairing the Bluetooth Speaker

1. Switch the ON/OFF switch to ON position.
2. Press the Mode button, the status LED will flash blue, indicating that the Bluetooth speaker is in pairing mode.
3. Set your Bluetooth-enabled device to search for Bluetooth devices.
4. When the Bluetooth-enabled device finds the Bluetooth speaker, select "YM-386" from the list of found devices.
5. After a successful pairing, a beep tone will be heard, indicating that the device is paired and the Bluetooth status LED will stay solid blue.

If a previously paired device is in range when the Bluetooth speaker is turned on and in Bluetooth pairing mode, the Bluetooth speaker will connect to it automatically.

## Using the Nightlight function

1. Press the (⊗) button to turn on the Night Light mode.
2. Press (⊗) again to turn off the Night Light.

## Using the Bluetooth Speaker

### Powering ON/OFF

\*Press (⊗) and hold the (⊗) button for about 3 seconds.

### Play/Pause/Mode button

Quick press (⊗) button to play or pause music. Press (⊗) and hold button for about 3 seconds to switch between Switch between Bluetooth, TF card playback, and AUX mode.

Press (+) button to skip to the next song.

Press button (-) to skip to the previous song, next song.

### Adjusting the volume:

Press (+) button to increase volume.

Press (-) button to decrease volume.

### Answering/ending a call:

To answer a call, quick press the (⊗) button.

To end a call, quick press the (⊗) button again.

### Redial the last number:

Double quick press the (⊗) button, The last number called will be redialed.

### Playing music from TF card

Insert TF card into the TF card slot.

Press (⊗) button to turn on the Bluetooth speaker.

Press Mode button to switch the Bluetooth speaker to TF card playback mode.

## Charging the Bluetooth speaker

To charge the Bluetooth speaker, connect the supplied micro USB cable to the USB charging port and the other end to your computer or USB charging device. The LED indicator next to the charging port will stay red when charging. When charging is completed, the charging LED indicator will turn off.

**i** Make sure you charge your Bluetooth speaker for at least 4 hours before using it for the first time.

## Specifications

Night light	White
Bluetooth profiles	HSP, HFP, A2DP and AVRCP
Bluetooth operating distance	10 meters (equal to 33 feet)
Output power	3.5w
Microphone sensitivity	-40db
Playback time	4 to 6 hours

Charging input power	DC 5V
Charging time	Approx 3 hours
Unit size	220x95x95 mm
Unit Weight	400g

Note: Battery life & charging time may vary, based on usage & types of devices used.

## FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver,
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: Modifications to this product will void the user's authority to operate this equipment.