




802.11g CHANNEL 2, CARRIER LEVEL



802.11g CHANNEL 2, REFERENCE LEVEL




802.11g CHANNEL 2, BAND EDGE




802.11g CHANNEL 10, CARRIER LEVEL




802.11g CHANNEL 10, REFERENCE LEVEL




802.11g CHANNEL 10, BAND EDGE




802.11g CHANNEL 11, CARRIER LEVEL




802.11g CHANNEL 11, REFERENCE LEVEL



802.11g CHANNEL 11, BAND EDGE




802.11n-20 MHz CHANNEL 1, CARRIER LEVEL




802.11n-20 MHz CHANNEL 1, REFERENCE LEVEL




802.11n-20 MHz CHANNEL 1, BAND EDGE




802.11n-20 MHz CHANNEL 2, CARRIER LEVEL




802.11n-20 MHz CHANNEL 2,
REFERENCE LEVEL



802.11n-20 MHz CHANNEL 2, BAND EDGE





802.11n-20 MHz CHANNEL 3, CARRIER LEVEL




802.11n-20 MHz CHANNEL 3, BAND EDGE


802.11n-20 MHz CHANNEL 3,
REFERENCE LEVEL




802.11n-20 MHz CHANNEL 4, CARRIER LEVEL




802.11n-20 MHz CHANNEL 4, REFERENCE LEVEL




802.11n-20 MHz CHANNEL 4, BAND EDGE




802.11n-20 MHz CHANNEL 5, CARRIER LEVEL




802.11n-20 MHz CHANNEL 5,
REFERENCE LEVEL



802.11n-20 MHz CHANNEL 5, BAND EDGE





802.11n-20 MHz CHANNEL 9, CARRIER LEVEL




802.11n-20 MHz CHANNEL 9, BAND EDGE


802.11n-20 MHz CHANNEL 9,
REFERENCE LEVEL




802.11n-20 MHz CHANNEL 10, CARRIER LEVEL




802.11n-20 MHz CHANNEL 10, REFERENCE LEVEL




802.11n-20 MHz CHANNEL 10, BAND EDGE




802.11n-20 MHz CHANNEL 11, CARRIER LEVEL




802.11n-20 MHz CHANNEL 11,
REFERENCE LEVEL



802.11n-20 MHz CHANNEL 11, BAND EDGE



802.11n-40 MHz CHANNEL 3, CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, BAND EDGE


802.11n-40 MHz CHANNEL 3,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 4, CARRIER LEVEL




802.11n-40 MHz CHANNEL 4, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 4, BAND EDGE




802.11n-40 MHz CHANNEL 5, CARRIER LEVEL




802.11n-40 MHz CHANNEL 5,
REFERENCE LEVEL



802.11n-40 MHz CHANNEL 5, BAND EDGE





802.11n-40 MHz CHANNEL 7, CARRIER LEVEL




802.11n-40 MHz CHANNEL 7, BAND EDGE


802.11n-40 MHz CHANNEL 7,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 8, CARRIER LEVEL




802.11n-40 MHz CHANNEL 8, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 8, BAND EDGE




802.11n-40 MHz CHANNEL 9, CARRIER LEVEL




802.11n-40 MHz CHANNEL 9,
REFERENCE LEVEL



802.11n-40 MHz CHANNEL 9, BAND EDGE




VHT-20 MHz CHANNEL 1, CARRIER LEVEL




VHT-20 MHz CHANNEL 1, BAND EDGE


VHT-20 MHz CHANNEL 1,
REFERENCE LEVEL




VHT-20 MHz CHANNEL 2, CARRIER LEVEL




VHT-20 MHz CHANNEL 2, REFERENCE LEVEL




VHT-20 MHz CHANNEL 2, BAND EDGE




VHT-20 MHz CHANNEL 3, CARRIER LEVEL




VHT-20 MHz CHANNEL 3, REFERENCE LEVEL




VHT-20 MHz CHANNEL 3, BAND EDGE




VHT-20 MHz CHANNEL 4, CARRIER LEVEL




VHT-20 MHz CHANNEL 4, BAND EDGE




VHT-20 MHz CHANNEL 4, REFERENCE LEVEL




VHT-20 MHz CHANNEL 5, CARRIER LEVEL




VHT-20 MHz CHANNEL 5, REFERENCE LEVEL




VHT-20 MHz CHANNEL 5, BAND EDGE




VHT-20 MHz CHANNEL 10, CARRIER LEVEL




VHT-20 MHz CHANNEL 10, REFERENCE LEVEL



VHT-20 MHz CHANNEL 10, BAND EDGE





VHT-20 MHz CHANNEL 11, CARRIER LEVEL




VHT-20 MHz CHANNEL 11, BAND EDGE

VHT-20 MHz CHANNEL 11, REFERENCE LEVEL



VHT-40 MHz CHANNEL 3, CARRIER LEVEL




VHT-40 MHz CHANNEL 3, REFERENCE LEVEL




VHT-40 MHz CHANNEL 3, BAND EDGE




VHT-40 MHz CHANNEL 4, CARRIER LEVEL




VHT-40 MHz CHANNEL 4, REFERENCE LEVEL




VHT-40 MHz CHANNEL 4, BAND EDGE




VHT-40 MHz CHANNEL 5, CARRIER LEVEL




VHT-40 MHz CHANNEL 5, BAND EDGE




VHT-40 MHz CHANNEL 5, REFERENCE LEVEL




VHT-40 MHz CHANNEL 7, CARRIER LEVEL




VHT-40 MHz CHANNEL 7, REFERENCE LEVEL



VHT-40 MHz CHANNEL 7, BAND EDGE





VHT-40 MHz CHANNEL 8, CARRIER LEVEL




VHT-40 MHz CHANNEL 8, REFERENCE LEVEL

VHT-40 MHz CHANNEL 8, BAND EDGE





VHT-40 MHz CHANNEL 9, CARRIER LEVEL




VHT-40 MHz CHANNEL 9, BAND EDGE

VHT-40 MHz CHANNEL 9, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 2, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 3, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 3, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 3, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 4, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 4, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 4, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 5, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 5,
REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 5, BAND EDGE



802.11ax-20 MHz(SU) CHANNEL 9, CARRIER LEVEL



802.11ax-20 MHz(SU) CHANNEL 9,
REFERENCE LEVEL



802.11ax-20 MHz(SU) CHANNEL 9, BAND EDGE

