




VHT-20 MHz CHANNEL 5, REFERENCE LEVEL



VHT-20 MHz CHANNEL 5, BAND EDGE





VHT-20 MHz CHANNEL 8, CARRIER LEVEL




VHT-20 MHz CHANNEL 8, BAND EDGE


VHT-20 MHz CHANNEL 8, REFERENCE LEVEL




VHT-20 MHz CHANNEL 9, CARRIER LEVEL




VHT-20 MHz CHANNEL 9, REFERENCE LEVEL




VHT-20 MHz CHANNEL 9, BAND EDGE




VHT-20 MHz CHANNEL 10, CARRIER LEVEL




VHT-20 MHz CHANNEL 10, REFERENCE LEVEL



VHT-20 MHz CHANNEL 10, BAND EDGE





VHT-20 MHz CHANNEL 11, CARRIER LEVEL




VHT-20 MHz CHANNEL 11, BAND EDGE

VHT-20 MHz CHANNEL 11, REFERENCE LEVEL




VHT-40 MHz CHANNEL 3, CARRIER LEVEL




VHT-40 MHz CHANNEL 3, REFERENCE LEVEL




VHT-40 MHz CHANNEL 3, BAND EDGE




VHT-40 MHz CHANNEL 4, CARRIER LEVEL




VHT-40 MHz CHANNEL 4, REFERENCE LEVEL




VHT-40 MHz CHANNEL 4, BAND EDGE




VHT-40 MHz CHANNEL 5, CARRIER LEVEL




VHT-40 MHz CHANNEL 5, REFERENCE LEVEL




VHT-40 MHz CHANNEL 5, BAND EDGE




VHT-40 MHz CHANNEL 7, CARRIER LEVEL




VHT-40 MHz CHANNEL 7, REFERENCE LEVEL




VHT-40 MHz CHANNEL 7, BAND EDGE




VHT-40 MHz CHANNEL 8, CARRIER LEVEL




VHT-40 MHz CHANNEL 8, REFERENCE LEVEL



VHT-40 MHz CHANNEL 8, BAND EDGE




VHT-40 MHz CHANNEL 9, CARRIER LEVEL




VHT-40 MHz CHANNEL 9, BAND EDGE

VHT-40 MHz CHANNEL 9, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 1, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 2, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 2,
REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 2, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 3, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 3,
REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 3, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 4, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 4, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 4, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 5, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 5,
REFERENCE LEVEL



802.11ax-20 MHz(SU) CHANNEL 5, BAND EDGE





802.11ax-20 MHz(SU) CHANNEL 8, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 8, BAND EDGE


802.11ax-20 MHz(SU) CHANNEL 8,
REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 9, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 10, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 10,
REFERENCE LEVEL




802.11ax-20 MHz(SU) CHANNEL 10, BAND EDGE




802.11ax-20 MHz(SU) CHANNEL 11, CARRIER LEVEL




802.11ax-20 MHz(SU) CHANNEL 11,
REFERENCE LEVEL



802.11ax-20 MHz(SU) CHANNEL 11, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 3, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 3, REFERENCE LEVEL




802.11ax-40 MHz(SU) CHANNEL 3, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 4, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 4,
REFERENCE LEVEL




802.11ax-40 MHz(SU) CHANNEL 4, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 5, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 5,
REFERENCE LEVEL




802.11ax-40 MHz(SU) CHANNEL 5, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 7, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 7, REFERENCE LEVEL




802.11ax-40 MHz(SU) CHANNEL 7, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 8, CARRIER LEVEL




802.11ax-40 MHz(SU) CHANNEL 8,
REFERENCE LEVEL




802.11ax-40 MHz(SU) CHANNEL 8, BAND EDGE




802.11ax-40 MHz(SU) CHANNEL 9, CARRIER LEVEL



802.11ax-40 MHz(SU) CHANNEL 9,
REFERENCE LEVEL



802.11ax-40 MHz(SU) CHANNEL 9, BAND EDGE



MIMO-Aux. Antenna


802.11b CHANNEL 1, CARRIER LEVEL



802.11b CHANNEL 1, REFERENCE LEVEL




802.11b CHANNEL 1, BAND EDGE




802.11b CHANNEL 11, CARRIER LEVEL




802.11b CHANNEL 11, REFERENCE LEVEL




802.11b CHANNEL 11, BAND EDGE




802.11g CHANNEL 1, CARRIER LEVEL




802.11g CHANNEL 1, REFERENCE LEVEL




802.11g CHANNEL 1, BAND EDGE




802.11g CHANNEL 2, CARRIER LEVEL




802.11g CHANNEL 2, REFERENCE LEVEL




802.11g CHANNEL 2, BAND EDGE




802.11g CHANNEL 3, CARRIER LEVEL




802.11g CHANNEL 3, REFERENCE LEVEL




802.11g CHANNEL 3, BAND EDGE




802.11g CHANNEL 8, CARRIER LEVEL




802.11g CHANNEL 8, REFERENCE LEVEL




802.11g CHANNEL 8, BAND EDGE




802.11g CHANNEL 9, CARRIER LEVEL




802.11g CHANNEL 9, REFERENCE LEVEL




802.11g CHANNEL 9, BAND EDGE




802.11g CHANNEL 10, CARRIER LEVEL




802.11g CHANNEL 10, REFERENCE LEVEL




802.11g CHANNEL 10, BAND EDGE




802.11g CHANNEL 11, CARRIER LEVEL




802.11g CHANNEL 11, REFERENCE LEVEL



802.11g CHANNEL 11, BAND EDGE




802.11n-20 MHz CHANNEL 1, CARRIER LEVEL



802.11n-20 MHz CHANNEL 1, REFERENCE LEVEL



802.11n-20 MHz CHANNEL 1, BAND EDGE



802.11n-20 MHz CHANNEL 2, CARRIER LEVEL

