




802.11n-20 MHz CHANNEL 2, CARRIER LEVEL




802.11n-20 MHz CHANNEL 2, REFERENCE LEVEL



802.11n-20 MHz CHANNEL 2, BAND EDGE





802.11n-20 MHz CHANNEL 10, CARRIER LEVEL




802.11n-20 MHz CHANNEL 10,
REFERENCE LEVEL

802.11n-20 MHz CHANNEL 10, BAND EDGE





802.11n-20 MHz CHANNEL 11, CARRIER LEVEL




802.11n-20 MHz CHANNEL 11, BAND EDGE


802.11n-20 MHz CHANNEL 11,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 3, CARRIER LEVEL




802.11n-40 MHz CHANNEL 3, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 3, BAND EDGE




802.11n-40 MHz CHANNEL 4, CARRIER LEVEL




802.11n-40 MHz CHANNEL 4,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 4, BAND EDGE




802.11n-40 MHz CHANNEL 5, CARRIER LEVEL




802.11n-40 MHz CHANNEL 5,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 5, BAND EDGE




802.11n-40 MHz CHANNEL 7, CARRIER LEVEL




802.11n-40 MHz CHANNEL 7, REFERENCE LEVEL




802.11n-40 MHz CHANNEL 7, BAND EDGE




802.11n-40 MHz CHANNEL 8, CARRIER LEVEL




802.11n-40 MHz CHANNEL 8,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 8, BAND EDGE




802.11n-40 MHz CHANNEL 9, CARRIER LEVEL




802.11n-40 MHz CHANNEL 9,
REFERENCE LEVEL




802.11n-40 MHz CHANNEL 9, BAND EDGE




VHT(20 MHz) CHANNEL 1, CARRIER LEVEL




VHT(20 MHz) CHANNEL 1, REFERENCE LEVEL




VHT(20 MHz) CHANNEL 1, BAND EDGE




VHT(20 MHz) CHANNEL 2, CARRIER LEVEL




VHT(20 MHz) CHANNEL 2, REFERENCE LEVEL




VHT(20 MHz) CHANNEL 2, BAND EDGE




VHT(20 MHz) CHANNEL 10, CARRIER LEVEL




VHT(20 MHz) CHANNEL 10, BAND EDGE




VHT(20 MHz) CHANNEL 10, REFERENCE LEVEL




VHT(20 MHz) CHANNEL 11, CARRIER LEVEL




VHT(20 MHz) CHANNEL 11, REFERENCE LEVEL




VHT(20 MHz) CHANNEL 11, BAND EDGE




VHT(40 MHz) CHANNEL 3, CARRIER LEVEL




VHT(40 MHz) CHANNEL 3, REFERENCE LEVEL




VHT(40 MHz) CHANNEL 3, BAND EDGE




VHT(40 MHz) CHANNEL 4, CARRIER LEVEL




VHT(40 MHz) CHANNEL 4, BAND EDGE




VHT(40 MHz) CHANNEL 4, REFERENCE LEVEL




VHT(40 MHz) CHANNEL 5, CARRIER LEVEL




VHT(40 MHz) CHANNEL 5, REFERENCE LEVEL




VHT(40 MHz) CHANNEL 5, BAND EDGE




VHT(40 MHz) CHANNEL 7, CARRIER LEVEL




VHT(40 MHz) CHANNEL 7, REFERENCE LEVEL




VHT(40 MHz) CHANNEL 7, BAND EDGE



VHT(40 MHz) CHANNEL 8, CARRIER LEVEL



VHT(40 MHz) CHANNEL 8, BAND EDGE



VHT(40 MHz) CHANNEL 8, REFERENCE LEVEL

