Antenna Infomation

Project number: C235249

Brand Name: OPPO

Model Name: CPH2519

Antenna Type: IFA Internal (Inverted F Antenna)

Manufacturer: Guangdong OPPO Mobile Telecommunications Corp., Ltd.

NO.18 Haibin Road, Wusha Village, Chang'an Town, Dongguan City, Guangdong, China

BT/WIFI

Antenna Gain and Antenna Type specification:

Brand Name: OPPO

Model Name: CPH2519

Antenna Location&dimension:

Please refer to "" for the information

Antenna Gain and Antenna Type specification:

Antenna Gain (dBi)		ANT	Ant		Ant 13		Antenna model	Manufacturer
		0	9	Ant 12		Antenna Type		
2.4G WiFi	2400~2483.5MHz	-0.69	1	0.07	/	IFA(Inverted F Antenna)	AC067-TOP-COVER	OPPO
5G Wifi	5150~5250 MHz	/	0.54	/	-3.76	IFA(Inverted F Antenna)	AC067-TOP-COVER	OPPO
	5250~5350 MHz	/	0.62	/	-3.26	IFA(Inverted F Antenna)	AC067-TOP-COVER	OPPO
	5470~5725 MHz	/	0.85	/	-2.86	IFA(Inverted F Antenna)	AC067-TOP-COVER	OPPO
	5725~5850 MHz	/	0.29	/	-2.36	IFA(Inverted F	AC067-TOP-COVER	OPPO

						Antenna)		
ВТ	2400~2483.5MHz	-0.69	/	0.07	/	IFA(Inverted F Antenna)	AC067-TOP-COVER	OPPO
NFC	13.56MHz	/	/	1	1	FPC(Flexible Printed Circuit)	AC076	Huizhou speed wireless technology co.,ltd.

Table 1 Antenna Gain and Antenna Type specification

Note: Antenna gain was measured in the anechoic chamber, 3D scan was exercised, and the highest numbers are reported in this document.

Accoring to Test standard: IEEE Std 149-2021, we measure antenna gain .


Antenna Radiation Pattern:

	Ant0	Ant9	Ant12	Ant13
WIFI2.4G/BT	3_01		Y	
WIFI5G b1 (5150~5250 MHz)				
WIFI5G b2 (5250~5350 MHz)				Y Y

WIFI5G b3 (5470~5725 MHz)	7	
WIFI5G b4 (5725~5850 MHz)	~	

NFC passive impedance on phone

Zload@13.56MHz	BW(-3dB)
4.75Ω+0.443Ω	0MHz



List of Test and Measurement Instruments

TEST EQUIPMENT

NO.	Equipment	Manufacturer	Model No.
1	AMS-8923	ETS-Lingen	SN1702
2	Network Analyzer E5071C	Kesight	MY4690575



Fig 2 dipole model 3126-2500 frequency 2500 MHz



Fig 3 model 3126-5500 frequency 5500 MHz

I. Measurement Setup:

A. Reflection Coefficient Measurement:

Instrument: Network Analyzer (Kesight E5071C).

Setup:

- 1. Calibrate the Network Analyzer by one port calibration using Kesight 85093C Electronic calibration module .
- 2. Connect the antenna under test to the Network Analyzer.
- 3. Measure the S11(reflection coefficient), Return Loss....

B. Pattern Measurement:

A Fully Anechoic Chamber is used to simulate free-space conditions.

A Fully Anechoic Chamber is a shielded room lined with RF/microwave absorber on all walls, ceiling, and floor.

RF/microwave absorber reduces reflections from the inner walls of the shield. Absorber performance depends on the depth and design of the

absorber and the angle of incidence of the field.

Normal incidence is best, shallower angles are worse.




Fig. 4. The fully anechoic chamber