one touch | MF100\M

Ouick Start Guide

For more information about how to use the phone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAO (English version only).



This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 15 of this

When carrying the product or using it while worn on your body, either use an approved www.sar-tick.com accessory such as a holster or otherwise maintain a distance of 1.5 cm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.



(

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates

ALCATELOne touch.

Calls

3.1 Making a call

Dial the desired number, press the ightharpoonup key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the 🛜 key.

Making an emergency call

If your phone is covered by the network, dial emergency number such as "I12" and press the ___ key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

3.2 Receiving a call

When you receive an incoming call, press the _ key to talk and then hang up using the key.

Your mobile.....

one touch MF100W



- Left softkey
- 6 Left navigation key 4 Lock (long keypress)/
- softkey and then *)
- Right navigation key 6 Silence mode Up/down navigation key unlock (Ouick keypress left OK key

With this menu, you may personalise wallpaper.

6 Power on/ off

End call

Display

Alarm

Your mobile phone has a built-in alarm clock with snooze

From the main menu, select the menu icon and select the

Phone settings, Call settings, SOS settings, Network

function of your choice in order to customise your telephone

settings, Security settings, Restore factory settings.

I.I Keys

- Up/down navigation key
- Adjust volume From idle screen
- Short keypress ▲: Inbox(Messages)
- Short keypress ▼: Calendar
- Left navigation key From idle screen
 - Short keypress 4: Alarm
- Right navigation key
- From idle screen - Short keypress : Settings
- Confirm an option From idle screen
 - Short keypress: access Menu
- Long keypress: activate SOS Send call
 - Access to call log (idle screen)
- Power on/off the handset (long keypress) End call
 - Return to idle screen
- Left softkey
- From idle screen
- Short keypress: access Menu
- Right softkey From idle screen
- Short keypress: access Phonebook

From idle screen

- Short keypress; enter zero
- Long keypress: enter the symbol "+/P/W" In edit mode:
- Short keypress:
- "-" (space) (text edit mode)
- 0 (Add numbers)

¥ ♠ From idle screen

- Short keypress: 3
- Long keypress: lock keypad in idle screen
- When the phone is locked, quick keypress left softkey and then * to unlock keypad
- In edit mode:
- Short keypress: access the symbols table

From idle screen

- Short keypress: #
- Long keypress: activate/deactivate the silence mode In edit mode:
- Short keypress: change input methods

Idle screen icons

- Battery charge level
- 24 Message unread
- Call divert programmed.
- Silence mode: your phone neither rings, beeps, nor
- Alarm clock programmed.
- Keypad locked.
- Level of network reception.

Getting started......

2.I Set-up

Removing and installing the back cover











Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, push it and slide it out.

Charging the battery



Connect the battery charger to your phone and mains socket respectively.

- The charging may take about 20 minutes to start if the battery is flat.
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables).
- When using your telephone for the first time, charge the battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the \Longrightarrow key until the phone powers on.

2.3 Power off your phone

Hold down the \Longrightarrow key from the main screen.

Safety and use..... We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained

. TRAFFIC SAFFTY.

11

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked.

When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some When switched on your phone emits electromagnetic waves that can

interfere with the vehicle's electronic systems such as ABS anti-lock brakes or airbags. To ensure that there is no problem:

- do not place your phone on top of the dashboard or within an airbag deployment area.
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF energy.
- CONDITIONS OF USE You are advised to switch off the telephone from time to time to optimise

Switch the phone off before boarding an aircraft.

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive atmosphere

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing Do not let children use the phone and/or play with the telephone and

accessories without supervision

12



In this menu, you will see Missed calls, Dialled calls, Received calls and Call time. You can also Delete calls.



Phonebook



8.1 Consulting your contacts

To access the directory from the idle screen, press the — key. The complete contacts are available in this menu.

8.2 Adding a contact

Select "Add new contact", press the "Options" softkey, select "select" to input the contact information.



Profiles



With this menu, you may personalise ringtones for different events and environments.



all the messaging options.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.



Press the key # sto get the decimal point. Confirm with the left

10.2 Converter

Through the menu, you can operate currency conversion with local

10.3 Sound recorder

In this menu, you can record new voice memo, and press or to save



can type a message and select to send it to a recipient. You can type a message, and you're also able to insert a pre-defined message from "Templates". While writing a message, select "Options" to access





II.I Create SMS

From the main menu select "Messages" to create text message. You



12.1 Calendar

Once you enter this menu, there is a monthly-view calendar for you to keep track of important appointments, etc. Days with events entered will be marked.

Latin input mode...

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key. Press the key several times until the desired letter is highlighted. When you release the key the highlight character is inserted into the text.
- Predictive with the Zi mode: this mode speeds up the writing of your text. Write the word by pressing a key between 2 and 9wxz. Press the key once and the word will be modified each time you press a key. As you go on, the word will keep changing. Example: For "Tomorrow", press on the following

8_{TUV}, 6_{MNO}, 6_{MNO} = Too -> 6_{MNO} -> 7_{PORS} -> Tomorrow O & key in edit mode Short keypress:

"-" (space) (text edit mode)

0 (Add numbers)

English - CIB25S0ALAAA

IP4244_MF100W_QG_Eng_GB_for FCC_01_130325.indd 1 2013-3-25 17:25:52



When replacing the cover please note that your phone may contain substances that could create an allergic reaction

Always handle your phone with care and keep it in a clean and dust-free place Do not allow your phone to be exposed to adverse weather o environmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C

Over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious. Emergency call numbers may not be reachable on all cellular networks. You

should never rely only on your phone for emergency calls Do not open, dismantle or attempt to repair your mobile phone yourself.

Do not drop, throw or bend your mobile phone. Do not paint it

Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are compatible with your phone model. TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries.

Remember to make back-up copies or keep a written record of all important information stored in your phone.

Some people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the

- Do not play or use a flashing-lights feature if you are tired or need sleep.
- Take a minimum of a 15-minute break hourly
- Play in a room in which all lights are on
- Play at the farthest distance possible from the screen
- If your hands, wrists, or arms become tired or sore while playing, stop and rest for several hours before playing again
- If you continue to have sore hands, wrists, or arms during or after playing. stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your body. Follow the instructions to avoid problems such as tendinitis, carpal tunnel syndrome, or other musculoskeletal disorders.

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original invoice.

Batteries (2) and accessories sold with your phone are also warranted against any defect which may occur during the first six (6) months (1) from the date of purchase as shown on your

In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

This warranty covers the cost of parts and labor but excludes any other costs.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

- The warranty period may vary depending on your country
- The life of a rechargeable mobile phone battery in terms of conversation time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months

ase note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your mobile phone regarding taking photographs and recording sounds with your mobile to take photographs and/or to record the voices of other people or any of their personal attributes, and duplicate or distribute them, as this may be considered to be an invasion of privacy. It is the user's sole responsibility to ensure that prior authorisation be obtained, if necessary, in order to record rivate or confidential conversations or take a photograph of another person: the manufacturer, the seller or vendor of your mobile phone (including the operator) disclaim any liability which may result from the improper use of the

BATTEDV.

Before removing the battery from your phone, please make sure that the phone is switched off.

Observe the following precautions for battery use:

- Do not attempt to open the battery (due to the risk of toxic fumes and burns).
- Do not puncture, disassemble or cause a short-circuit in a battery Do not burn or dispose of a used battery in household rubbish or store it
- at temperatures above 60°C Batteries must be disposed of in accordance with locally applicable

environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates



This symbol on your telephone, the battery and the accessories means that these products must be taken to collection points at the end of their life:

- Municipal waste disposal centres with specific bins for these items of equipment

- Collection bins at points of sale.

They will then be recycled, preventing substances being disposed of in the environment, so that their components can be reused.

In European Union countries:

These collection points are accessible free of charge.

All products with this sign must be brought to these collection points In non European Union jurisdictions:

Items of equipment with this symbol are not to be thrown into ordinary hins if your jurisdiction or your region has suitable recycling and collection facilities; instead they are to be taken to collection points for them to be recycled.

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.



- recommended by TCT Mobile Limited.
- by TCT Mobile Limited or its affiliates or your vendor
- 4) Inclement weather, lightning, fire, humidity, infiltration of high voltage, corrosion, oxidation.

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

CHARGERS

Mains powered chargers will operate within the temperature range of: 0°C

The chargers designed for your mobile phone meet with the standard for safety of information technology equipment and office equipment use. They are also compliant to the ecodesign directive 2009/125/EC. Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive

RADIO WAVES

Your mobile device is a radio transmitter and receiver. It is designed not to persons, regardless of age and health.

The radio wave exposure guidelines use a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit for mobile devices is 2.0 W/kg. Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are:

Troubleshooting..... My phone cannot charge properly Make sure you are using an Alcatel battery and the charger

from the box

in the charge

(0°C to +40°C)

Invalid SIM card

scratched

· Try connecting in another location

Unable to make outgoing calls

SIM card valid, etc.)

is displayed

Before contacting the service centre, you are advised to follow the instructions below:

- You are advised to fully charge (III) the battery for optimal
- Avoid storing large amounts of data in your phone as this may affect its performance
- Use User Data Format to perform phone formatting, (to perform User Data format, hold down # while simultaneously pressing the power on/off key under the power off mode). ALL User phone data: contacts, photos, messages and files will be lost permanently.

and carry out the following checks:

My phone cannot switch on

the phone (

- Check the battery contacts, remove and reinstall your battery, then turn your phone on
- Check the battery power level, charge for at least 20 minutes
- If it still does not work, please use User Data Format to reset

My phone is frozen or has not responded for several

- Restart your phone by pressing and holding the 🗫 key
- Remove the battery and re-insert it, then restart the phone
- If it still does not work, please use User Data Format to reset the phone (1)

My phone turns off by itself

- Check that your keypad is locked when you are not using your phone, and make sure power off key is not mis-contacted due to unlocking keypad.
- · Check the battery charge level
- If it still does not work, please use User Data Format to reset

nize interference on the network, the operating power of your mobile device is automatically decreased when full power is not needed for the call. The lower the power output of the device, the lower its SAR value Body-worn SAR testing has been carried out at a separation distance of 1.5

cm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from

Organizations such as the World Health Organization and the US Food and Drug Administration have stated that if people are concerned and want to reduce their exposure they could use a hands-free device to keep the phone away from the head and body during phone calls, or reduce the amount of time spent on the phone

For more information you can go to www.alcatelonetouch.com Additional information about electromagnetic fields and public health are

Your telephone is equipped with a built-in antenna. For optimal operation you should avoid touching it or degrading it.

other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 1.5 cm away from the

This mobile phone complies with part 15 of the ECC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

compliance could void the user's authority to operate the equipment.

Supplement C.

• RF Exposure Information (SAR)

antenna, the lower the power output.

FCC is 1.6W/kg, and 1.6W/kg by Industry Canada.

with the device directly contacted to the body.

1.14 W/kg, for usage near the body is 0.55 W/kg.

of 15 mm between this device and your body.

after searching on FCC ID: RAD375.

This phone is designed and manufactured not to exceed the emission limits

During SAR testing, this device is set to transmit at its highest certified power

level in all tested frequency bands, and placed in positions that simulate RF

exposure in usage against the head with no separation, and near the body

with the separation of 15 mm. Although the SAR is determined at the highest

certified power level, the actual SAR level of the device while operating can

be well below the maximum value. This is because the phone is designed to

operate at multiple power levels so as to use only the power required to

reach the network. In general, the closer you are to a wireless base station

The exposure standard for wireless devices employs a unit of measurement

known as the Specific Absorption Rate, or SAR. The SAR limit set by the

This device is compliance with SAR for general population /uncontrolled

exposure limits in ANSI/IEEE C95.1-1992 and Canada RSS 102, and had been

specified in OET Bulletin 65 Supplement C, and Canada RSS 102. This device

The ECC has granted an Equipment Authorization for this model phone with

all reported SAR levels evaluated as in compliance with the FCC RF exposure

guidelines. SAR information on this model phone is on file with the FCC and

can be found under the Display Grant section of www.fcc.gov/oet/ea/fccid

For this device, the highest reported SAR value for usage against the head is

While there may be differences between the SAR levels of various phone

SAR compliance for body-worn operation is based on a separation distance

of 15 mm between the unit and the human body. Carry this device at least 15

mm away from your body to ensure RF exposure level compliant or lower to

the reported level. To support body-worn operation, choose the belt clips or

holsters, which do not contain metallic components, to maintain a separation

RF exposure compliance with any body-worn accessory, which contains

metal, was not tested and certified, and use such body-worn accessory should

This device is compliance with SAR for general population /uncontrolled

exposure limits in ANSI/IEEE C95.1-1999 and had been tested in accordance

with the measurement methods and procedures specified in OET Bulletin 65

and at various positions, they all meet the government requirement

has been tested, and meets the FCC, IC RF exposure guidelines when tested

tested in accordance with the measurement methods and procedures

exposure to radio frequency (RF) energy set by the Federa

- · Make sure your phone is switched on and connected to a network (check for overloaded or unavailable network)
- Check your subscription status with your operator (credit, SIM card valid, etc.)

The caller's name/number does not appear when a call Make sure that your battery is not completely discharged; if

- Check that you have subscribed to this service with your operator

I cannot find my contacts

- Make sure your SIM card is inserted properly
- Import all contacts stored in SIM card to phone

The sound quality of the calls is poor

- You can adjust the volume during a call by pressing the \$\ding\$ key
- Make sure that the receiver, connector or speaker on you phone is clean

I am unable to use the features described in the manual

- includes this service
- Make sure this feature does not require an Alcatel accessory

- Make sure that you have correctly recorded the number in
- calling a foreign country

General information......

- Internet address: www.alcatelonetouch.com
- Hot Line Number: see "TCT Mobile Services" leaflet or go to our Internet site

On our Internet site, you will find our FAO (Frequently Asked Questions) section. You can also contact us by e-mail to ask any questions you may have.

An electronic version of this user guide is available in English and other languages according to availability on our server: www.alcatelonetouch.com

Your telephone is a transceiver that operates on GSM networks with 900 and 1800 MHz hands

Protection against theft '

Your telephone is identified by an IMEI (phone serial number) shown on the packaging label and in the product's memory. We recommend that you note the number the first time you use your telephone by entering * # 0 6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number allows your mobile telephone to be blocked preventing a third person from using it, even with a different SIM card.

Disclaimer

17

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator services.

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively.

Contact your network operator to check service availability

I am unable to add a contact in my contacts

· Make sure that your SIM card contacts are not full; delete some files or save the files in the phone contacts

The flickering icon is displayed on my standby

You have saved too many short messages on your SIM card: delete some of them or archive them in the phone memory SIM card PIN locked

Contact your network operator to obtain the PUK code

(Personal Unblocking Key) How to make your battery last longer

- Make sure you follow the complete charge time (minimum 3) hours)
- · After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the charger to obtain an exact indication
- Switch on the backlight upon request

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2012 TCT Mobile Limited.

material or technical specification without prior notice

and files will be lost permanently. Please store phone data in SIM card before you want to format

after purchase and for approximately 200 more recharges

2) Connection to any equipment not supplied or not

3) Modification or repair performed by individuals not authorised

liquids or foods, chemical products, download of files, crash,

There are no express warranties, whether written, oral or

In no event shall TCT Mobile Limited or any of its affiliates be liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or

Some countries/states do not allow the exclusion or limitation

During use, the actual SAR values for this device are usually well below the values stated above. This is because, for purposes of system efficiency and to

RADIO WAVES

THIS DEVICE MEETS INTERNATIONAL GLIDELINES FOR EXPOSURE TO

exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all available on the following site: http://www.who.int/peh-emf.

As mobile devices offer a range of functions, they can be used in positions

• FCC Regulations

Changes or modifications not expressly approved by the party responsible for

Make sure your battery is inserted properly and clean the

battery contact if it's dirty. It must be inserted before plugging

the battery power is empty for a long time, it may take around

When abroad, check that the voltage input is compatible

Verify the network coverage with your operator

Try selecting the available network(s) manually

• Make sure the SIM card has been correctly inserted

Make sure the service of your SIM card is available

network is not overloaded or unavailable

Check with your operator that your SIM card is valid

Try connecting at a later time if the network is overloaded

Make sure the chip on your SIM card is not damaged or

Make sure you have dialed a valid number and press the

Make sure your phone is connected to a network, and the

Check your subscription status with your operator (credit,

For international calls, check the country and area codes

My phone cannot connect to a network or "No service"

22

Unable to receive incoming calls

is received

20 minutes to display the battery charger indicator on the Your caller has concealed his/her name or number Make sure charging is carried out under normal conditions

Make sure your SIM card is not broken

- Check the network strength III

- Check with your operator to make sure that your subscription
- When I select a number from my contacts, the number cannot be dialed
- Make sure that you have inputted the country prefix when

TCT Mobile Limited reserves the right to alter

User Data Format ALL user phone data: Contacts, messages

2013-3-25 17:25:53

IP4244 MF100W QG Eng GB for FCC 01 130325.indd 2