

BelAir Networks Inc. 603 March Road Kanata, Ontario Canada K2K 2M5 www.belairnetworks.com



#### B2CH114AA

# B2CH114AA Product Manual DRU 2.4 GHz WLAN Radio Module

Document Date: Document Number: Document Version Number: Document Status: Nov 10, 2010 B2CH114AA 1 Release

© Copyright 2010 by BelAir Networks. All rights reserved.

# Contents

About this Document	2
Introduction	3
Conditions of Use	4
Module Installation and Service	5
Final Product Requirements	6
Regulatory Statements	11

## About this Document

This document is a product manual for the DRU 2.4 GHz WLAN Radio Module, including its limitations on use in any product marketed or offered for sale. It is intended as a supplement to training and documentation by BelAir Networks Inc. or its authorized agents.

### Introduction

The B2CH114AA (hereafter referred to as "the module") is a 2.4 GHz radio module compatible with the IEEE 802.11 standard for Wireless LAN operation. It is designed to be interoperable with WLAN products which are based on Orthogonal Frequency Division Multiplexing (OFDM) radio technology.

The module contains a complete IEEE 802.11b/g/n radio and Medium Access Control (MAC) protocol engine which allows implementation of an IEEE 802.11b/g/n access point (AP).

The module is not intended for stand-alone operation. It will only be marketed as a complete product, in conjunction with a package, DC power supply and antennas (hereafter referred to as "the product" or the "final product").

The module can be used in the 2.4 GHz ISM unlicensed bands.

Since the module has a BelAir networks proprietary digital interface, it cannot be directly connected to any standard telecommunications or computer devices. It can only be used with final products designed and authorized specifically for that purpose.

# **Conditions of Use**

#### **General Conditions of Use**

This manual is intended to supplement training provided by BelAir Networks or authorized parties. The module B2CH114AA is only intended for use in BelAir Networks products and is not for sale to the general public as a stand-alone module.

Please read this entire document, including the Regulatory Statements section before attempting to install or operate the module.

**Warning:** Any use of B2CH114AA in any manner which is not expressly specified within this manual or specifically approved by BelAir Networks or its authorized agents will void the user's right to operate this module, and is expressly forbidden by BelAir Networks. This includes any modification of the module, installation of the module in a configuration or used with antennas which are not expressly listed in this document or approved by BelAir Networks.

#### **Country of Use**

B2CH114AA is certified with limited modular approval for use as an Intentional Radiator in the United States as device: FCC ID: RAR30002002 and in Canada as IC: 4674A-30002002. Please read all regulatory statements at the end of this document before any attempt to install or operate this module.

The module is only certified for operation in the United States and Canada. Before attempting to install and operate this module in any other country, contact BelAir Networks for approval.

#### **Module Labeling**

One or more labels are applied to the module during manufacture, including a label which identifies the FCC and Industry Canada identification numbers. Do not attempt to remove any labels from the module.

## **Module Installation and Service**

#### Installation into a Product

The module shall only be installed by a technician trained by BelAir Networks or its authorized agents. It should only be installed into an approved product (see above) following all manufacturing and service procedures for that product. The module should only be installed into a final product in a manufacturing or service depot site.

**Caution:** B2CH114AA is an electro-static discharge (ESD) sensitive device. All appropriate ESD measures must be taken when handling the module. Failure to employ appropriate ESD protection may damage the module.

#### **Module Service**

The module is not intended as a field-serviceable unit. It contains no fieldreplaceable or field-serviceable parts, or any external adjustable mechanisms. The module should only be serviced in a manufacturing or service depot site approved by BelAir Networks or its authorized agents.

## **Final Product Requirements**

The requirements below apply to any final product in which the B2CH114AA module is installed.

#### Antenna Usage and Module Transmit Power

The DRU 2.4GHz radio module supports MIMO 2x3 configuration with two transmit chains and three receive chains. The B2CH114AA module shall only be used at the following output power levels in conjunction with the following antenna types as outlined in the tables that follow.

### 2400-2483.5 MHz - Part 15.247 Subpart C

For operation in the 2400-2483.5 MHz ISM band, the B2CH114AA may be set to operate on 20 MHz channel bandwidths.

Omni Antennas									
Modulation	Freq. (MHz)	output power (dBm)	Conducted output power limit (dBm)	Conducted output power margin (dB)	Antenna gain (dBi)	Cable loss (dB)	EIRP (dBm)	EIRP Limit (dBm)	EIRP Margin (dB)
	2412	21.45	30	8.55	5	0.5	25.95	36	10.05
	2437	28.77	30	1.23	5	0.5	33.27	36	2.73
802.11n	2462	21.75	30	8.25	5	0.5	26.25	36	9.75
	2412	21.49	30	8.51	5	0.5	25.99	36	10.01
	2437	28.63	30	1.37	5	0.5	33.13	36	2.87
802.11g	2462	22.27	30	7.73	5	0.5	26.77	36	9.23
	2412	27.33	30	2.67	5	0.5	31.83	36	4.17
	2437	27.08	30	2.92	5	0.5	31.58	36	4.42
802.11b	2462	26.83	30	3.17	5	0.5	31.33	36	4.67
	2412	21.45	28.5	7.05	8	0.5	28.95	36	7.05
	2437	28.11	28.5	0.39	8	0.5	35.61	36	0.39
802.11n	2462	19.7	28.5	8.8	8	0.5	27.2	36	8.8
	2412	21.49	28.5	7.01	8	0.5	28.99	36	7.01
	2437	27.86	28.5	0.64	8	0.5	35.36	36	0.64
802.11g	2462	20.8	28.5	7.7	8	0.5	28.3	36	7.7
	2412	27.33	28.5	1.17	8	0.5	34.83	36	1.17
	2437	27.08	28.5	1.42	8	0.5	34.58	36	1.42
802.11b	2462	26.39	28.5	2.11	8	0.5	33.89	36	2.11

Directional antennas (Point to Point P2P)								
Modulation	Freq. (MHz)	Output power (dBm)	Conducted output power limit (dBm)	Conducted output power margin (dB)	Antenna gain (dBi)	Cable loss (dB)	EIRP (dBm)	
	2412	22.52	29.5	6.98	8	0.5	30.02	
	2437	28.11	29.5	1.39	8	0.5	35.61	
802.11n	2462	23.88	29.5	5.62	8	0.5	31.38	
	2412	23.02	29.5	6.48	8	0.5	30.52	
	2437	27.86	29.5	1.64	8	0.5	35.36	
802.11g	2462	25.05	29.5	4.45	8	0.5	32.55	
	2412	27.33	29.5	2.17	8	0.5	34.83	
[	2437	27.08	29.5	2.42	8	0.5	34.58	
802.11b	2462	27.16	29.5	2.34	8	0.5	34.66	
	2412	25.82	26.83	1.01	16	0.5	41.32	
[	2437	26.58	26.83	0.25	16	0.5	42.08	
802.11n	2462	26.78	26.83	0.06	16	0.5	42.28	
	2412	25.93	26.83	0.9	16	0.5	41.43	
	2437	26.78	26.83	0.06	16	0.5	42.28	
802.11g	2462	26.4	26.83	0.43	16	0.5	41.9	
	2412	26.75	26.83	0.08	16	0.5	42.25	
	2437	26.62	26.83	0.21	16	0.5	42.12	
802.11b	2462	26.39	26.83	0.44	16	0.5	41.89	

Directional ant	Directional antenna (Point to Multipoint P2MP)									
			Conducted	Conducted						
			output power	output power						
	Freq.	Output power	limit	margin	Antenna gain	Cable loss	EIRP	EIRP Limit	EIRP Margin	
Modulation	(MHz)	(dBm)	(dBm)	(dB)	(dBi)	(dB)	(dBm)	(dBm)	(dB)	
	2412	22.52	28.5	5.98	8	0.5	30.02	36	5.98	
	2437	28.11	28.5	0.39	8	0.5	35.61	36	0.39	
802.11n	2462	23.88	28.5	4.62	8	0.5	31.38	36	4.62	
	2412	23.02	28.5	5.48	8	0.5	30.52	36	5.48	
	2437	27.86	28.5	0.64	8	0.5	35.36	36	0.64	
802.11g	2462	25.05	28.5	3.45	8	0.5	32.55	36	3.45	
	2412	27.33	28.5	1.17	8	0.5	34.83	36	1.17	
	2437	27.08	28.5	1.42	8	0.5	34.58	36	1.42	
802.11b	2462	27.16	28.5	1.34	8	0.5	34.66	36	1.34	

Directional ant	Directional antenna with triplexer (Point to Point P2P)									
			Conducted	Conducted						
			output power	output power						
	Freq.	output power	limit	margin	Antenna gain	Cable loss	EIRP			
Modulation	(MHz)	(dBm)	(dBm)	(dB)	(dBi)	(dB)	(dBm)			
	2412	22.99	26.83	3.84	16	0.5	38.49			
	2437	26.06	26.83	0.78	16	0.5	41.56			
802.11n	2462	26.51	26.83	0.33	16	0.5	42.01			
	2412	23	26.83	3.83	16	0.5	38.5			
	2437	26.16	26.83	0.67	16	0.5	41.66			
802.11g	2462	26.68	26.83	0.16	16	0.5	42.18			
	2412	25.78	26.83	1.05	16	0.5	41.28			
	2437	25.16	26.83	1.67	16	0.5	40.66			
802.11b	2462	25.1	26.83	1.73	16	0.5	40.6			

Directional ant	Directional antenna with triplexer (Point to Multipoint P2MP)									
Modulation	Freq. (MHz)	Output power (dBm)	Conducted output power limit (dBm)	Conducted output power margin (dB)	Antenna gain (dBi)	Cable loss (dB)	EIRP (dBm)	EIRP Limit (dBm)	EIRP Margin (dB)	
	2412	19.87	20.5	0.63	16	0.5	35.37	36	0.63	
	2437	20.03	20.5	0.47	16	0.5	35.53	36	0.47	
802.11n	2462	20.06	20.5	0.44	16	0.5	35.56	36	0.44	
	2412	19.9	20.5	0.6	16	0.5	35.4	36	0.6	
	2437	19.72	20.5	0.78	16	0.5	35.22	36	0.78	
802.11g	2462	19.73	20.5	0.77	16	0.5	35.23	36	0.77	
	2412	20.05	20.5	0.45	16	0.5	35.55	36	0.45	
	2437	19.72	20.5	0.78	16	0.5	35.22	36	0.78	
802.11b	2462	19.72	20.5	0.78	16	0.5	35.22	36	0.78	

#### **Certified Antennas:**

The following antennas are certified for use:

Manufacter	Part #	Gain (dBi)	Туре
BelAir	BMAG00287-A	5 dBi	Omni
BelAir	BNCKG0057	8 dBi	Omni
BelAir	BMAH00263-A	8 dBi	Directional
BelAir	BNCKG0082	16 dBi	Directional

In order to comply with the FCC and Industry Canada rules in the USA and Canada, respectively, it is required to respect the maximum transmit power limits as follows for each of the antenna types as indicated in the above tables.

**Warning:** Use of this module in conjunction with any antenna not expressly listed above will void authority to install or operate this equipment.

**Warning:** Setting of module transmit power above the limits specified in the above table for a particular combination of antenna type, frequency of operation, and type of usage, will exceed FCC or Industry Canada limits and void authority to install or operate this equipment.

**Warning:** Directional antennas must be used exclusively for fixed, point-to-point operations. The installer is responsible for ensuring that the radio is used exclusively for fixed, point-to-point operations when directional antennas are used.

### **Product Installation**

Products which contain B2CH114AA shall only be installed by professional installers trained by BelAir Networks or its authorized agents. This product is to be installed on fixed permanent structures. In addition to normal installation procedures and good installation practice, professional installers are responsible to ensure that:

- 1. Only an approved antenna (see above) is connected to the module, and,
- 2. The antenna is mounted in such a manner and in such a location that access to the antenna by the general population is minimized. Access to the antenna by the general population should be limited to more than the minimum safety distance. This distances are outlined according to product type and whether high gain antennas are used:

Minimum Safety Distances								
Standard	Antennas	Meduim Gai	n Antennas	High Gain Antennas (up to 22 dBi)				
DRU 2.4GHz radio	DRU 5GHz radio	DRU 2.4GHz radio	DRU 5GHz radio	DRU 2.4GHz radio	DRU 5GHz radio			
5 dBi	7 dBi	≤ 8dBi	≤ 15dBi	> 8dBi	> 15dBi			
Minimum Distance		Minimum	Distance	Minimum Distance				
8.1 inches		19.3 i	nches	42.9 i	nches			

Adherence to these rules by the professional installer is mandatory. See full installation procedures for the particular product for details.

### **Product Labeling**

The following permanent label, or one containing equivalent information, must be affixed in a conspicuous location on the exterior of every product containing this module:

## **Regulatory Statements**

The following regulatory notes apply to the product which contains module B2CH114AA. The following sections or equivalent information shall appear in the user-manual of the final product.

#### **Regulatory Information and Disclaimers**

Installation and use of this device must be in strict accordance with the instructions included in the user documentation provided with the product. Any changes or modifications to this product not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

The manufacturer is not responsible for any interference to radio or television equipment caused by unauthorized modification of this device, or attachment of any antennas or equipment other than those specified by the manufacturer. The manufacturer or its authorized resellers or distributors will assume no liability for any damage or violation of government regulations arising from failing to comply with these guidelines.

#### Manufacturer's FCC Conformity Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

• Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### Manufacturer's Industry Canada Conformity Statement

This device has been designed to operate with an antenna having a maximum gain of 16 dBi. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.

This device has been designed to ensure that radio frequency emissions are maintained within the band of operation under all normal operating conditions listed in this manual.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropic radiated power (EIRP) is not more than that required for successful communication.

This Class B Digital apparatus meets all the requirements of the Canadian Interference-Causing Equipment Regulations.

#### **RF Exposure Statement**

This device complies with FCC RF radiation exposure limits for an uncontrolled environment. The radiated output power of this Wireless LAN device is below the FCC radio frequency exposure limits. However, this device should still be installed and used in such a manner that the potential for human contact during normal operation is minimized. In order to comply with RF exposure limits established in the ANSI C95.1 standard, this equipment should be installed and operated at a minimum distance between the radiator and a human body. This minimum distance is:

Minimum Safety Distances								
Standard Antennas		Meduim Gai	in Antennas	High Gain Antennas (up to 22 dBi)				
DRU 2.4GHz radio	DRU 5GHz radio	DRU 2.4GHz radio	DRU 5GHz radio	DRU 2.4GHz radio	DRU 5GHz radio			
5 dBi	7 dBi	≤ 8dBi	≤ 15dBi	> 8dBi	> 15dBi			
Minimum Distance		Minimum	Distance	Minimum Distance				
8.1 inches		19.3 i	nches	42.9 i	nches			

#### BelAir Networks Inc.

603 March Road Kanata, Ontario Canada K2K 2M5 **613-254-7070** 

#### Sales sales@belairnetworks.com Support support@belairnetworks.com General Information Info@belairnetworks.com