


ANNN Tag

Manual



Important tips: When pairing a device with Find My® app, the phone will link to the Apple® Server . Pairing may fail because of network problems. The following actions are recommended: Change the phone's network, such as switching between WiFi and mobile network.

01. Getting Started

01.1 Power On / Off:

Press the iTag Function Button once to turn it on. It should beep once to indicate that it is powered on.

To power off, hold the same button for at least three seconds. You will hear two beeps to indicate that your iTag is powered off.



01.2 Check For Updates:

To use the Apple® Find My® app to locate this item, the latest version of iOS®, iPadOS®, or macOS® is recommended. The Find Items app on Apple Watch® requires the latest version of watchOS®.

02. Add Your iTag

02.1 Start The App

Open Find My app on your supported iPhone®.

02.2 Connect Your iTag

Press the function button once to power on your iTag.

Tap+, then "Add Other Item" .

Once your iTag is located, tap "connect"

Enter a name and choose an emoji for your iTag and tap "Continue".

Find My will ask for confirmation to add your iTag to your Apple ID Tap "Agree"

Tap "Finish" and your iTag will be set up and ready to be used.

03. Locate Your iTag

03.1 Find iTag When It's Nearby:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch.

Tap on your iTag from the list.

Tap "Play Sound" to make your iTag beep.

Tap "Stop Sound" to stop the beeps once you find.

03.2 Find iTag's Location:

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your iTag from the list.
Your iTag's location will appear on the Map with a time stamp of when the item was located. To navigate to the iTag's location, tap "Directions" to open Apple Maps .

04. Notifications

04.1 Enabling "Notify When Left Behind":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your iTag from the list.
Under "Notifications" enable the "Notify When Left Behind" toggle.
You will receive a notification when you leave your iTag behind and it's no longer in range of your device.

04.2 Enabling "Notify When Found":

Under "Notifications", enable the "Notify When Found" toggle.
When your iTag is seen by another Find My network device, you will receive a notification of its location.
Note : "Notify When Found" can only be activated when your iTag is out of range.

05. When Your iTag Is Lost

05.1 Enabling "Lost Mode":

Open Find My app and select the "Items" tab or open the Find Items app on your Apple Watch. Tap on your iTag from the list.
Under "Lost Mode" tap "Enable"
A screen detailing Lost Mode will pop up, tap "Continue"
Enter your phone number or email address and tap "Next".
You may enter a message that will be shared with the person that finds your item.
Tap "Activate" to enable "Lost Mode"
Note: When "Lost Mode" is enabled, "Notify When Found" is automatically enabled.
Note: When "Lost Mode" is enabled, your iTag is locked and cannot be paired to a new device.

06. Resetting iTag

06.1 Remove The iTag From Find My App:

Open Find My app and select the "Items" tab.
Tap on your iTag from the list.
Please ensure "Lost Mode" is disabled.
Scroll to the bottom of the screen and tap "Remove Item".
A summary will open, tap "Remove" to confirm.

06.2 Connect Your iTag

After successfully removing the iTag from Find My app, press the iTag's function button four times rapidly and then hold it a fifth time until you hear a ringing chime.
The iTag is now reset and ready to be paired to a new Apple ID.

07. Extras

07.1 Replace The Battery:

Carefully open the shell along the gap in the middle of the iTag.
Replace the battery with a new CR2032 battery, with the positive side facing up (with the text side facing up).
Carefully close the iTag by aligning the top holes on both sides

07.2 Unwanted tracking:

If any Find My network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

1. If you have an iPhone, iPad®, Find My will send a notification to your Apple device. This feature is available on iOS or iPadOS 14.5 or later.
2. If you don't have an iOS device or a smartphone, a Find My network accessory that isn't with its owner for a period of time will emit a sound when it's moved.

These features were created specifically to discourage people from trying to track you without your knowledge.

08. The Fine Print

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications or changes to this equipment. Such modifications or changes not expressly approved by the party responsible for compliance could void the user's authority to operate this device.

The device has been evaluated to meet general RF exposure requirement, The device can be used in portable exposure conditions without restriction. Federal Communication Commission (FCC) Radiation Exposure Statement Power is so low that no RF exposure calculation is needed.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radiofrequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

09. About Apple Find My

The Apple Find My network provides an easy, secure way to locate compatible personal items using the Find My app on your iPhone, iPad, Mac®, or the Find Items app on Apple Watch.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device: The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.