

Figure 1: EL-2614

The EL-2614 is a keyfob transmitter designed for use with Electronics Line 3000's supervised wireless range of receivers.

## Registration

To register the EL-2614:

1. Set the receiver to Registration mode.
2. Press one of the buttons, making sure that the LED lights up when the button is pressed.
3. Press the same button again to complete the registration process.

## Battery Replacement

If the LED blinks during transmissions, this indicates that the batteries are low and need replacing.

To replace the batteries:

1. Insert a small screwdriver into the pry-off slot – see *Figure 2*. Carefully twist the screwdriver to separate the front and back of the casing.
2. Observing correct polarity, replace the batteries.
3. Close the casing making sure that the front and back click shut.




Figure 2: Opening the Casing

## Technical Specifications

Antenna: Built-in whip

Frequency: 418MHz FM

Power: 2 x 3V Lithium Battery,

Size CR1225 (Part No. BT5099)

Current Consumption:

16mA (transmission),

2µA (standby)

RFI Immunity: 40V/m

Operating Temperature: 32-140°F (0 to 60°C)

Dimensions: 2.4"H X 1.7"W X 0.6"D (62 x 42 x 15mm)

FCC ID: RIYEL2614




Figure 3: EL-2614  
Rear View (Casing Open)

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna, 2. Increase the separation between the equipment and the receiver, 3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected, 4. Consult the dealer or an experienced radio/TV technician for help.

**Warning:** Changes or modifications to this equipment not expressly approved by the party responsible for compliance (Electronics Line 3000 Ltd.) could void the user's authority to operate the equipment.



Electronics Line

**Electronics Line 3000 Ltd.:** 2 Granit Street, Kiryat Arie, POB 3253, Petah Tikvah 49130 Israel. Tel: (972-3) 918-1333, Fax: (972-3) 922-0831

**USA:** 5637 Arapahoe Avenue, Boulder, Colorado 80303. Tel: (800) 683-6835, Fax: (303) 938-8062

**UK:** Unit 7, Levis Trading Estate, Station Road, Stechford, Birmingham B33 9AE. Tel: (44-121) 789-8111, Fax: (44-121) 789-8055

**France:** ZI-61, rue du Marché Rollay, 94500 Champigny-Sur-Marne. Tel: (33-1) 45.16.19.20, Fax: (33-1) 45.16.19.29

All data is subject to change without prior notice. In no event shall Electronics Line 3000 Ltd. (EL3K) be liable for an amount in excess of EL3K's original selling price of this product, for any loss or damage whether direct, indirect, incidental, consequential or otherwise arising out of any failure of the product.

ZI0311A (11/03)