



RBW 1 MHz

Delta 1 [T1]

*VBW 1 MHz


-54.37 dB

Ref -20 dBm

*Att 0 dB

SWT 80 ms

26.720000 ms

1 PK
VIEW

Center 433.916 MHz

8 ms/

Duty Cycle

$$= \frac{4.4 + 2 \times 0.7 + 5 \times 1.8}{26.72}$$

$$= 0.554$$

Average Factor

$$= 20 \log (0.554)$$

$$= -5.1 \text{ dB}$$




RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz 0.02 dB
SWT 50 ms 4.400000 ms

Ref -20 dBm

*Att 0 dB

1 PK
VIEW



Center 433.916 MHz

5 ms/



A




RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz 1.05 dB
SWT 50 ms 700.000000 μ s

Ref -20 dBm

*Att 0 dB

1 PK
VIEW



Center 433.916 MHz

5 ms/




RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz 0.04 dB
SWT 50 ms 1.800000 ms

Ref -20 dBm

*Att 0 dB

1 PK
VIEW



A

Center 433.916 MHz

5 ms/




RBW 1 MHz Delta 1 [T1]
*VBW 1 MHz -37.85 dB
SWT 10 s 320.000000 ms

Ref -20 dBm

*Att 0 dB

1 PK *
VIEW



Center 433.93 MHz

1 s/