




Ref 87 dBuV Att 10 dB RBW 1 MHz Delta 1 [T1 ]  
 \*VBW 1 MHz -0.00 dB  
 SWT 100 ms 24.100000 ms



Duty Cycle:

$$= \frac{(22 \times 0.4) + (3 \times 0.81)}{24.1} \text{ ms}$$

$$= \frac{11.23}{24.1} \text{ ms}$$


$$= 0.466$$

Average Factor:

$$= 20\text{Log}(0.466)$$

$$= -6.6$$


Date: 5.NOV.2009 14:12:05



Date: 5.NOV.2009 14:12:42




Ref 87 dBμV Att 10 dB RBW 1 MHz Delta 1 [T1 ]  
\*VBW 1 MHz -0.24 dB  
SWT 5 ms 810.000000 μs



Date: 5.NOV.2009 14:14:36



Ref 87 dBuV Att 10 dB RBW 1 MHz Delta 1 [T1 ]  
\*VBW 1 MHz -0.20 dB  
SWT 5 ms 400.000000 μs



Date: 5.NOV.2009 14:15:03